



Connect Series Accessories

CONNECT SERIES ACCESSORIES


Table of Contents

<u>ALTERNATOR HEATERS</u>	<u>1</u>
<u>ANNUNCIATORS</u>	<u>2</u>
<u>AUXILIARY</u>	<u>3</u>
AUXILIARY CONFIGURABLE SIGNAL INPUTS / RELAY OUTPUTS	3
AUXILIARY OUTPUTS RELAYS	3
<u>BATTERIES</u>	<u>4</u>
<u>BATTERY ACCESSORIES</u>	<u>4</u>
BATTERY HEATER KITS	4
BATTERY TRAY KITS	4
<u>BATTERY CHARGERS</u>	<u>5</u>
<u>CIRCUIT BREAKERS</u>	<u>6-16</u>
CIRCUIT BREAKER ACCESSORIES	6
CIRCUIT BREAKER KITS	6-16
<u>COLD WEATHER ACCESSORIES</u>	<u>17</u>
EXTREME COLD ACCESSORY KITS	17
<u>EXCITER / VOLTAGE REGULATOR KITS</u>	<u>18</u>
EXCITATION BOOST SYSTEM KIT	18
PERMANENT MAGNET GENERATOR KIT	18
<u>LOAD MANAGEMENT KIT</u>	<u>18</u>
<u>MAINTENANCE</u>	<u>19</u>
PAINTS	19
PREVENTATIVE MAINTENANCE KITS	19
<u>REMOTE DISPLAYS</u>	<u>20-21</u>
REMOTE DISPLAY	20
REMOTE BARGRAPH DISPLAY	20
REMOTE UNIT HMI 220/320	21
<u>SAFETY</u>	<u>21-22</u>
ALARM INSTALLATION, AUDIBLE, ENGINE SHUTDOWN	21
EMERGENCY STOP DISPLAY PANEL	21
LOW COOLANT LEVEL KIT	21
OIL MAKEUP SYSTEM KITS	22
<u>FLEXIBLE FUEL HOSE</u>	<u>23</u>
<u>SOUND</u>	<u>24</u>
BASE BARRIER – ELEVATED GENERATORS	24
SOUND KITS	24
<u>MOUNTING PADS</u>	<u>25</u>
<u>DISPLAY TILTING KIT</u>	<u>25</u>

Alternator Heaters

Prevents condensation and frost from forming on the alternator. Designed to prevent corrosive damage of electrical and mechanical components in high humidity environments.

Part Number	Compatibility	Kit Includes
A044G635	Generators using the CA125 or CA135 Alternators: RS36, RS40 RX40, RX45, RX50, RX60	Alternator heater, marking label, cable ties, hex nuts, lock washers, thread sealant, instruction sheet
A044G637	Generators using the CA115 Alternator: RS22, RS25, RS30, RS36, RS40 RX30, RX36, RX40, RX45, RX50	Alternator heater, marking label, cable ties, hex nuts, lock washers, thread sealant, instruction sheet



Annunciators

RS485 Annunciator

The Universal Annunciator Module provides visual and audible indication of up to 20 separate alarm or status conditions, based on discrete (relay) inputs or network inputs. Each LED can be controlled by either a discrete wire input or by a signal on the PCCnet network sent from an external device, such as a PCC1302, 2300, 3300 controls. Remote annunciator panels comply with NFPA 110 (Emergency and Standby Power Systems). The annunciator module can also be used for monitoring of transfer switch or other equipment status.

In addition to the LEDs, the annunciator can control four custom relays based on signals received over the PCCnet. When one of the annunciator's discrete inputs is activated, the annunciator will broadcast that information over the network. By taking advantage of the network, discrete inputs and custom relays, the annunciator can be used as expanded I/O for a PCC1302, 2300, 3300 controls.


Part Number	Compatibility	Kit Includes
A045J199	RS22, RS25, RS30, RS36, RS40 RX30, RX36, RX40, RX45, RX50, RX60 RS50, RS60, RS80, RS100 RS125, RS150	Panel Mount version: Annunciator, wiring harness, cable tie, and window splice
A045J201		Enclosure version: Annunciator, wiring harness, cable tie, and window splice



Auxiliary

Auxiliary Configurable Signal Inputs / Relay Outputs


The PowerCommand® AUX101 Input/Output module provides up to eight Form-C relay output sets and eight (8) discrete/analog inputs for auxiliary control and monitoring of the power system. The relays may be configured individually from the generator control operator interface or using InPower Software.



Part Number	Compatibility	Kit Includes
A044Z055	RS22, RS25, RS30, RS36, RS40 RX30, RX36, RX40, RX45, RX50, RX60 RS50, RS60, RS80, RS100 RS125, RS150	Input/Output Card, Protection Cover, Circuit Card Harness, Generator Electrical Harness, Electrical Guard, hardware, and instruction sheet

Auxiliary Output Relays

Allows for remote control functionality from controller. The relays can handle up to 600 VAC @ 10 amps (or 30 VDC @ 10A) with 4 poles (2 poles normally open, 2 poles normally closed).



Part Number	Compatibility	Kit Includes
A044Z053	RS22, RS25, RS30, RS36, RS40 RX30, RX36, RX40, RX45, RX50, RX60 RS50, RS60, RS80, RS100 RS125, RS150	Two relays, harness, screws, cable ties, and instruction sheet

Batteries

Part Number	Standby/Cold	Group	Compatibility
A052Y816	Standby Battery	51R – 450 CCA	RS13A, RS17A, RS20A
0416-1051	Standby Battery	26 – 530 CCA	RS22, RS25, RS30, RS36, RS40, RX30, RX36, RX40, RX45, RX50, RX60
A045P632	Cold Starting	34 – 850 CCA	RS22, RS25, RS30, RS36, RS40, RX30, RX36, RX40, RX45, RX50, RX60
A045P632	Standby Battery	34 – 850 CCA	RS50, RS60, RS80, RS100 RS125 *, RS150 *
A030Y976	Cold Starting	4D – 1050 CCA	RS50, RS60, RS80, RS100

* - For Cold Starting, these generators take 2 of these batteries

Battery Accessories

Battery Heater Kits

Improves cold weather starting performance. Requires external power source connected to heater.

Part Number	Compatibility	Kit Includes
A046G494	RS22, RS25, RS30, RS36, RS40 RX30, RX36, RX40, RX45, RX50, RX60	Heater pad with build-in thermostat, cable ties, instruction sheet
A052E356	RS50, RS60, RS80, RS100	Heater pad with build-in thermostat, cable ties, instruction sheet
A054X752	RS125, RS150	Heater pad with build-in thermostat, cable ties, instruction sheet



A046G494

Battery Tray Kits


Larger tray which allows for installation of larger battery in place of the standard battery.

Part Number	Compatibility	Kit Includes
A052A484	RS50, RS60, RS80, RS100	Battery tray, battery strap, screws, grommet, tie cable

Battery Chargers

Battery Charger - 10A (12 VDC)

Cummins fully automatic battery chargers - using switched mode power electronics - are constant voltage/constant current chargers incorporating a 4-stage charging algorithm. Designed for use in applications where battery life and reliability are important; these chargers, complete with built-in equalize charge capability, are ideal for stationary or portable starting battery charging service. To achieve optimum battery life, a 4-stage charging cycle is implemented. The four charging stages are trickle, bulk, absorption and float. The trickle stage safely charges overly discharged batteries. It protects a damaged or shorted battery from excessive current. During bulk charge a constant current is applied to quickly restore the maximum battery charge level in the shortest amount of time.



Part Number	Compatibility	Kit Includes
A048G602	RS22, RS25, RS30, RS36, RS40 RX30, RX36, RX40, RX45, RX50, RX60 RS50, RS60, RS80, RS100 RS125, RS150	Battery charger, operator's manual, and instruction sheet

Battery Charger - 6A (12 VDC)

Cummins fully automatic battery chargers use a 3-stage charging cycle to maximize battery life. During the bulk stage, the charger uses its full amp output to do the heaviest charging, quickly bringing your battery to about 75% of capacity. In the absorption stage, the current slows, adjusting for maximum charging efficiency while it gently tops off the battery to about 98% of capacity. During the maintenance stage, a lower, closely-regulated, constant voltage is applied to maintain full charge and prevent discharge.



Part Number	Compatibility	Kit Includes
A045D925	RS22, RS25, RS30, RS36, RS40 RX30, RX36, RX40, RX45, RX50, RX60	Battery charger, cable ties, screws, terminal block connectors, and instruction sheet
A052A181	RS50, RS60, RS80, RS100, RS125, RS150	Battery charger, cable ties, screws, terminal block connectors, and instruction sheet

Circuit Breakers

Circuit Breaker Accessories

Part Number	Type	Description	Kit Includes
0406-1234	Lockout	Allows for locking of H-, J-, and D- frame Square D circuit breakers in the off position using up to 3 padlocks	1 Locking plate
A054Z037	Lockout	Allows for locking of P- frame Square D circuit breakers in the off position using up to 3 padlocks	1 Locking plate
A043X760	Shunt Trip	Allows the ability to remotely trip the Square D circuit breakers when the shunt trip is energized	Shunt trip and 12 VDC-1 circuit breaker
A043X785	Switch Auxiliary	Provides a Remote Signal Indicating the Circuit Breaker Contacts are Open or Closed, Auxiliary Switch 1A/1B, Trip indication, Overcurrent indication	1 Switch
A026M166	Wire Seal Kit	Allows for locking of Square D circuit breakers with electronic trip to prevent changes being made to set trip level	6 Seal kits

Circuit Breaker Kits

Use the tables in the following pages to determine the part numbers needed in order to change the current circuit breaker or add additional breakers.

For RS22, RS25, RS30, RS36, RS40 RX30, RX36, RX40, RX50, and RX60:

1. Locate the model in Model Reference Table #1
 - a. Read across the table to find the alternator and circuit breaker the generator was shipped with
2. Locate the desired circuit breaker amperage on the Single Phase or Three Phase table and do the following:
 - a. Read across for the Alternator Model
 - b. Continue to read across and find the necessary accessory part numbers:
 - i. Single Circuit Breaker: Order Accessory 1 (Breaker)
 - ii. Dual Circuit Breaker: Order Accessories 1, 2, and 3 (Breaker, Hardware, and Lead Kit)

For RS50, RS60, RS80, RS100, RS125, and RS150:

1. Locate the model in Model Reference Table #2
 - a. Read across the model to find the circuit breaker the generator was shipped with
2. Locate the desired circuit breaker amperage on Model Reference Table #3 and #4

Use Table #3 for RS50, RS60, RS80, and RS100

Use Table #4 for RS125 and RS150

 - a. Read across and find the necessary accessory part numbers to order based off the position desired
 - i. The circuit breaker is the same regardless of position
 - ii. Dual Circuit Breaker: Order Accessories 1, 2, and 3 (Breaker; Hardware, and Lead Kit)

Model Reference Table #1

Product Name	Marketing Name	Updated Preconfigured	Engine RPM	Voltage	Phase	Alternator	Circuit Breaker	Compatible Exciter/Regulator
RS22	C22 N6	A051X280	1800	120/240	1 phase	CA115	100	EBS
RS22	C22 N6	A051Y397	1800	120/208	3 phase	CA115	90	EBS
RS22	C22 N6	A051Y398	1800	120/240	3 phase	CA115	80	EBS
RS25	C25 N6	A051Y239	1800	120/240	1 phase	CA115	125	EBS
RS25	C25 N6	A051Y399	1800	120/208	3 phase	CA115	100	EBS
RS25	C25 N6	A051Y400	1800	120/240	3 phase	CA115	90	EBS
RS30	C30 N6	A051Y401	1800	120/240	1 phase	CA115	150	EBS
RS30	C30 N6	A051Y402	1800	120/208	3 phase	CA115	125	EBS
RS30	C30 N6	A051Y405	1800	120/240	3 phase	CA115	100	EBS
RS36	C36 N6	A051Y417	1800	120/240	1 phase	CA115	175	EBS
RS36	C36 N6	A051Y418	1800	120/208	3 phase	CA115	150	EBS
RS36	C36 N6	A051Y413	1800	120/240	3 phase	CA115	125	EBS
RS36	C36 N6	A051Y416	1800	277/480	3 phase	CA115	60	EBS
RS40	C40 N6	A051Y419	1800	120/240	1 phase	CA125	200	PMG
RS40	C40 N6	A051Y420	1800	120/208	3 phase	CA115	175	EBS
RS40	C40 N6	A051Y421	1800	120/240	3 phase	CA115	150	EBS
RS40	C40 N6	A051Y424	1800	277/480	3 phase	CA115	80	EBS
RX30	C30 N6H	A051Y426	3600	120/240	1 phase	CA115	150	
RX30	C30 N6H	A051Y428	3600	120/208	3 phase	CA115	125	
RX30	C30 N6H	A051Y429	3600	120/240	3 phase	CA115	100	
RX36	C36 N6H	A051Y444	3600	120/240	1 phase	CA115	175	
RX36	C36 N6H	A051Y448	3600	120/208	3 phase	CA115	150	
RX36	C36 N6H	A051Y453	3600	120/240	3 phase	CA115	125	
RX36	C36 N6H	A051Y458	3600	277/480	3 phase	CA115	60	
RX40	C40 N6H	A051Y459	3600	120/240	1 phase	CA115	200	
RX40	C40 N6H	A051Y463	3600	120/208	3 phase	CA115	175	
RX40	C40 N6H	A051Y465	3600	120/240	3 phase	CA115	150	
RX40	C40 N6H	A051Y467	3600	277/480	3 phase	CA115	80	
RX45	C45 N6H	A051Y468	3600	120/240	1 phase	CA135	200	
RX45	C45 N6H	A051Y469	3600	120/208	3 phase	CA115	200	
RX45	C45 N6H	A051Y472	3600	120/240	3 phase	CA115	150	
RX45	C45 N6H	A051Y473	3600	277/480	3 phase	CA115	80	
RX50	C50 N6H	A051Y474	3600	120/240	1 phase	CA135	200	
RX50	C50 N6H	A051Y476	3600	120/208	3 phase	CA115	200	
RX50	C50 N6H	A051Y477	3600	120/240	3 phase	CA115	175	
RX50	C50 N6H	A051Y478	3600	277/480	3 phase	CA115	90	
RX60	C60 N6H	A051Y479	3600	120/240	1 phase	CA135	250	
RX60	C60 N6H	A051Y480	3600	120/208	3 phase	CA135	250	
RX60	C60 N6H	A051Y482	3600	120/240	3 phase	CA135	200	
RX60	C60 N6H	A051Y483	3600	277/480	3 phase	CA135	100	

SINGLE PHASE

													Accessories					
CIRCUIT BREAKER				CIRCUIT BREAKER SELECTION												1	2	3
Feature Code "A" POSITION	Feature Code "B" POSITION	Amps	Model	Alternator Model	C22N6	C25N6	C30N6	C36N6	C40N6	C30N6H	C36N6H	C40N6H	C45N6H	C50N6H	C60N6H	CIRCUIT BREAKER	Hardware Kit	"B" Position LEADS Kit
KV05-2	KV55-2	15	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z201	A045P241	A045A626
				CA125				X	X									A045B104
				CA135								X	X	X	X			A045B104
KV06-2	KV56-2	20	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z200	A045P241	A045A626
				CA125				X	X									A045B104
				CA135								X	X	X	X			A045B104
KV07-2	KV57-2	25	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z203	A045P241	A045A626
				CA125				X	X									A045B104
				CA135								X	X	X	X			A045B104
KV08-2	KV58-2	30	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z199	A045P241	A045A626
				CA125				X	X									A045B104
				CA135								X	X	X	X			A045B104
KV09-2	KV59-2	40	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z198	A045P241	A045A626
				CA125				X	X									A045B104
				CA135								X	X	X	X			A045B104
KV10-2	KV60-2	50	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z197	A045P241	A045A626
				CA125				X	X									A045B104
				CA135								X	X	X	X			A045B104
KV11-2	KV61-2	60	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z196	A045P241	A045A626
				CA125				X	X									A045B104
				CA135								X	X	X	X			A045B104
KV12-2	KV62-2	70	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z195	A045P241	A045A626
				CA125				X	X									A045B104
				CA135								X	X	X	X			A045B104
KV13-2	KV63-2	80	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z194	A045P241	A045A626
				CA125				X	X									A045B104
				CA135								X	X	X	X			A045B104
KV14-2	KV64-2	90	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z193	A045P241	A045A626
				CA125				X	X									A045B104
				CA135								X	X	X	X			A045B104
KV15-2	KV65-2	100	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z192	A045P241	A045A626
				CA125				X	X									A045B104
				CA135								X	X	X	X			A045B104
KV16-2	KV66-2	125	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z191	A045P241	A045A626
				CA125				X	X									A045B104
				CA135								X	X	X	X			A045B104
KV17-2	KV67-2	150	H-Frame, Thermal Magnetic	CA115		X	X	X	X	X	X	X	X	X		A044Z190	A045P241	A045A626
				CA125				X	X									A045B104
				CA135								X	X	X	X			A045B104
KV18-2	KV68-2	175	H-Frame, Thermal Magnetic	CA115			X	X	X	X	X	X	X	X		A044Z184	A045P245	A045A626
				CA125				X	X									A045B104
				CA135								X	X	X	X			A045B104
KV19-2	KV69-2	200	H-Frame, Thermal Magnetic	CA115				X	X		X	X	X	X		A044Z183	A045P245	A045A626
				CA125				X	X									A045B104
				CA135								X	X	X	X			A045B104

SINGLE PHASE (continued)

														Accessories				
CIRCUIT BREAKER					CIRCUIT BREAKER SELECTION											1	2	3
Feature Code "A" POSITION	Feature Code "B" POSITION	Amps	Model	Alternator Model	C22N6	C25N6	C30N6	C36N6	C40N6	C30N6H	C36N6H	C40N6H	C45N6H	C50N6H	C60N6H	CIRCUIT BREAKER	Hardware Kit	"B" Position LEADS Kit
KV20-2	KV70-2	225	H-Frame, Thermal Magnetic	CA115					X			X	X	X		A044Z182	A045P245	A045A626
				CA125					X									A045B104
				CA135							X	X	X	X	A045B104			
KV21-2	KV71-2	250	H-Frame, Thermal Magnetic	CA115									X	X		A044Z045	A045P245	A045A626
				CA125														A045B104
				CA135							X	X	X	X	A045B104			
KV47-2	Not Offered	250	J-Frame, Electronic , LSI, 100%	CA135										X	X	A044Z217	A045P249	
Not Offered	KX27-2	250	J-Frame, Electronic , LSI, 80%	CA135											X	A050P695	A045P249	A045B106
KX26-2	Not Offered	250	J-Frame, Electronic , LSI, 100%	CA135											X	A050P695	A045P249	

THREE PHASE

															Accessories			
CIRCUIT BREAKER					CIRCUIT BREAKER SELECTION											1	2	3
Feature Code "A" POSITION	Feature Code "B" POSITION	Amps	Model	Alternator Model	C22N6	C25N6	C30N6	C36N6	C40N6	C30N6H	C36N6H	C40N6H	C45N6H	C50N6H	C60N6H	CIRCUIT BREAKER	Hardware Kit	"B" Position LEADS Kit
KV30-2	KV80-2	15	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z215	A045P245	A045B102
				CA125				X	X									A045B106
				CA135							X	X	X	X				A045B106
KV31-2	KV81-2	20	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z214	A045P245	A045B102
				CA125				X	X									A045B106
				CA135							X	X	X	X				A045B106
KV32-2	KV82-2	25	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z216	A045P245	A045B102
				CA125				X	X									A045B106
				CA135							X	X	X	X				A045B106
KV33-2	KV83-2	30	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z213	A045P245	A045B102
				CA125				X	X									A045B106
				CA135							X	X	X	X				A045B106
KV34-2	KV84-2	40	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z212	A045P245	A045B102
				CA125				X	X									A045B106
				CA135							X	X	X	X				A045B106
KV35-2	KV85-2	50	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z211	A045P245	A045B102
				CA125				X	X									A045B106
				CA135							X	X	X	X				A045B106
KV36-2	KV86-2	60	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z210	A045P245	A045B102
				CA125				X	X									A045B106
				CA135							X	X	X	X				A045B106
KV37-2	KV87-2	70	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z209	A045P245	A045B102
				CA125				X	X									A045B106
				CA135							X	X	X	X				A045B106
KV38-2	KV88-2	80	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z207	A045P245	A045B102
				CA125				X	X									A045B106
				CA135							X	X	X	X				A045B106
KV39-2	KV89-2	90	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z206	A045P245	A045B102
				CA125				X	X									A045B106
				CA135							X	X	X	X				A045B106
KV40-2	KV90-2	100	H-Frame, Thermal Magnetic	CA115	X	X	X	X	X	X	X	X	X	X		A044Z208	A045P245	A045B102
				CA125				X	X									A045B106
				CA135							X	X	X	X				A045B106
KV41-2	KV91-2	125	H-Frame, Thermal Magnetic	CA115		X	X	X	X	X	X	X	X	X		A044Z205	A045P245	A045B102
				CA125				X	X				X	X	X			A045B106
				CA135								X	X	X	X			A045B106
KV43-2	KV93-2	175	H-Frame, Thermal Magnetic	CA115				X	X		X	X	X	X		A044Z189	A045P245	A045B102
				CA125				X	X									A045B106
				CA135							X	X	X	X				A045B106
KV44-2	KV94-2	200	H-Frame, Thermal Magnetic	CA115					X			X	X	X		A044Z187	A045P245	A045B102
				CA125					X									A045B106
				CA135								X	X	X	X			A045B106

THREE PHASE (continued)

														Accessories				
CIRCUIT BREAKER					CIRCUIT BREAKER SELECTION											1	2	3
Feature Code "A" POSITION	Feature Code "B" POSITION	Amps	Model	Alternator Model	C22N6	C25N6	C30N6	C36N6	C40N6	C30N6H	C36N6H	C40N6H	C45N6H	C50N6H	C60N6H	CIRCUIT BREAKER	Hardware Kit	"B" Position LEADS Kit
KV45-2	KV95-2	225	H-Frame, Thermal Magnetic	CA115									X	X		A048N320	A045P245	A045B102
															A045B106			
				CA135								X	X	X	A045B106			
KV46-2	KV96-2	250	H-Frame, Thermal Magnetic	CA115												A044Z185	A045P245	A045B102
				CA125											A045B106			
				CA135										X	A045B106			
KV47-2	Not Offered	250	J-Frame, Electronic , LSI, 100%	CA135											X	A044Z217	A045P249	
Not Offered	KX27-2	250	J-Frame, Electronic , LSI, 100%	CA135											X	A050P695	A045P249	A045B106
KX26-2	Not Offered	250	J-Frame, Electronic , LSI, 100%	CA135											X	A050P695	A045P249	

Model Reference Table #2

Product Name	Marketing Name	Model Number	Voltage	Phase	Circuit Breaker
RS50	C50N6	A054F630	120/240	1 phase	250
RS50	C50N6	A054F636	120/208	3 phase	225
RS50	C50N6	A054F647	277/480	3 phase	100
RS50	C50N6	A054F649	120/240	3 phase	200
RS60	C60N6	A054F666	120/240	1 phase	250 **
RS60	C60N6	A054F821	120/208	3 phase	250
RS60	C60N6	A054F833	277/480	3 phase	125
RS60	C60N6	A054F835	120/240	3 phase	225
RS80	C80N6	A054F838	120/240	1 phase	400 **
RS80	C80N6	A054F849	120/208	3 phase	400 *
RS80	C80N6	A054F852	277/480	3 phase	150
RS80	C80N6	A054F857	120/240	3 phase	250 **
RS100	C100N6	A054F867	120/240	1 phase	400 **
RS100	C100N6	A054F870	120/208	3 phase	400 **
RS100	C100N6	A054F873	277/480	3 phase	200
RS100	C100N6	A054F874	120/240	3 phase	400 *
RS125	C125N6	A058T799	120/240	1 phase	600 **
RS125	C125N6	A058T800	120/208	3 phase	600 *
RS125	C125N6	A058T801	277/480	3 phase	250
RS125	C125N6	A058T804	120/240	3 phase	400 **
RS150	C150N6	A058T805	120/240	1 phase	600 **
RS150	C150N6	A058T806	120/208	3 phase	600 **
RS150	C150N6	A058T809	277/480	3 phase	250 **
RS150	C150N6	A058T810	120/240	3 phase	600 *

* - Electronic, 80% rated

** - Electronic, 100% rated

Model Reference Table #3

(RS50, RS60, RS80, and RS100)

Feature Code "A" POSITION	Feature Code "B" POSITION	Feature Code "C" POSITION	Amps	Model	1 or 3 Phase Accessories CIRCUIT BREAKER Part Number	Location A		Location B		Location C	
						Hardware Kit	LEADS Kit	Hardware Kit	LEADS Kit	Hardware Kit	LEADS Kit
KV30-2	KV80-2	KX34-2	15	H-Frame, Thermal-Magnetic, 80%	A044Z215	A052W286	A052X211	A052W312	A052X193	A052X002	A052X187
KV31-2	KV81-2	KX35-2	20	H-Frame, Thermal-Magnetic, 80%	A044Z214	A052W286	A052X211	A052W312	A052X193	A052X002	A052X187
KV32-2	KV82-2	KX36-2	25	H-Frame, Thermal-Magnetic, 80%	A044Z216	A052W286	A052X211	A052W312	A052X193	A052X002	A052X187
KV33-2	KV83-2	KX37-2	30	H-Frame, Thermal-Magnetic, 80%	A044Z213	A052W286	A052X211	A052W312	A052X193	A052X002	A052X187
KV34-2	KV84-2	KX38-2	40	H-Frame, Thermal-Magnetic, 80%	A044Z212	A052W286	A052X211	A052W312	A052X193	A052X002	A052X187
KV35-2	KV85-2	KX39-2	50	H-Frame, Thermal-Magnetic, 80%	A044Z211	A052W286	A052X211	A052W312	A052X193	A052X002	A052X187
KV36-2	KV86-2	KX40-2	60	H-Frame, Thermal-Magnetic, 80%	A044Z210	A052W286	A052X211	A052W312	A052X193	A052X002	A052X187
KV37-2	KV87-2	KX41-2	70	H-Frame, Thermal-Magnetic, 80%	A044Z209	A052W286	A052X211	A052W312	A052X193	A052X002	A052X187
KV38-2	KV88-2	KX42-2	80	H-Frame, Thermal-Magnetic, 80%	A044Z207	A052W286	A052X211	A052W312	A052X193	A052X002	A052X187
KV39-2	KV89-2	KX43-2	90	H-Frame, Thermal-Magnetic, 80%	A044Z206	A052W286	A052X211	A052W312	A052X193	A052X002	A052X187
KV40-2	KV90-2	KX44-2	100	H-Frame, Thermal-Magnetic, 80%	A044Z208	A052W286	A052X211	A052W312	A052X193	A052X002	A052X187
KV41-2	KV91-2	KX45-2	125	H-Frame, Thermal-Magnetic, 80%	A044Z205	A052W288	A052X212	A052W314	A052X194	A052X004	A052X189
KV42-2	KV92-2	KX46-2	150	J-Frame, Thermal-Magnetic, 80%	A044Z204	A052W288	A052X212	A052W314	A052X194	A052X004	A052X189
KV43-2	KV93-2	KX47-2	175	J-Frame, Thermal-Magnetic, 80%	A044Z189	A052W288	A052X212	A052W314	A052X194	A052X004	A052X189
KV44-2	KV94-2	KX48-2	200	J-Frame, Thermal-Magnetic, 80%	A044Z187	A052W288	A052X212	A052W314	A052X194	A052X004	A052X189
KV45-2	KV95-2	KX49-2	225	J-Frame, Thermal-Magnetic, 80%	A044Z186	A052W288	A052X213	A052W314	A052X199	A052X004	A052X191

Model Reference Table #3 (continued)

(RS50, RS60, RS80, and RS100)

Feature Code "A" POSITION	Feature Code "B" POSITION	Feature Code "C" POSITION	Amps	Model	1 or 3 Phase Accessories CIRCUIT BREAKER Part Number	Location A		Location B		Location C	
						Hardware Kit	LEADS Kit	Hardware Kit	LEADS Kit	Hardware Kit	LEADS Kit
KV46-2	KV96-2	KX50-2	250	J-Frame, Thermal-Magnetic, 80%	A044Z185	A052W288	A052X213	A052W314	A052X199	A052X004	A052X191
KX26-2	KX28-2	KX29-2	250	J-Frame, Electronic LSI, 100%	A050P695	A052W289	A052X213	A052W315	A052X199	A052X005	A052X191
KX51-2	KX52-2	NOT OFFERED	400	L-Frame, Electronic LSI, 80%	A045U169	A052W291	A052X214	A052W317	A052X209	NOT OFFERED	NOT OFFERED
KX30-2	KX31-2	NOT OFFERED	400	L-Frame, Electronic LSI, 100%	A052T045	A052W290	A052X214	A052W316	A052X209	NOT OFFERED	NOT OFFERED
KX32-2	KX33-2	NOT OFFERED	600	L-Frame, Electronic LSI, 80%	A045U164	A052W291	A052X214	A052W317	A052X209	NOT OFFERED	NOT OFFERED

Model Reference Table #4 **(RS125 and RS150)**

Feature Code "A" POSITION	Feature Code "B" POSITION	Feature Code "C" POSITION	Amps	Model	1 or 3 Phase Accessories CIRCUIT BREAKER Part Number	Location A		Location B		Location C	
						Hardware Kit	LEADS Kit	Hardware Kit	LEADS Kit	Hardware Kit	LEADS Kit
KV30-2	KV80-2	KX34-2	15	H-Frame, Thermal-Magnetic, 80%	A044Z215	A057L942	A057M150	A057M879	A057M144	A057N249	A057M140
KV31-2	KV81-2	KX35-2	20	H-Frame, Thermal-Magnetic, 80%	A044Z214	A057L942	A057M150	A057M879	A057M144	A057N249	A057M140
KV32-2	KV82-2	KX36-2	25	H-Frame, Thermal-Magnetic, 80%	A044Z216	A057L942	A057M150	A057M879	A057M144	A057N249	A057M140
KV33-2	KV83-2	KX37-2	30	H-Frame, Thermal-Magnetic, 80%	A044Z213	A057L942	A057M150	A057M879	A057M144	A057N249	A057M140
KV34-2	KV84-2	KX38-2	40	H-Frame, Thermal-Magnetic, 80%	A044Z212	A057L942	A057M150	A057M879	A057M144	A057N249	A057M140
KV35-2	KV85-2	KX39-2	50	H-Frame, Thermal-Magnetic, 80%	A044Z211	A057L942	A057M150	A057M879	A057M144	A057N249	A057M140
KV36-2	KV86-2	KX40-2	60	H-Frame, Thermal-Magnetic, 80%	A044Z210	A057L942	A057M150	A057M879	A057M144	A057N249	A057M140
KV37-2	KV87-2	KX41-2	70	H-Frame, Thermal-Magnetic, 80%	A044Z209	A057L942	A057M150	A057M879	A057M144	A057N249	A057M140
KV38-2	KV88-2	KX42-2	80	H-Frame, Thermal-Magnetic, 80%	A044Z207	A057L942	A057M150	A057M879	A057M144	A057N249	A057M140
KV39-2	KV89-2	KX43-2	90	H-Frame, Thermal-Magnetic, 80%	A044Z206	A057L942	A057M150	A057M879	A057M144	A057N249	A057M140
KV40-2	KV90-2	KX44-2	100	H-Frame, Thermal-Magnetic, 80%	A044Z208	A057L942	A057M150	A057M879	A057M144	A057N249	A057M140
KV41-2	KV91-2	KX45-2	125	H-Frame, Thermal-Magnetic, 80%	A044Z205	A057L944	A057M151	A057M881	A057M145	A057N251	A057M142
KV42-2	KV92-2	KX46-2	150	J-Frame, Thermal-Magnetic, 80%	A044Z204	A057L944	A057M151	A057M881	A057M145	A057N251	A057M142
KV43-2	KV93-2	KX47-2	175	J-Frame, Thermal-Magnetic, 80%	A044Z189	A057L944	A057M151	A057M881	A057M145	A057N251	A057M142
KV44-2	KV94-2	KX48-2	200	J-Frame, Thermal-Magnetic, 80%	A044Z187	A057L944	A057M152	A057M882	A057M146	A057N251	A057M143
KV45-2	KV95-2	KX49-2	225	J-Frame, Thermal-Magnetic, 80%	A044Z186	A057L944	A057M152	A057M882	A057M146	A057N251	A057M143

Model Reference Table #4 (continued)

(RS125 and RS150)

Feature Code "A" POSITION	Feature Code "B" POSITION	Feature Code "C" POSITION	Amps	Model	1 or 3 Phase Accessories CIRCUIT BREAKER Part Number	Location A		Location B		Location C	
						Hardware Kit	LEADS Kit	Hardware Kit	LEADS Kit	Hardware Kit	LEADS Kit
KV46-2	KV96-2	KX50-2	250	J-Frame, Thermal-Magnetic, 80%	A044Z185	A057L944	A057M152	A057M882	A057M146	A057N251	A057M143
KX26-2	KX28-2	KX29-2	250	J-Frame, Electronic LSI, 100%	A050P695	A057L945	A057M152	A057M882	A057M146	A057N252	A057M143
KX51-2	KX52-2	NOT OFFERED	400	L-Frame, Electronic LSI, 80%	A045U169	A057L947	A057M153	A057M883	A057M147	NOT OFFERED	NOT OFFERED
KX30-2	KX31-2	NOT OFFERED	400	L-Frame, Electronic LSI, 100%	A052T045	A057L947	A057M154	A057M884	A057M148	NOT OFFERED	NOT OFFERED
KX32-2	KX33-2	NOT OFFERED	600	L-Frame, Electronic LSI, 80%	A045U164	A057L948	A057M154	A057M885	A057M148	NOT OFFERED	NOT OFFERED
KY06-2	KY07-2	NOT OFFERED	600	L-Frame, Electronic LSI, 100%	A045U164	A057L949	A057M154	A057M886	A057M148	NOT OFFERED	NOT OFFERED
KY08-2	KY09-2	NOT OFFERED	800	L-Frame, Electronic LSI, 80%	A054K393	A057L950	A057M155	A057M887	A057M149	NOT OFFERED	NOT OFFERED

Cold Weather Accessories

For cold climates, plan ahead to ensure the performance of your generator. The components shown in the chart below will work together to keep your generator running, even when the temperatures dip below 0°F.

Extreme Cold Weather Kits

Part Number	Compatibility	Kit Includes
A052B640	Extreme cold, naturally aspirated RS50	1500W Coolant heater, engine oil heater, CCV heaters, larger battery tray, larger starter, instruction sheets
A052B642	Extreme cold, turbo charged RS60, RS80, RS100	1500W Coolant heater, engine oil heater, CCV heaters, larger battery tray, larger starter, instruction sheets
A052V713	Extreme cold, naturally aspirated – CSA RS50	1500W Coolant heater, engine oil heater, CCV heaters, larger battery tray, larger starter, instruction sheets
A052V715	Extreme cold, turbo charged - CSA RS60, RS80, RS100	1500W Coolant heater, engine oil heater, CCV heaters, larger battery tray, larger starter, instruction sheets
A054B984	Extreme cold, naturally aspirated RS13A, RS17A, RS20A	Engine oil heater, battery heater, instruction sheets


Extreme Cold Weather Kits are standard on the following models:

RS22, RS25, RS30, RS36, RS40
RX30, RX36, RX40, RX45, RX50, RX60
RS125, RS150

Exciter/Voltage Regulator Kits


Excitation Boost System – EBS Kit

A single self-contained unit installed to the non-drive end of the generator to feed additional power to the generator excitation system whenever the generator is subjected to a large impact load, such as motor starting. The added power supports the load power until the breaker discrimination can enable the generator to pick up a motor and drive the voltage recovery.



Permanent Magnet Generator – PMG Kits

The PMG is a separate Permanent Magnet Generator installed on the end of the main generator's shaft, providing an isolated power source for the voltage regulator, so that the excitation circuit is not affected by the load on the generator. PMG is recommended for enhanced motor starting capability and performance with non-linear load conditions.



Part Number	Compatibility	Kit Includes
A049F140	Generators using the CA115 alternator for Feature code B979-2. See "Connect Series Preconfigured Model Reference Table" in the Circuit Breaker section for model listing compatibility	Excitation Boost kit, Alternating current harness, Cable ties, and instruction sheet
A049S000	Generators using CA125 or CA135 alternators for feature code B184-2. See "Connect Series Preconfigured Model Reference Table" in the Circuit Breaker section for model listing compatibility	Permanent Magnet Generator kit, receptacle housing, cable ties, and instruction sheet
A052U030	RS50, RS60, RS80, RS100 RS125, RS150	Permanent Magnet Generator kit, receptacle housing, cable ties, and instruction sheet

Load Management

Load Management Kit

This kit allows the generator to control up to two, 50A loads. Full details are described in the Operators manual under 'Load Management'. Kit can be flush or surface mounted.

Part Number	Compatibility	Kit Includes
A051C329	RS13A, RS17A, RS20A	Enclosure, relays, and instruction sheet

Maintenance

Completing a scheduled maintenance program for your generator will ensure that it remains in good operating conditions, and that you meet warranty requirements. Recommended maintenance intervals are shown in the generator Operator Manual, for your reference.

Paints (Touch-Up)

Brush-in-cap bottle helps to cover minor scratches and keep your generator looking good throughout its lifetime.

Part Number	Compatibility
A043J735 (Sandstone)	RS22, RS25, RS30, RS36, RS40, RS50, RS60, RS80, RS100 RX30, RX36, RX40, RX45, RX50, RX60
	RS13A, RS17A, RS20A
A043J319 (Green)	RS125, RS150

Preventative Maintenance Kits

Part Number	Compatibility	Kit Includes
A046N983	RS30, RS36, RS40	1 Oil filter and 1 heavy duty air filter
A046N985	RS22, RS25, RS30 RX30	1 Oil filter and 1 heavy duty air filter
A046N987	RS36, RS40 RX36, RX40, RX45, RX50, RX60	1 Oil filter and 1 heavy duty air filter
A054H068	RS13A, RS17A, RS20A	1 Oil filter, 1 air filter, and 2 valve cover gaskets



A046N983



A046N985



A046N987

Remote Displays

Remote Displays

Surface mount HMI that allows remote monitoring/control functionality for Connect Series generators from a remote location. Provides ability to monitor generator functions, review basic diagnostic status, and set user preferences. Surface-mountable design for easy installation.

Part Number	Compatibility
A053K028	RS13A, RS17A, RS20A
A046K103 *	RS22, RS25, RS30, RS36, RS40 RX30, RX36, RX40, RX45, RX50, RX60 RS50, RS60, RS80, RS100

* - Only with generators equipped with PCC1.1 controllers




A053K028

Remote Bargraph Display

The bargraph display that can be mounted remote to display individual LED bars for AC amps and voltage for each phase, Frequency, Power (kVA), etc.

Part Number	Compatibility
A045J203	RS22, RS25, RS30, RS36, RS40, RS50, RS60, RS80, RS100 RX30, RX36, RX40, RX45, RX50, RX60
A029T102	RS125, RS150



A045J203



A029T102

Remote Unit HMI 220 / 320

The Human Machine Interface 220/320 Remote Panel is our robust multi-line display unit, which can be used to monitor and display dynamic generator set performance information, as well as perform basic generator set control and configuration on a medium or large size display respectively.

Part Number	Description	Compatibility
A041J582	HMI220	RS50, RS60, RS80, RS100 RS125, RS150
A041J589	HMI320	

* - Only with generators equipped with PCC2.3 controllers



A045J582



A045J58

Safety

Alarm Installation, Audible, Engine Shutdown

When engine shuts down, an audible alarm is given.

Part Number	Compatibility
A043F059	RS22, RS25, RS30, RS36, RS40, RS50, RS60, RS80, RS100 RX30, RX36, RX40, RX45, RX50, RX60 RS125, RS150

Emergency Stop Switch

Pressing the Emergency Stop control switch will cause the generator set to immediately shut down. The generator set is prevented from running or cranking with the switch pressed in.



Part Number	Compatibility
A044Z051	RS22, RS25, RS30, RS36, RS40, RS50, RS60, RS80, RS100 RX30, RX36, RX40, RX45, RX50, RX60 RS125, RS150
	RS13A, RS17A, RS20A

Low Coolant Level Kit (A052U651)

Sensors send signals to the controller that the coolant level is low. The controller can be programmed for warning or shutdown.

Part Number	Compatibility
A052U651	RS22, RS25, RS30, RS36, RS40, RS50, RS60, RS80, RS100 RX30, RX36, RX40, RX45, RX50, RX60 RS125, RS150

Oil Makeup System Kits

This kit includes a 4 quarts (3.8 litres) reservoir and regulator/sight gage. It gives protection against possible engine damage from running with low oil levels. The controller can then shutdown the generator once the reservoir is empty and the oil level in the engine drops to a certain level.


Part Number	Compatibility
A052Z182	RS22, RS25 RX30
A052Y142	RS30, RS36, RS40 RX36, RX40, RX45, RX50, RX60

Flexible Fuel Hose

This line is installed between the main fuel supply and the generator set, to protect the generator against damage caused by vibration, expansion, and contraction.

Part Number	Thread Size	Length	Compatibility
0501-0776-02	3/4"	24"	RS22, RS25, RS30, RS36, RS40, RS50, RS60, RS80, RS100 RX30, RX36, RX40, RX45, RX50
0501-0776-03	1"	27"	RX60
0501-0776-04	1 - 1/4"	31.5"	RS125, RS150

* - This hose comes with all generators except RS125 and RS150



Sound

Base Barrier – Elevated Generator

Used on roof installed Connect Series to provide a sheet metal barrier between generator and roof.

Part Number	Compatibility	Kit Includes
A046J607	RS30, RS36, RS40 RX36, RX40, RX45, RX50, RX60	Cover plates, support members, hardware, instruction sheet
A046J612	RS22, RS25 RX30	Cover plates, support members, hardware, instruction sheet
A052U603	RS50, RS60, RS80, RS100	Cover plates, support members, hardware, instruction sheet
A056H773	RS125, RS150	Cover plates, support members, hardware, instruction sheet

Sound Kits


These kits will provide additional enhanced sound attenuation beyond stock enclosure. An insulated duct bolts to the inlet end of the generator and will match generator in color.

Part Number	Compatibility
A043J733 (Sandstone)	RS22, RS25, RS30, RS36, RS40 RX30, RX36, RX40, RX45, RX50, RX60
A052V798 (Sandstone)	RS50, RS60, RS80, RS100
A056H766 (Green)	RS125, RS150



Mounting Pads

Pre-cast concrete composite pad that is 3 inches thick and a 1-inch overhang around generator. Pad comes with mounting hardware for securing the generator.




Part Number	Pads per pack	Compatibility
A052A795	1	RS13A, RS17A, RS20A, RS20AC
A057M349	5	
A057M351	10	

Display Tilting Kits

This kit can be used to tilt the operator panel on the products listed below. The panel can be tilted up or down depending on your application for easier reading.

Part Number	Compatibility
A060K859	RS22, RS25, RS30, RS36, RS40 RX30, RX36, RX40, RX45, RX50, RX60 RS50, RS60, RS80, RS100



**For more information contact your local Cummins distributor or
visit power.cummins.com**

Our energy working for you.™



All rights reserved. Cummins is a registered trademark of Cummins Inc. PowerCommand, AmpSentry, InPower and "Our energy working for you." are trademarks of Cummins Inc. Other company, product, or service names may be trademarks or service marks of others. Specifications are subject to change without notice.

Bulletin 5544098 (NAAC-6260-EN) (A056T959) Rev. 10/19
©2019 Cummins Inc.