

CFP15E SERIES

Operation & Maintenance Manual Fire Pump Drive Engines






Table of Contents

Warranty Information

Section 1 - Safety

1.1 Introduction	1-1
1.2 Advisory and Cautionary Statements	1-1
1.3 Safety Precautions	1-1

Section 2 - Description

2.1 Introduction	2-1
2.2 Fire Pump Engines	2-1
2.3 Operator Control Panel	2-3
2.3.1 Overspeed Switch	2-4
2.3.2 Operating Speed	2-4
2.4 Fire Pump Controller	2-4
2.5 Air Intake System	2-4
2.6 Raw Water Cooling System	2-5
2.7 Fuel Cooling System	2-7
2.7.1 Fuel Supply and Drain Location	2-7
2.8 High Pressure Injector (HPI) Fuel System	2-7
2.9 Engine Oil System	2-9
2.10 Exhaust System	2-9

Section 3 - Installation

3.1 Receiving and Handling Information	3-1
3.1.1 Damage During Shipping	3-1
3.1.2 Claim Filing Procedure	3-1
3.2 Site Preparation	3-1
3.2.1 Site Considerations	3-1
3.3 Fuel Supply Installation	3-3
3.3.1 Fuel System Preparation	3-3
3.3.2 Fuel Recommendations	3-4
3.4 Raw Water Supply Installation	3-4
3.4.1 Install Raw Water Piping	3-4
3.5 Battery Selection	3-5
3.5.1 Battery Requirements	3-5
3.5.2 Battery Installation	3-6
3.5.3 Auxiliary Battery Starting	3-6
3.6 Signal and Control Installation	3-6
3.7 Coolant System Preparation	3-8
3.8 Charge Air Cooler System	3-9
3.9 Lubricating Oil System Preparation	3-10
3.10 Pre-Start Inspections	3-11
3.11 Engine Start Test	3-11
3.11.1 Engine Will Not Start	3-13
3.11.2 Engine Starts	3-13

Table of Contents

Section 4 - Controls

4.1	Operator Control Panel	4-1
4.1.1	Coolant Temperature Gauge	4-1
4.1.2	Lubrication Oil Pressure Gauge	4-1
4.1.3	Tachometer and Hour Meter	4-2
4.1.4	Battery A and B Voltmeters	4-2
4.1.5	Circuit Breaker Switches	4-2
4.1.6	AUTO/MANUAL Mode Switch	4-2
4.1.7	Overspeed Warning Lamp	4-2
4.1.8	Engine Overspeed Warning Lamp	4-3
4.1.9	Overspeed RESET/STOP Switch	4-3
4.1.10	High Coolant Temperature Warning Lamp	4-3
4.1.11	Low Oil Pressure Warning Lamp	4-3
4.1.12	CRANK BATT A/B Switch	4-4
4.1.13	ECM Fault Code Lamps	4-4
4.1.14	ECM A/B Indicator Lamps	4-4
4.2	Electronic Control Module (ECM)	4-4
4.2.1	ECM Data Plate	4-4
4.3	Overspeed Switch	4-5
4.4	Raw Water Flow Control Valves	4-6
4.5	Engine Protection System	4-6
4.5.1	Engine Protection Fault	4-6

Section 5 - Operation

5.1	Start-up Procedures	5-1
5.2	General Operating Information	5-1
5.3	Remote Starting Procedure	5-1
5.4	Local Starting Procedure	5-2
5.5	Emergency Starting Procedure	5-2
5.6	Engine Operating Speed	5-3
5.7	Overspeed Set Point	5-3
5.8	Crank Terminate Set Point	5-3
5.9	ECM Fault Code Lamps	5-3
5.10	Isolated Acceptance Testing	5-5
5.10.1	Integrated Acceptance Testing	5-5

Section 6 - Maintenance

6.1	Introduction	6-1
6.2	Engine Operation Report	6-1
6.3	Weekly Maintenance	6-4
6.3.1	General Walk Around Inspection	6-4
6.3.2	Air Filter and Piping	6-4
6.3.3	Cooling System	6-4
6.3.4	Engine Oil System	6-5
6.3.5	Fuel System Inspections	6-6
6.3.6	Engine Exhaust System	6-7
6.3.7	Electrical Supply and Controls	6-7
6.3.8	Crankcase Breather Tube	6-7
6.3.9	Clean Raw Water Strainers	6-7
6.3.10	Check Battery Condition	6-7
6.3.11	Engine Test Run	6-8
6.3.12	Engine Coolant Heater	6-9

Table of Contents

6.3.13 Check Antifreeze	6-9
6.3.14 Air Cleaner Service Indicator	6-10
6.4 Annual Maintenance	6-10
6.4.1 Electrical Components	6-10
6.4.2 Turbocharger Mounting Nuts	6-11
6.4.3 Engine Mounting Bolts	6-11
6.4.4 Inspect Fuel Pump	6-11
6.4.5 Engine Oil and Oil Filter Change	6-12
6.4.6 Change Fuel Filter or Filter Separator	6-13
6.4.7 Output Shaft Lubrication	6-14
6.4.8 Engine Operation Checks	6-15
6.4.8.1 Crank Termination Set Point	6-15
6.4.8.2 Engine Speed Calibration	6-15
6.4.8.3 Overspeed Set Point Adjustment	6-16
6.4.9 Coolant Pump Belt Inspection	6-17
6.4.10 Coolant Pump Belt Tension	6-17
6.4.11 Alternator Belt Inspection	6-18
6.4.12 Alternator Belt Tension	6-18
6.4.13 Heat Exchanger Pressure Test	6-19
6.4.14 Turbocharger Inspection	6-19
6.5 Every 2 Years or 2000 Hours	6-20
6.5.1 Coolant Pump Inspection	6-20
6.5.2 Drain and Flush Cooling System	6-20
6.6 Every 4 Years or 5000 Hours	6-22
6.6.1 Coolant Thermostat Removal/Installation	6-23
6.6.2 Coolant Pump Belt Replacement	6-23
6.6.3 Alternator Belt Replacement	6-24
6.6.4 Charge Air Cooler Heat Exchanger	6-25

Section 7 - Troubleshooting

7.1 Troubleshooting	7-1
7.1.1 Alternator Overcharging with the Engine Running	7-8
7.1.2 Neither Battery is Charging with the Engine Running	7-8
7.1.3 Only One Battery is Charging with the Engine Running	7-9
7.1.4 Voltage Indications Differ	7-9
7.1.5 Coolant Contamination	7-10
7.1.6 Excessive Coolant Loss	7-11
7.1.7 Coolant Temperature Above Normal	7-12
7.1.8 Coolant Temperature Below Normal	7-13
7.1.9 Raw Water Drain Steaming	7-14
7.1.10 Raw Water Solenoid Valve fails to Operate	7-14
7.1.11 Auto Start failure - Does not Crank on BATT A or B	7-15
7.1.12 Auto Start failure - Cranks but does not Start	7-15
7.1.13 Auto Start failure - Engine Starts but Crank Terminate Does Not Occur	7-16
7.1.14 Manual Start Failure from Solenoid Lever - Does not Crank on A or B	7-17
7.1.15 Manual Start Failure from Control Panel - Does not Crank on A or B	7-17
7.1.16 Engine Cranks Normally But Will Not Start (No Exhaust Smoke)	7-18
7.1.17 Engine Cranks Slowly But Does Not Start	7-19
7.1.18 Engine Stops During Operation	7-20
7.1.19 Engine Will Not Reach Rated Speed (RPM)	7-21
7.1.20 Engine Will Not Shut Off Remotely	7-22
7.1.21 Engine Will Not Shut Off Locally	7-23
7.1.22 Fuel Consumption is Excessive	7-23

7.1.23	Fuel or Engine Oil Leaking From Exhaust Manifold	7-24
7.1.24	Engine Oil is Contaminated.	7-24
7.1.25	Engine Oil Consumption is Excessive.	7-25
7.1.26	Lubrication Oil in the Coolant	7-26
7.1.27	Engine Overspeed Trip	7-26
7.1.28	Tachometer Does not Indicate Engine Speed.	7-27

8.1 Part Ordering Information	8-1
8.2 Routine Service and Parts	8-1
8.3 Emergency Repairs and Technical Service	8-1
8.4 Recommended Spares Inventory	8-1

TOC-iv

List of Figures

Figure 2-1	Heat Exchanger Tanks	2-1
Figure 2-2	Raw Water Cooling Loop Manifold	2-1
Figure 2-3	Engine Components - Instrument Panel Side	2-2
Figure 2-4	Engine Components - Turbocharger Side	2-3
Figure 2-5	Engine Overspeed Control Module	2-4
Figure 2-6	Turbocharger and Exhaust Manifold	2-4
Figure 2-7	Engine Air Intake and Charge Air Cooling Flow Diagram	2-5
Figure 2-8	Engine Cooling System Flow Diagram	2-6
Figure 2-9	Fuel System Components	2-8
Figure 2-10	Flow Diagram - Engine Lubricating Oil System (typical)	2-9
Figure 2-11	Flow Diagram - Exhaust System (typical)	2-10
Figure 2-12	Turbocharger Exhaust Flow Diagram (typical)	2-10
Figure 3-1	Engine Lifting Lugs (Engine Only)	3-2
Figure 3-2	Drive Coupling Alignment	3-2
Figure 3-3	Drive Coupling Grease Fittings	3-2
Figure 3-4	Fuel Line Inlet and Outlet Hoses	3-3
Figure 3-5	Engine Fuel Filter	3-3
Figure 3-6	Raw Water Cooling Loop Manifold	3-4
Figure 3-7	Cooling Loop Heat Exchangers	3-5
Figure 3-8	Series Battery Connection - 24 VDC	3-6
Figure 3-9	Termination Blocks and Wiring Decal	3-7
Figure 3-10	Upper Cooling Hose Clamps	3-8
Figure 3-11	Coolant Circulation System	3-9
Figure 3-12	Engine Coolant Expansion Tank	3-9
Figure 3-13	Charge Air Cooler Tubing	3-9
Figure 3-14	Turbocharger and Charge Air Cooler (CAC) Piping	3-10
Figure 3-15	Oil Level Dipstick & Oil Fill Port	3-10
Figure 3-16	Turbocharger Oil Line Location	3-10
Figure 3-17	Turbocharger Turbine Wheel (typical)	3-11
Figure 3-18	Operator Control Panel - Instruments	3-12
Figure 3-19	Operator Control Panel - Controls	3-12
Figure 3-20	Manual Starter Contactors	3-12
Figure 4-1	Operator Control Panel - Instruments	4-1
Figure 4-2	Operator Control Panel - Controls	4-2
Figure 4-3	Engine Settings Plates	4-3
Figure 4-4	ECM Selector Panel and Switch	4-4
Figure 4-5	Electronic Control Modules (ECMs)	4-5
Figure 4-6	Engine Overspeed Control Module	4-5
Figure 4-7	Raw Water Flow Control Valves	4-6
Figure 5-1	Operator Control Panel Switches	5-1
Figure 5-2	ECM Selector Panel and Switch	5-2
Figure 5-3	Manual Starter Contactors	5-3
Figure 5-4	ECM Diagnostic Reader Plug-ins	5-4
Figure 5-5	Control Panel Indicator Lamps	5-4
Figure 5-6	Engine Speed Control Panel	5-5

Table of Contents

Figure 6-1	Air Filter	6-4
Figure 6-2	Heat Exchanger Tanks	6-5
Figure 6-3	Engine Oil Dipstick	6-6
Figure 6-4	Engine Fuel Filter/Water Separator	6-6
Figure 6-5	Raw Water Strainers	6-7
Figure 6-6	24 VDC Series Battery Connection	6-8
Figure 6-7	Engine Heater	6-9
Figure 6-8	Air Cleaner Service Indicator	6-10
Figure 6-9	Electrical Control Modules	6-10
Figure 6-10	Turbocharger	6-11
Figure 6-11	Engine Mounting Bracket	6-11
Figure 6-12	Fuel Pumps, Filter, Lines and Hoses	6-12
Figure 6-13	Oil Pan Drain Plug (right side shown)	6-12
Figure 6-14	Oil Filter Canister	6-13
Figure 6-15	Oil Fill Port and Oil Level Dipstick	6-13
Figure 6-16	Engine Fuel Filter or Filter/Separator	6-14
Figure 6-17	Drive Coupling Grease Fittings	6-14
Figure 6-18	Engine Overspeed Control Module	6-15
Figure 6-19	Coolant Pump Drive Belt	6-17
Figure 6-20	Alternator Drive Belt	6-18
Figure 6-21	Turbocharger Connections	6-20
Figure 6-22	Turbocharger Turbine Wheel	6-20
Figure 6-23	Engine Coolant Drains	6-21
Figure 6-24	Filter Housing Gasket Mount	6-21
Figure 6-25	Thermostat Housing	6-23
Figure 6-26	Coolant Pump Drive Belt	6-24
Figure 6-27	Alternator Drive Belt	6-25
Figure 6-28	Charge Air Cooler (CAC) Heat Exchanger	6-26



This manual contains proprietary information to equipment produced by Cummins Fire Power or Cummins, Inc. and is being supplied solely for the purpose of operating, maintaining and servicing the fire pump engine purchased from Cummins Fire Power.

© Copyright 2009, Cummins, Inc.

Warranty Information

LIMITED WARRANTY

EXCLUSIVE EXPRESS LIMITED WARRANTY: Cummins Fire Power (CFP), division of Cummins NPower, LLC expressly warrants to the original end consumer only that, for a period not to exceed the earlier of two (2) years or 2000 hours of use from the start-up date (or, if the original end consumer fails to register as purchaser with CFP, six (6) months from CFP shipment date), the diesel fire pump drivers, manufactured and sold by CFP, shall be free from defects in material and workmanship when used and serviced in accordance with the Operations and Maintenance manual for the applicable Cummins Fire Pump engine model (the “Exclusive Warranty”). The Exclusive Warranty is nontransferable and shall immediately terminate and be of no further force or effect upon the sale, lease, assignment, transfer or other disposition by an original end consumer of a Cummins Fire Pump engine that contains a diesel fire pump driver covered by this Exclusive Warranty. Nothing contained herein shall be construed to extend the Exclusive Warranty, and the Exclusive Warranty shall not be extended, to:

- Maintenance, adjustment, installation or start-up costs;
- Diesel fire pump driver failure due to normal wear, accident, misuse, abuse, neglect, improper installation or a defect attributable to a Cummins Fire Pump engine;
- Alterations or modifications not authorized in writing by CFP;
- Additional components added to a diesel fire pump driver package subsequent to shipment of the engine; or
- Starting batteries
- Coolant heaters are covered for 12 months.

DISCLAIMER OF WARRANTIES: Except for the Exclusive Warranty provided above, which is in lieu of all other express and implied warranties, CFP EXPRESSLY DISCLAIMS ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

LIMITATION AND EXCLUSION OF REMEDIES: All claims under this Exclusive Warranty shall be deemed waived by the original end consumer if not submitted to CFP or an authorized distributor within thirty (30) days of initial discovery that a diesel fire pump driver is not conforming to the Express Warranty. The original end consumer’s remedy under this Exclusive Warranty is limited, in CFP’s reasonable discretion, to repair, replacement or other appropriate adjustment of a nonconforming diesel fire pump driver determined, upon CFP’s inspection, to have been properly installed, maintained and operated in accordance with the Operations and Maintenance manual furnished by CFP. **IN ANY EVENT, CFP SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.**

The Cummins Industrial Warranty covers the base engine for a period of time not to exceed the earlier of two (2) years or 2000 hours of operation from the date of delivery and start-up of the engine. Reference bulletin numbers 3381321 US/Canada & 3381322 Outside US/Canada. Cummins Fire Power components are warranted for a period of time not to exceed the earlier of two (2) years or 2000 hours of operation from the start-up date of the fire pump system, and the coverage includes travel time and mileage for the first year of the Limited Warranty, and repair or replacement of parts and reasonable cost of labor. The Cummins Fire Power Limited Warranty does not cover failures or damage due to abuse or neglect and including, but not limited to: shipping damage, improper storage, improper installation, unauthorized modification or lack of maintenance. Cummins Fire Power is not responsible for incidental or consequential damages.



Section 1 - Safety

1.1 Introduction

Cummin's Fire Power and Engine Manuals should be considered part of the equipment. Keep the manuals with the equipment. If the equipment is traded or sold, give the manuals to the new owner.

All personnel responsible for operation and maintenance of the equipment should read and thoroughly understand this manual.

1.2 Advisory and Cautionary Statements

Advisory and Cautionary Statements are used throughout this manual to call attention to special information, correct operating procedures and to safety precautions.

NOTE: *A general advisory statement relating to equipment operation and maintenance procedures*

IMPORTANT: *A specific advisory statement intended to prevent damage to the equipment or associated components.*

Cautionary Statements consist of two levels:



WARNING

Indicates the presence of a hazard which CAN cause severe personal injury.



CAUTION

Indicates the presence of a hazard which CAN cause personal injury, or cause equipment damage.

1.3 Safety Precautions

Warning: Read and understand all of the safety precautions and warnings before performing any repair. This manual contains the general safety precautions that must be followed to provide personal safety. When they apply, special safety precautions are included with operating procedures.

Warning: Perform a walk around inspection and alert all area personnel that the equipment will be starting before manual operation.

Warning: Do not operate faulty or damaged equipment. Ensure that all hoses, pipe connections, clamps and guards are in place and securely fastened. Electrical components should be kept in good working condition and repaired immediately by qualified personnel.

Warning: After performing maintenance, remove all tools and foreign materials, reinstall and securely fasten ALL guards, covers and protective devices.

Warning: Exposed in-running belt nips can cause severe personal injury or dismemberment. Ensure that guards are in place and securely fastened before operation.

Warning: Rotating drive shafts can lacerate, dismember or cause strangulation. Keep hands, body parts, long hair, or loose-fitting clothing clear at all times.

Warning: Never attempt to manually clean a machine while it is operating or in standby mode.

Warning: Never open ports on tanks or piping while the engine is operating. Contact with pressurized agents can cause severe personal injury.

Warning: Relieve all pressure in the air, oil, and the cooling systems before any lines, fittings, or related items are removed or disconnected.

Caution: Engine fuel is flammable when in contact with electrical spark or flame sources. Remove all sources of spark or flame from the work area.

Caution: Always use the same fastener part number (or equivalent) when replacing fasteners.

Caution: Some state and federal agencies in the USA have determined that used engine oil can be carcinogenic and can cause reproductive toxicity. Dispose of waste oil in accordance with applicable requirements.




Section 2 - Description

2.1 Introduction

This manual contains information for the correct operation and maintenance of a Cummins Fire Pump Engine. Read and follow all safety instructions. Refer to the General Safety Instructions in [Section 1 - Safety](#).

Keep this manual with the equipment. If the equipment is traded or sold, give the manual to the new owner.

Cummins Fire Power, Cummins NPower and Cummins, Inc. reserve the right to make changes at any time without obligation. If any differences are found between an engine and the information in this manual, contact the local Cummins Authorized Repair Location.




1. Coolant Expansion Tank
2. Coolant Fill Cap
3. Expansion Tank Level Sight Gauge
4. Charge Air Cooler (CAC) Heat Exchanger
5. Coolant/Fuel Heat Exchanger
6. Heat Exchanger Discharge

Figure 2-1 Heat Exchanger Tanks

The latest technology and the highest quality components were used to produce this engine. When replacement parts are needed, we recommend using only genuine Cummins or ReCon® exchange parts.


2.2 Fire Pump Engines

Cummins complete line of fire pump engines have been approved as packaged units (engine and all accessories) by Factory Mutual Approvals and listed by Underwriter's Laboratories, Inc. and Underwriter's Laboratories of Canada.



1. Bypass Water Outlet Valve
2. Bypass Pressure Regulator/Strainer
3. Bypass Water Inlet Valve
4. 1-1/4" NPT Raw Water Inlet
5. Normal Water Inlet Valve
6. Normal Pressure Regulator/Strainer
7. Normal Water Solenoid Valve
8. Normal Water Outlet Valve
9. Raw Water Drain Plug
10. Pipe To Heat Exchanger
11. Pressure Gauge Isolation Valve
12. Water Supply Pressure Gauge


Figure 2-2 Raw Water Cooling Loop Manifold



CFP-072

- | | |
|--|--|
| 1. Coolant Pressure/Fill Cap | 14. Fuel Lift Pump |
| 2. Charge Air Cooler Pipe | 15. Fuel Supply Line |
| 3. Electronic Control Modules (ECMs) | 16. Engine Breather Hose |
| 4. Exhaust Flex Connection | 17. Fuel Filter |
| 5. Terminal Box (customer connection inside) | 18. Fuel Return Line |
| 6. Manual Start Instruction Decal | 19. 1-1/4" NPT Raw Water Inlet |
| 7. Engine Speed Settings Plate | 20. Oil Level Dip Stick |
| 8. Air Cleaner | 21. Operator's Control Panel |
| 9. A/B Battery Starter Contactors | 22. Oil Fill Port |
| 10. Flywheel Housing | 23. Coolant/Fuel Heat Exchanger |
| 11. Engine Supports | 24. Charge Air Cooler (CAC) Heat Exchanger |
| 12. Oil Pan Drain | 25. Coolant Expansion Tank |
| 13. ECM Selector Panel and Switch | |

Figure 2-3 Engine Components - Instrument Panel Side



CFP-073

- | | |
|---|-----------------------------------|
| 1. Air Cleaner Assembly | 10. Raw Water Manifold |
| 2. Manifold Heat Shield | 11. 1-1/2" NPT Raw Water Outlet |
| 3. Exhaust Flex Connection | 12. Coolant Pump |
| 4. Upper Coolant Hose | 13. Coolant Filter |
| 5. Coolant Pressure/Fill Cap | 14. Lower Coolant Hose |
| 6. Expansion Tank Level Sight Gauge | 15. Alternator (under belt guard) |
| 7. Coolant Expansion Tank | 16. Engine Oil Filter |
| 8. Charge Air Cooler (CAC) Heat Exchanger | 17. Starter Motor |
| 9. Coolant/Fuel Heat Exchanger | 18. Engine Heater |

Figure 2-4 Engine Components - Turbocharger Side

Models CFP15E-F10 through F40 meet Tier 3 emission levels, while models CFP15E-F50 through F70 meet Tier 2 emission levels. This turbocharged engine requires charge air cooling (CAC) and fuel cooling.

No deviations are permitted without prior written approval. These engines are to be used only for fire protection applications. Refer to [Figure 2-1](#), [Figure 2-2](#), [Figure 2-3](#) and [Figure 2-4](#).

2.3 Operator Control Panel

The engine control panel is mounted on the flywheel end on the left (fuel pump) side of the engine. Refer to [Section 4 - Controls](#) for additional information.


The operator control panel contains controls for starting, monitoring engine performance and controlling fire pump engine operation.

2.3.1 Overspeed Switch

Each engine is equipped with an electronic overspeed module which activates the fuel pump solenoid valve and ECM ignition to shut off the engine when the RPM exceeds a preset limit. The overspeed switch senses engine speed during the start cycle and stops the starter motor cranking cycle. Refer to [Figure 2-5](#).

2.3.2 Operating Speed

All Cummins fire pump engines are shipped from the factory adjusted to the requested operating speed (RPM). Final operating speed adjustment must be made during the in-service inspection to obtain the required operating speed specified by the pump manufacturer.



1. Spring Clamp Terminal Blocks
2. Speed Increase/Decrease Toggle Switch
3. RESET Button
4. TEST Button
5. Diagnostic ON/OFF Toggle Switch
6. CRANK Termination or Run Signal Indicator LED (factory use only)
7. Overspeed Indicator LED
8. Pre-wired Terminals
9. Crank Terminate Potentiometer Cover
10. Overspeed Potentiometer Cover

Figure 2-5 Engine Overspeed Control Module

2.4 Fire Pump Controller


Fire pump controller is not supplied by Cummins Fire Power, or Cummins, Inc. The fire pump controller starts the engine automatically when a remote fire demand signal is initiated and automatically shuts down the engine when the fire demand signal is discontinued.

The engine may be started locally in the MANUAL Mode and shut down using the operator control panel AUTO/MANUAL Mode Switch by returning the switch to automatic mode.

NOTE: Pressure recorders are available to provide a permanent record of water pressure fluctuations and engine starts. Sequential starting is available for multiple-pump installations to prevent all pumps from starting simultaneously.


2.5 Air Intake System

The Air Intake System supplies combustion air to the fire pump engine cylinders. The air filter prevents particulate matter from entering the air intake. Combustion air drawn into the system by the turbocharger is directed through the charge air cooler (CAC) heat exchanger for cooling before entering the intake manifold where the charge air is mixed with fuel. Refer to [Figure 2-6](#) and [Figure 2-7](#).



1. Turbocharger
2. Exhaust Manifold
3. Turbo Connection to Charge Air Cooler
4. Exhaust Flex Connection

Figure 2-6 Turbocharger and Exhaust Manifold



CFP-062


- | | |
|---|---|
| 1. Filtered Intake Air from Air Cleaner | 4. Charge Air Cooler (CAC) Heat Exchanger |
| 2. Turbocharger | 5. Charge Air Cooler Pipe |
| 3. Air Hose To Charge Air Cooler | 6. Combustion Air Intake Manifold |

Figure 2-7 Engine Air Intake and Charge Air Cooling Flow Diagram

2.6 Raw Water Cooling System

The fire pump raw water supply provides cooling water for the engine heat exchanger system. A water-to-air Charge-Air-Cooler (CAC) Heat Exchanger reduces the combustion air temperature at the intake

manifold. A low charge air temperature (requirement of 60° C (140° F) (with 25° C (77° F) ambient) meets emission levels while improving engine performance and efficiency.



CFP-063

- | | |
|---|------------------------------------|
| 1. Coolant Fill Cap | 11. Raw Water Inlet Pipe |
| 2. Coolant Expansion Tank | 12. Coolant Pump |
| 3. Charge Air Cooler (CAC) Heat Exchanger | 13. Coolant Filter |
| 4. Coolant/Fuel Heat Exchanger | 14. 85° C (180° F) Thermostat |
| 5. Raw Water Drain Line | 15. Engine Block |
| 6. Raw Water Pressure Gauge | 16. Combustion Air Intake Manifold |
| 7. Manual Shut-off Valve | 17. Air Filter |
| 8. Raw Water Solenoid Valve | 18. Turbocharger |
| 9. Raw Water Pressure Regulator/Strainer | 19. Exhaust Flex Connection |
| 10. Bypass Piping | 20. Exhaust Manifold |

Figure 2-8 Engine Cooling System Flow Diagram

Water entering the cooling system through the 1-1/4" NPT raw water inlet, first circulates through the charge air cooler (CAC) heat exchanger, cooling the compressed air from the turbocharger outlet ducting. The cooled combustion air exits the CAC outlet duct to the engine air intake manifold. Refer to [Figure 2-1](#), [Figure 2-2](#) and [Figure 2-7](#).

NOTE: *The raw water supply must be immediately available when the engine is started.*

The raw water from the CAC heat exchanger then enters the Coolant/Fuel Heat Exchanger. The raw water exits the Coolant/Fuel Cooler Heat Exchanger through the 1-1/2" NPT drain line. Refer to [Figure 2-7](#).

IMPORTANT: *If the piping will be supplied by the customer, provide raw water supply piping and components equivalent to components supplied by Cummins Fire Power and as shown in Assembly Diagram, Raw Water Piping. Refer to National Fire Protection Association NFPA20 Chapter 11 for US installation requirements. When choosing components for the raw water supply and bypass, ensure that the internal cross sectional area of the component is at least as large as the recommended pipe size.*

When the raw water piping is installed, adjust both pressure regulator set points before operating the pump.

1. The upper line is the bypass line. The bypass line outlet valve should be closed.
2. The lower line with the solenoid valve is the normal inlet line. The pressure gauge isolation valve must be open. The normal raw water inlet line valve should be open.

IMPORTANT: *Monitor the oil pressure and coolant temperature gauges frequently. Refer to Lubricating Oil System Specifications or Cooling System Specifications in the Engine Data Sheets for recommended operating pressures and temperatures. Shut off the engine if any pressure or temperature does not meet the specifications.*

Maximum engine coolant temperature should not exceed 107° C (225° F). The coolant expansion tank/

fill cap must meet the minimum pressure of 10 kPa (15 psi).

The engine coolant system contains a mixture of at least 50% anti-freeze and 50% water. The coolant level should be maintained in or just below the coolant expansion tank level sight gauge.



CAUTION

Continuous operation with low coolant temperature (below 70° C (158° F)) or high coolant temperature (above 107° C (225° F)) can damage the engine. Verify raw water coolant pressure and flow.

2.7 Fuel Cooling System


A combination coolant/fuel cooling heat exchanger maintains fuel temperature to meet the maximum allowable fuel inlet temperature (71° C (160° F)). Performance of the fuel cooling system is critical to engine durability, performance and emissions compliance.

2.7.1 Fuel Supply and Drain Location

The fuel inlet and drain connections are located at the front of the unit below the raw water manifold assembly. The fuel inlet line runs from the connection fitting directly to a Lift Pump and Fleetguard® 25 micron fuel filter instead of to an ECM cooling plate. Refer to [Figure 2-9](#).

2.8 High Pressure Injector (HPI) Fuel System

The fire pump engine is equipped with an electronic fuel system that delivers precise fuel quantities with precise injection timing at high injection pressures. The system consists of six (6) high-pressure unit injectors and an Integrated Fuel System Module (IFSM). The IFSM provides individual cylinder control fuel metering and injection timing and controls the fuel supply pump and regulator pressure using various system monitoring sensors. The system is controlled by CM570 Engine Control Modules (ECMs) for fueling and timing based on temperature, altitude, boost pressure, and throttle position. Refer to [Figure 2-9](#).




CFP-074

- | | |
|---|---|
| 1. Coolant/Fuel Cooling Heat Exchanger | 8. Fuel Return Line |
| 2. ECM Module A | 9. Fuel Supply Line |
| 3. Integrated Fuel System Module (IFSM) | 10. Fuel Lift Pump |
| 4. Fuel Pump | 11. Fuel Filter or Filter/Separator |
| 5. ECM Cooling Plate | 12. Fuel Cooling Line To Heat Exchanger |
| 6. ECM Module B | 13. Fuel Cooling Line From Heat Exchanger |
| 7. ECM Selector Panel and Switch | |

Figure 2-9 Fuel System Components

With the HPI fuel system, fuel priming is required for conditions such as: initial start-up, running out of fuel and maintenance of fuel system components (i.e., filter change). A 24 VDC fuel lift pump is standard.

NOTE: The system will prime a totally dry fuel system in 120 seconds or less. Applications with remote fuel tank requires a fuel lift pump (supplied). Lift pump run time is limited to two minutes.



CFP-010

- | | |
|-------------------------------|---------------------------|
| 1. Oil Pump | 7. Oil Cooler |
| 2. Pressure Regulator Valve | 8. Combination Oil Filter |
| 3. Oil Return To Pan | 9. Filter Bypass Gears |
| 4. High Pressure Relief Valve | 10. Idler Gears |
| 5. Oil Return To Pan | 11. Viscosity Sensor |
| 6. Oil Thermostat | 12. Turbocharger |

Figure 2-10 Flow Diagram - Engine Lubricating Oil System (typical)

2.9 Engine Oil System


The Engine Oil System lubricates moving internal engine parts (pistons, piston arms, valves, cam shafts, drive shafts and bearings). The oil pump circulates oil from the oil pan, through the oil filter and into engine areas where friction may develop. Refer to [Figure 2-10](#).

Typically engine oil has been added during manufacture and testing procedures, however, shipping restrictions can affect whether the oil is maintained in the engine or drained for shipment.

Check the oil level at the dipstick. Add oil as necessary to bring the oil level to the H (high) mark on the dipstick.


2.10 Exhaust System

The exhaust system removes engine exhaust from the cylinders after the combustion process. The exhaust discharges from the exhaust manifold, passes through (drives) the turbocharger, and exits through the exhaust flex-pipe. Refer to [Figure 2-11](#), and [Figure 2-12](#).



- | | |
|------------------------|--|
| 1. Exhaust Valve Ports | 3. Combustion Air To Charge Air Cooler |
| 2. Exhaust Manifold | 4. Turbocharger Turbine |

Figure 2-11 Flow Diagram - Exhaust System (typical)



- | | |
|--|---------------------|
| 1. Wastegate Actuator Cylinder | 4. Wastegate OPEN |
| 2. Exhaust Flow to Flex Pipe | 5. Wastegate CLOSED |
| 3. Combustion Air To Charge Air Cooler | |

Figure 2-12 Turbocharger Exhaust Flow Diagram (typical)



Section 3 - Installation

3.1 Receiving and Handling Information

Cummins Fire Power Pump Engines are pre-assembled and tested before shipment. Parts not shipped attached to the engine are sometimes shipped individually. The equipment was thoroughly inspected and prepared for shipping before it was turned over to the carrier.

1. Carefully remove the components from the shipping container. Remove crating, shipping tape, braces and tie-downs.
2. Inspect the equipment for damage that may have occurred in shipping.
3. Check each item carefully against the shipping manifest or bill of lading.

3.1.1 Damage During Shipping

File a *Claim For Damages* with the carrier, if your equipment was received damaged or not received at all. Notify Cummins Fire Power, or Cummins Inc. as soon as possible to determine if a replacement item or repair is required.

3.1.2 Claim Filing Procedure

The following information is required if a claim is filed:

1. A *Claim Statement* describing the damaged or lost merchandise and how the claim was determined.
2. A *Bill of Lading* or *Freight Bill* is required as proof of who transported the freight.
3. A noted *Freight Bill* or *Inspection Report Copy*, as evidence of loss or damage.
4. *Invoice Copy* or other documents establishing the cost to you of the freight lost or damaged, or an *Invoice for Repairs*.

3.2 Site Preparation

This section provides instructions for the initial installation, adjustment, and testing of the Cummins Fire Pump Engine. Appropriate portions of this section

should be used when returning the engine to operation after overhaul or major maintenance.

The site should be clean and relatively level. Clear the proposed equipment area of overhanging obstructions and obstacles protruding from the floor.

Raw water piping should be installed by trained technicians, familiar with local, state and federal codes and regulations, per the equipment layouts supplied by Cummins Fire Power, or Cummins Inc.

3.2.1 Site Considerations

Refer to the general fire pump and engine layout drawings for installation dimensions supplied with this manual.



CAUTION

Avoid installation in a dusty or dirty environment. Provide adequate physical protection from other physical damage as may be present in the specific location.


Refer to National Fire Protection Association NFPA 20, Chapter 11 for US installation and applicable local code requirements.

1. Lay out a designated center line on the site floor. Find the center line of the engine drive shaft. Lay out a center line on the cross frame members.

IMPORTANT: *Ensure that the lifting device or forklift is capable of handling the package weight and size requirements.*

2. If the engine is lifted separately, use the lifting hooks (supplied with the engine) and a spreader bar to position the engine. Refer to [Figure 3-1](#).

If the engine is assembled with the drive line, pump and mounting base, use the lifting points provided on the mounting base or lift the entire skid using an approved fork lift. Refer to the layout drawings supplied with this manual for lifting points.




1. Lifting Lug
2. Lifting Spreader Bar

Figure 3-1 Engine Lifting Lugs (Engine Only)

CAUTION

Ensure that the lifting device is capable of safely lifting the weight of the engine or the combined weight of the assembled pump base, drive line and pump. Refer to the Bill of Lading for combined shipping weights.

3. Position the engine as required for the interface with the fire pump, water piping, fuel piping, exhaust and air system connections.
4. Position the engine center line to align the engine drive shaft with the fire pump drive. Ensure that the engine and pump are correctly aligned.
 - a. Ensure engine position is centered on frame side to side within $\pm .03$ inch, by measuring outside of frame side to engine support leg mounting pad. (Compare two front engine supports and two back engine supports).
 - b. Align engine center line to pump center line within $\pm .03$ inch. Refer to [Figure 3-2](#).
 - c. The pump center line to the engine crank center line (in vertical plane) is to be $.25$ inch: $+0$, $-.25$ inch offset.
 - d. Drive shaft mounting flanges must be parallel.



1. Planes Must Be Parallel
2. Align Both Mounting Center lines to $\pm .03$ "
3. Distance to Equal Half of Total Travel
4. $.25$ " $+0$, $-.25$ " Offset

Figure 3-2 Drive Coupling Alignment

5. Check that the fire pump is properly installed per the pump manufacturer's specifications.
6. Connect the exhaust piping to a safe location, away from building air intake sources (air conditioners, windows, fresh air intake pipes, etc.).




Figure 3-3 Drive Coupling Grease Fittings


7. Check that the alternator and coolant pump drive belts are properly installed.
8. Check that all hoses and tubes are properly installed and all clamps secure.
9. Lubricate grease fittings on the drive shaft universal joint. Refer to [Figure 3-3](#).
 - a. Wipe the grease fittings and grease gun nozzle with a clean cloth.
 - b. Add grease to the universal joint grease fittings.
 - c. Wipe excess grease from the grease fittings.

NOTE: Cummins Fire Power, or Cummins Inc. recommends using a good quality semi-synthetic, molybdenum-fortified NLGI #2 lithium complex grease which protects from -54° to 400° F such as Valvoline Durablend®.

NOTE: Some lubrication loss may occur during transport and storage. It is recommended that the drive shaft be re-lubricated upon installation.


3.3 Fuel Supply Installation

1. Install an elevated no. 2 diesel fuel tank or other fuel supply arrangement which is compatible with ASTM no. 2 diesel fuel specifications.



1. Engine Base Frame
2. 3/4" Fuel Inlet Hose
3. 3/4" Fuel Outlet Hose

Figure 3-4 Fuel Line Inlet and Outlet Hoses



1. Fuel Injection Pump
2. Fuel Return Connection
3. Fuel Supply Connection
4. Fuel Lift Pump
5. Fuel Filter or Filter/Separator

Figure 3-5 Engine Fuel Filter

NOTE: The fuel supply line at the fuel tank must be higher than the fuel intake port on the engine fuel filter. Ensure that the fuel system is installed in a safe and effective manner.

2. Size the fuel tank for the maximum expected full-load engine operation period with the initial fuel level at the minimum level for refueling.
3. Install a 3/4" NPT (minimum) fuel return line. Route this line to the bottom of the fuel tank in order to minimize the return head. Refer to [Figure 3-4](#).
4. Install a 3/4" NPT (minimum) fuel supply line to the fire pump engine.

NOTE: DO NOT use copper or galvanized pipe for the fuel return or supply lines.

3.3.1 Fuel System Preparation

The fire pump engine fuel system has been primed during manufacturing and test procedures. The

engine is equipped with an electric primer pump which primes the fuel filter or filter/separator and high pressure fuel pump when the engine is cranked. Refer to [Figure 3-5](#).

A Water Separator must be integrated into the fuel delivery system of the fire pump engine. A Fuel Filter/ Water Separator may be installed directly on the unit in the primary fuel filter location, or a separate filter/ separator may be installed in the fuel delivery system near the fire pump engine assembly.

1. Ensure that the filter/separator is free of water by opening the fuel filter/water separator drain at the bottom of the filter. Refer to [6.3.5 Fuel System Inspections](#) for additional information.
2. Drain the fuel into a container until no water is present. Dispose of the contaminated fuel in accordance with local environmental regulations.

CAUTION

Due to the precise tolerances of diesel injection systems, it is extremely important that the fuel be kept clean and free of dirt or water. Dirt or water in the system can cause severe damage to both the fuel pump and the fuel injectors.

3.3.2 Fuel Recommendations

WARNING

Do not mix gasoline, alcohol, gasohol, ethanol or methanol with diesel fuel. This mixture will cause severe engine damage or explosion.

CAUTION

Use ONLY no. 2 diesel (ASTM no. 2D) fuel. Any adjustment to compensate for reduced performance with a fuel system using alternate fuel is not warrantable.

3.4 Raw Water Supply Installation

Raw water circulated through the system cools the charge air cooler (CAC) heat exchanger, the coolant/ fuel cooling heat exchange fluid. Raw water supplied from the fire pump water source prior to the pump discharge flange, is forced through the cooling system to the various heat exchangers. Refer to [Figure 3-6](#) and [Figure 3-7](#).

IMPORTANT: *The raw water supply must be immediately available when the engine is started. Ensure that the supply line valves are in the OPEN position.*


CAUTION

When the raw water piping is installed, adjust both pressure regulator set points before operating the pump. Damage to the heat exchanger may occur from improperly regulated raw water supply pressure.

3.4.1 Install Raw Water Piping

NOTE: *The velocity of the raw water should be as great as possible without exceeding the maximum allowable pressure shown in the appropriate engine data sheet.*

1. Provide 1-1/2" NPT raw water drain line at the outlet of the heat exchanger. Refer to [Figure 3-6](#).



1. Bypass Water Outlet Valve
2. Bypass Pressure Regulator/Strainer
3. Bypass Water Inlet Valve
4. 1-1/4" NPT Raw Water Inlet
5. Normal Water Inlet Valve
6. Normal Pressure Regulator/Strainer
7. Normal Water Solenoid Valve
8. Normal Water Outlet Valve
9. Raw Water Drain Plug
10. Pipe To Heat Exchanger
11. Pressure Gauge Isolation Valve
12. Water Supply Pressure Gauge


Figure 3-6 Raw Water Cooling Loop Manifold

NOTE: Raw water outlet piping from the heat exchanger should be one pipe size larger than the supply piping.

2. Provide raw water supply line to the 1-1/4" NPT raw water cooling loop manifold.

NOTE: The water supply set points have been set by the manufacturer during engine assembly and testing.

3. Check the pressure regulator setting with water flowing through the heat exchanger. Both raw water pressure regulators have been set at 207 kPa (30 psig) or slightly less during manufacture and testing. The raw water should be adjusted based on water flow rather than water pressure. The flow is dependent on the raw water temperature. Refer to the engine curve and data sheet for details.



1. Engine Coolant Expansion Tank
2. Charge Air Cooler (CAC) Heat Exchanger
3. Raw Water Inlet Pipe
4. Coolant/Fuel Cooler Heat Exchanger
5. Raw Water Outlet Pipe
6. Fuel Cooling Lines

Figure 3-7 Cooling Loop Heat Exchangers

4. Use a 5 gallon container to measure and time the flow from discharge pipe.

Flow rate = time to fill container/container.

Example: Time to fill 5 gallon container = 15 seconds.

Divide 15 by 5 = 3 (seconds per gallon).

Divide 60 seconds by 3 = 20 gallons per minute.

5. Adjust both pressure regulators to a pressure that will provide the flow rate at or above the specifications.

The minimum raw water flow rate is 25 GPM @ 10° C (50° F), 30 GPM @ 21° C (70° F), and 35 GPM @ 32° C (90° F).

IMPORTANT: The manual raw water valves for the Automatic Loop should remain OPEN at ALL times. The manual valves for the Bypass Loop should be CLOSED during Automatic (pump controller) operation.

NOTE: When running, the engine should stabilize between 82° C and 85° C (180° F and 185° F). The flow rate may need to be increased if the temperature stabilizes above this range. Do not exceed 60 psi.

NOTE: Excess cold (4° C to 23° C (40° F to 75° F)) raw water flow can cause condensation inside the charge air cooler.

IMPORTANT: Continuous operation with low coolant temperature (below 70° C (158° F)) or high coolant temperature (above 107° C (225° F)) can damage the engine.

3.5 Battery Selection

The minimum recommended reserve capacity (SAE RC) and cold cranking ampere (SAE CCA) values for a particular engine can be found on the engine curve and data sheet. RC and CCA definitions can be found in SAE standard J537. All battery information is for lead/acid batteries.

3.5.1 Battery Requirements

Two redundant sets of batteries must be supplied for the standard 24 VDC operating voltage. Refer to National Fire Protection Association, NFPA 20, Chapter 11 and Section 1 - Safety of this manual for additional battery installation information.

IMPORTANT: Batteries must meet the requirement listed in Electrical System Specifications. Batteries may be supplied by Cummins Fire Power, or Cummins Inc. as an option or may be supplied by the customer.




Figure 3-8 Series Battery Connection - 24 VDC

! WARNING

Battery electrolyte (sulfuric acid) is highly caustic and can burn clothing, and skin. Wear acid impervious neoprene gloves, and safety goggles or full face shield, when working with the batteries. Always disconnect the negative (-) battery cable first and attach the negative (-) battery cable last.

! CAUTION

DO NOT connect battery charging cables to any electronic control system component. This can damage the electronic control system.

NOTE: Use the inductive charging-cranking systems analyzer, Cummins Part Number 3377193, to test the output amperage of either maintenance-free or conventional vent cap batteries. Follow the instructions provided with the test equipment.

3.5.2 Battery Installation

Install the Loose Wire Kit per instructions on Cummins Drawing 9768. If purchased, install the optional Battery Cable Kit (Cummins Fire Power Part No. 14852). Otherwise, install equivalent customer supplied wiring. Install battery sets in a well ventilated or otherwise protected location.

NOTE: There are two possible heavy-duty battery connections: Battery terminal and clamp or threaded battery terminal and nut.

1. Provide adequate room for servicing or replacing the batteries. Provide protection from extremes of temperature and weather.

2. Locate the batteries near the engine or increase the size of the conductors as required by applicable codes. Ensure that the batteries are configured properly for 24 VDC standard operations. Refer to [Figure 3-8](#).

3. Check the battery cables and connections.

NOTE: Coat the terminals with petroleum jelly to prevent corrosion. Install the cables and tighten the battery connections.

3.5.3 Auxiliary Battery Starting

If a battery charging system is not provided, the engine can be started using charged batteries.

NOTE: For maintainable lead acid batteries supplied by Cummins Fire Power, or Cummins Inc., check the state of charge by measuring battery cell specific gravity. Refer to Battery Testing in [Section 6 - Maintenance](#) for additional information.

! WARNING

Batteries can emit explosive gases during charging. Always ventilate the compartment before servicing the batteries. Remove sources of spark or open flame. To avoid arcing, remove the negative (-) battery cable first and attach the negative (-) battery cable last.

3.6 Signal and Control Installation



This section explains how to connect the controller wires to the terminal block.

! CAUTION

If the batteries have been installed prior to the control wiring, disconnect the negative (-) cable first and then disconnect the positive (+) battery lead. Install the cables with the positive (+) cable first and the negative (-) cable last before testing.

NOTE: Install signal and control wiring at Terminal Board TB. Refer to the terminal wiring schematic decal on the inside of the instrument enclosure.

1. Ensure that the fire control system is properly installed and configured per the manufacturer's instructions. Refer to the Wiring Schematic Drawings provided with the pump manual.



CFP-044

Figure 3-9 Termination Blocks and Wiring Decal

2. Complete the fire pump controller wiring (customer supplied) per the manufacturer's instructions.
3. Connect the following wires to the Fire Pump Engine Instrument Panel per the engine electrical diagrams. Refer to [Figure 3-9](#).
 - a. TB-1: Connect the Control Power from the Fire Pump Controller. This power source is necessary for fire pump operations while in the AUTO Mode.
 - b. TB-2: Connect the Crank Terminate input signal for the Fire Pump Controller. This signal is present when the engine is running. This signal indicates that the engine has started and that the crank command from the fire pump controller should stop immediately.
 - c. TB-3: Connect the remote Overspeed Alarm Input to the Fire Pump Controller. This signal is present when the overspeed switch has operated. If this event occurs, the fire pump engine will stop.

- d. TB-4: Connect the Low Oil Pressure Alarm Input from the Fire Pump Controller. This 0 VDC grounded signal is present when the oil pressure has dropped below the 110 ± 13 kPa (16 ± 2 psig) Set Point.
 - e. TB-5: Connect the High Coolant Temperature Alarm Input from the Fire Pump Controller. This 0 VDC grounded signal is activated when the engine is running and the coolant temperature is at or above 93°C (200°F). The alarm will deactivate when the engine is running and the coolant temperature drops below 88°C (190°F).
 - f. TB-6: Connect Battery Set "A" lead from the controller. The controller senses Battery A charge state and charges the battery through this heavy gauge wire.
 - g. TB-8: Connect Battery Set "B" lead from the controller. The controller senses Battery B charge state and charges the battery through this heavy gauge wire.
 - h. TB-9: Connect Crank From Battery A Lead. During a cranking cycle, the controller energizes the coil of Starter Contactor A through terminal TB-9 to start the engine.
 - i. TB-10: Connect Crank From Battery B Lead. During a cranking cycle, the controller energizes the coil of Starter Contactor B through terminal TB-10 to start the engine.
 - j. TB-11: Connect the "Battery Ground" lead from the controller. This heavy gauge wire provides a common ground between the engine and controller.
 - k. TB-301: Connect the "Operating On Alternate ECM" lead. This 0 VDC ground signal is present when the engine's ECM selector switch is set to ECM-B.
 - l. TB-302: Connect the "ECM / Fuel Fault" signal wire. This 0 VDC ground signal is present when the engine signals a trouble fault.
4. Ensure electrical continuity and adequate insulation resistance for the installed wiring.

5. Provide the initial charge on the redundant batteries per the battery charger's instructions.
6. Check that both voltmeters on the operator's control panel indicate the approximate battery voltage.

3.7 Coolant System Preparation


The fire pump engine cooling and lubrication system was initially filled during manufacture and testing.



CAUTION

Ensure that all cooling and lubrication systems have been filled to the proper level before operation.


1. Inspect the engine coolant hoses and hose clamps. Ensure that all coolant hoses and clamps are properly installed and tight. Refer to [Figure 3-10](#) and [Figure 3-11](#).



1. Upper Coolant Hose
2. Hose Clamps
3. Thermostat Housing Flange

Figure 3-10 Upper Cooling Hose Clamps

2. Ensure that the engine coolant level is visible at the center of the expansion tank sight gauge. Add coolant as required. **DO NOT OVERFILL!**
 - a. If engine coolant temperature is below 50°C (122°F), remove the expansion tank pressure/fill cap. Refer to [Figure 3-12](#).




1. Engine Heater
2. Coolant Filter
3. Lower Coolant Hose
4. Coolant Pump

Figure 3-11 Coolant Circulation System

NOTE: Supplemental engine coolant should be a mixture of 50% ethylene glycol anti-freeze and 50% water to avoid engine damage. Refer to Anti-freeze information found in [Section 6 - Maintenance](#) for additional information.

- b. Check and correct any cooling system leaks.
- c. Install the pressure/fill cap on the Coolant Expansion Tank.



1. Engine Coolant Expansion Tank
2. Coolant Expansion Tank Pressure/Fill Cap

Figure 3-12 Engine Coolant Expansion Tank


3. The engine coolant heater must maintain an engine coolant temperature of 49° C (120° F) or above. Refer to [Figure 3-11](#).

Ensure that coolant is present in the engine heater before plugging in the heater element.

3.8 Charge Air Cooler System


The charge air cooler system reduces the temperature of the compressed combustion air from the turbocharger before entering the air intake manifold. Refer to [Figure 3-13](#) and [Figure 3-14](#).

1. Inspect the charge air cooler piping and hoses for loose/missing hose clamps, hose punctures, leaking manifold seals, or corrosion. Torque the hose clamps to 8 N-m (72 in-lb).
2. After the engine starts, a whistling noise may indicate an air leak from the turbocharger to discharge elbow connection, loose hose clamps, damaged manifold seals, missing hose clamps, or hose punctures.
3. Inspect for damage. Tighten loosen clamps. Torque hose clamp screws to 8 N-m (72 in-lb).



1. Charge Air Cooler (CAC) Heat Exchanger
2. CAC Tubing and Clamps
3. Intake Manifold

Figure 3-13 Charge Air Cooler Tubing



CFP-142

1. Charge Air Turbocharger
2. Exhaust Manifold
3. Charge Air Cooler (CAC) Tubing
4. Exhaust Flex Connection

Figure 3-14 Turbocharger and Charge Air Cooler (CAC) Piping

3.9 Lubricating Oil System Preparation

The fire pump engine was initially lubricated during manufacture and testing.


CAUTION

Some regulatory and shipping restrictions may require that all lubricants, fuels and coolants be drained for transport. Ensure that all cooling and lubrication systems have been filled to the proper level before operation.

1. Check the oil level using the crankcase dip stick before operating. Refer to [Figure 3-15](#).
2. Fill the crankcase at the oil fill port, to the "H" mark on the dipstick with lubricating oil. Refer to [Figure 3-15](#).

NOTE: Do not use special "break-in" lubricating oils for new or rebuilt Cummins engines. Use the same type of oil during the "break-in" as used in normal operation.


NOTE: Using multi-viscosity lubricating oil can improve oil consumption control and improve engine cranking in cold temperatures while maintaining lubrication at high operating temperatures. Cummins Inc. recommends Valvoline Premium Blue® 15W-40 oil for most climates.



CFP-081

1. Oil Level Dipstick
2. Oil Fill Port


Figure 3-15 Oil Level Dipstick & Oil Fill Port



CFP-144

1. Turbocharger Oil Line
2. Charge Air Cooler (CAC) Tubing
3. Exhaust Flex Connection
4. Turbocharger
5. Turbocharger Air Intake
6. Exhaust Manifold

Figure 3-16 Turbocharger Oil Line Location



1. Turbocharger Turbine Wheel
2. Turbocharger Intake Housing
3. Air Intake Tube and Clamp

Figure 3-17 Turbocharger Turbine Wheel (typical)

3. The turbocharger has been lubricated during manufacture and testing. Refer to [Figure 3-16](#).
 - a. Remove the air filter element.
 - b. Rotate the turbine wheel to allow oil to enter the bearing housing. Any excess oil will drain through the oil drain line. Refer to [Figure 3-17](#).
 - c. Lubricate the bearings by pouring 59 to 89 ml (2 to 3 oz.) of clean engine lubricating oil into the turbocharger oil supply line fitting.
 - d. Reconnect the turbocharger oil inlet line.
 - e. Install the air intake filter assembly.

3.10 Pre-Start Inspections

Perform a visual inspection as follows:

1. Check that there is no apparent damage and that all components are installed.
2. Check that the drive belt is properly installed.
3. Check that all hoses and tubes are properly installed.
4. Check that all electrical connections are properly installed.
5. Check that the fire pump is properly installed per the pump manufacturer's instructions, is correctly aligned, and is free to rotate.
6. Lubricate grease fittings on the auxiliary drive shaft.

NOTE: *Some lubrication loss may occur during transport and storage. It is recommended that all drive shafts be re-lubricated upon installation.*

7. Ensure that the engine exhaust pipe exhausts to atmosphere away from other building air intake piping.

3.11 Engine Start Test


Perform the following engine start test after completing all preliminary setup procedures, previously covered. Additional engine start tests and speed adjustment procedures are explained in [Section 5 - Operation](#)



WARNING

Before operating the equipment, complete all safety checks, remove all tools and foreign objects from the equipment, ensure that all guards are in place and securely fastened. Alert area personnel that the equipment will be starting. Unintentional equipment start-up or contact with exposed or moving components can cause personal injury or equipment damage.

The object of this test is to check that the engine starts and operates normally with oil pressure being displayed and raw water flow being established to the coolant heat exchanger. Operation at the factory-adjusted rated speed is also checked.




1. Coolant Temperature Gauge
2. Engine Oil Pressure Gauge
3. Tachometer and Hour Meter
4. Circuit Breaker
5. Battery "A" Voltmeter
6. Battery "B" Voltmeter

Figure 3-18 Operator Control Panel - Instruments


1. To start the engine from the Fire Pump Controller Panel:
 - a. The AUTO Mode Switch position is the default operating position.
 - b. Place the AUTO/MANUAL Mode Switch on the Operator's Instrument Panel in the AUTO Mode position. Refer to [Figure 3-18](#) and [Figure 3-19](#).
 - c. Start the engine by initiating an engine start signal from the Fire Pump Control Panel.

NOTE: The fire pump engine will crank automatically when either solenoid A or solenoid B is selected at the fire pump controller panel.



1. ON/OFF Switch Locking Button
2. ON/OFF Switch (AUTO/MANUAL)
3. Overspeed RESET/STOP Switch
4. Low Oil Pressure Warning Lamp
5. Crank Battery A/B Momentary Start Switch
6. ECM Engine Shut Down Lamp (red)
7. ECM A/B Indicator Lamps
8. ECM Warning Lamp (amber)
9. High Coolant Temperature Warning Lamp
10. Overspeed Warning Lamp

Figure 3-19 Operator Control Panel - Controls



1. Battery A Starter Contactor
2. Battery B Starter Contactor

Figure 3-20 Manual Starter Contactors

2. To start the engine from the Operator Control Panel:

- a. Disengage the AUTO/MANUAL Switch Locking Button and place the switch in the MANUAL Mode position.
 - b. Place the AUTO/MANUAL Start Switch on the Operator's Control Panel in the MANUAL START position.
 - c. Press downward on either CRANK BATT A/B Switch to start the engine.
3. To start the engine using the Manual Override Contactor A/B Levers:
 - a. Place the AUTO/MANUAL Start Switch on the Operator's Instrument Panel in the MANUAL START position.
 - b. Press downward on either Manual Override Contactor A/B Lever to start the engine. Refer to [Figure 3-20](#).
 - c. Release the Contactor Lever immediately after the engine starts.
 4. Check that the engine starts and operates at rated speed.
 5. The engine may be stopped locally by pressing and holding the Overspeed RESET/STOP Switch until the engine stops.

3.11.1 Engine Will Not Start

If the engine still will not start, refer to [Section 7 - Troubleshooting](#) for possible causes.

3.11.2 Engine Starts

If the engine starts it is important to monitor the oil and raw water pressure gauges and coolant temperature gauge to ensure safe operation.



CAUTION

If the oil pressure is not displayed on the gauge or if the Low Oil Pressure Lamp is illuminated for 15 seconds, STOP THE ENGINE immediately! Continued operation without proper lubrication will cause engine damage.

1. Immediately check that oil pressure is displayed at the pressure gauge within a few seconds. Ensure that the oil pressure is between 276-414 kPa (40-60 psi).

If oil pressure is not within the rated range, troubleshoot per Lubricating Oil Pressure High or Lubricating Oil Pressure Low in [Section 7 - Troubleshooting](#).

2. Immediately check that raw water flow is established through the coolant heat exchanger. Raw water flow should be established immediately but some delay may occur before the flow exits the heat exchanger drain connection.
 - a. Ensure that raw water is flowing through the heat exchanger and water pressure shown on the local pressure gauge is no more than 414 kPa (60 psig). The minimum raw water flow rate is 25 GPM @ 10° C (50° F), 30 GPM @ 21° C (70° F), and 35 GPM @ 32° C (90° F).



CAUTION

If the coolant temperature gauge is not reading properly or if the Coolant Temperature Lamp is illuminated for 15 seconds, STOP THE ENGINE immediately! Continued operation without proper cooling will cause engine damage.

3. Ensure that engine operating temperature stabilizes between 82° and 95° C (180° and 203° F).
 - a. If temperature does not stabilize, stop the engine and refer to Coolant Temperature Above Normal or Coolant Temperature Below Normal (Engine Running) in [Section 7 - Troubleshooting](#).
4. Operate the engine for 8 to 10 minutes.
5. Inspect for leaks, unusual noises, or other indications of incorrect operation.
6. Shut off the engine by pressing and holding the RESET/STOP Switch until the engine stops.
7. Check that raw water flow stops automatically shortly after the engine stops.
8. Correct any problems found during the inspection before proceeding.
9. Check the engine lubricating oil level at the crankcase dip stick. Top off if necessary.

-
10. Check the coolant expansion tank level. Top off if necessary.
 11. Check the raw water strainers. Clean the strainer as required per the instructions in [Section 6 - Maintenance](#).
 12. Perform engine speed control and safety system tests per the instructions in [Section 5 - Operation](#).

Section 4 - Controls

4.1 Operator Control Panel

The operator control panel is mounted on the fly-wheel end of the engine.

The Operator Control Panel contains instruments and controls for starting, monitoring engine performance and controlling fire pump engine operation. Refer to [Figure 4-1](#).

4.1.1 Coolant Temperature Gauge

The Coolant Temperature Gauge displays the temperature of the coolant circulating through the fire pump engine. The gauge works in unison with the High Coolant Temperature Alarm Sensor to the fire pump controller at terminal TB-5. This 0 VDC grounded signal is present when the engine is running and the coolant temperature has risen above the 93° C (200° F) Set Point.

When the engine starts, immediately check that raw water flow is established through the fuel/coolant heat exchanger. Raw water flow should be established immediately but some delay may occur before the flow exits the heat exchanger drain connection. Stop the engine if the coolant temperature alarm is illuminated for more than 15 second.


CAUTION

If the coolant temperature exceeds the high coolant temperature set point, the High Coolant Temperature Warning Lamp is illuminated. The engine will continue to operate but immediate attention is necessary in order to prevent extensive damage to the engine or catastrophic engine failure.

4.1.2 Lubrication Oil Pressure Gauge

The Lubrication Oil Pressure Gauge displays the lubricating oil pressure. The gauge works in unison with the Low Oil Pressure Alarm Input from sensor TB-5. The 0 VDC grounded signal is terminated when the oil pressure has dropped below the 110 kPa (16 psig) set point.

When the engine starts, immediately check that oil pressure is displayed. It should be on-scale within a few seconds. If oil pressure is not present or if the Low Oil Pressure Lamp does not go out, stop the engine and troubleshoot per the instructions in [Section 7 - Troubleshooting](#).



CFP-021

1. Coolant Temperature Gauge
2. Engine Oil Pressure Gauge
3. Tachometer and Hour Meter
4. Circuit Breaker
5. Battery "A" Voltmeter
6. Battery "B" Voltmeter

Figure 4-1 Operator Control Panel - Instruments

CAUTION

If the engine oil pressure drops below the minimum oil pressure set point, the Low Oil Pressure Warning Lamp is illuminated. The engine will continue to operate but immediate attention is necessary in order to prevent extensive damage to the engine or catastrophic engine failure.

4.1.3 Tachometer and Hour Meter

The Tachometer displays the engine speed in revolutions per minute (RPM) whenever the engine is operating. The Hour Meter maintains a running total of the hours of operation (run time). The Tachometer works in unison with the Engine Overspeed Alarm Input from sensor TB-3. This 24 VDC signal is present when the overspeed switch has operated.



CAUTION

If an engine overspeed condition occurs, the fire pump engine will stop to avoid fire system over-pressurization. The fault must be corrected and the local RESET Button must be pressed in order to restart the engine.

NOTE: The Run Speed and Engine Overspeed Set Point are displayed on the Factory Setting Tag, on the flywheel end of the unit.

NOTE: Electronically controlled engines should operate within a few RPM of the rated speed whether the engine is fully loaded or unloaded. If it becomes necessary to adjust the engine's actual speed to match the rated value, refer to Rated Speed Set Point Adjustment in [Section 5 - Operation](#).

4.1.4 Battery A and B Voltmeters

The Battery Voltmeters display the charge status (VDC) of the relative battery connections. Permanently installed redundant battery charging systems with connections at TB-6 and TB-8 (+) and TB-11 (-) should also be used for remote battery voltage indications at the fire pump control system or elsewhere.

NOTE: The two voltmeters may differ slightly due to calibration differences between the meters. Normal differences in battery condition may also cause indication differences. These are normal differences and require no action.

4.1.5 Circuit Breaker Switches

The engine control panel has two manual-reset type, 30 A Circuit Breakers. They protect against a catastrophic failure, such as a direct battery-terminal ground fault or a battery charger malfunction. One breaker is for Battery A, and the other breaker is for Battery B.


NOTE: If one of the circuit breakers trips, locate and repair the source of the fault before pressing the RESET Button.

4.1.6 AUTO/MANUAL Mode Switch

The AUTO/MANUAL Mode Switch determines whether the engine starts and is controlled by the operator (MANUAL) or by an automatic signal from the fire pump controller (AUTO). Refer to [Figure 4-2](#).

The Manual Mode is typically used for engine setup, testing and maintenance procedures. The AUTO Mode is used to start the engine under the control of the fire pump control system (in the absence of a live operator).

In the AUTO mode, the fire pump engine stops upon loss of signal power from the fire pump controller.




CFP-022

1. AUTO/MANUAL Mode Switch Locking Button
2. AUTO/MANUAL Mode Switch
3. Overspeed RESET/STOP Switch
4. Low Oil Pressure Warning Lamp
5. Crank Battery A/B Momentary Start Switch
6. ECM Engine Shut Down Lamp (red)
7. ECM A/B Indicator Lamps
8. ECM Warning Lamp (amber)
9. High Coolant Temperature Warning Lamp
10. Overspeed Warning Lamp

Figure 4-2 Operator Control Panel - Controls

4.1.7 Overspeed Warning Lamp

The Overspeed Warning Lamp is illuminated whenever the engine RPM rate exceeds the factory set Engine Overspeed Set Points. The lamp is not lit when the engine is operating within the normal engine RPM range. Refer to [Figure 4-2](#).



CFP-082

1. Engine Serial Number Plate
2. Field Engine Speed and Overspeed Settings
3. Factory Engine Speed and Overspeed Settings

Figure 4-3 Engine Settings Plates

NOTE: The Run Speed and Engine Overspeed Set Point are displayed on the Factory Setting Tag, on the flywheel end of the unit. Refer to [Figure 4-3](#).

4.1.8 Engine Overspeed Warning Lamp

The Overspeed Sensor monitors engine speed during the start cycle and engine operation. The remote Overspeed Alarm Input from the engine controller is connected to terminal TB-3. The speed switch is factory programmed to enable at 115% rated engine speed. If the engine RPM's exceed 115% rated speed, the engine Overspeed Warning Lamp is illuminated and the engine will shut down.

NOTE: The overspeed switch has been set at the factory during assembly and testing. It should not require additional programming unless the pump operating speed is changed.



CAUTION

If the Overspeed Sensor is tripped, the fire pump engine will stop to avoid catastrophic failure. The fault must be corrected and the local RESET Button must be pressed in order to restart the engine.

4.1.9 Overspeed RESET/STOP Switch

Pressing the Overspeed RESET Switch after correcting an engine overspeed shutdown, resets the operator controls, allowing subsequent restart of the fire pump engine.

Once running, the engine may be stopped locally by pressing and holding the Overspeed RESET/STOP Switch until the engine stops.

4.1.10 High Coolant Temperature Warning Lamp

The High Coolant Temperature Lamp is lit whenever the engine is running and the coolant temperature has risen above the 93° C (200° F) Set Point.

IMPORTANT: If high coolant temperature lamp does not go out, stop the engine and troubleshoot per the instructions in [Section 7 - Troubleshooting](#).



CAUTION

If the coolant temperature exceeds the high coolant temperature set point, the high coolant temperature warning lamp is illuminated. The engine will continue to operate but immediate attention is necessary in order to prevent extensive damage to the engine or catastrophic engine failure.

4.1.11 Low Oil Pressure Warning Lamp

The Low Oil Pressure Warning Lamp is switch activated at a falling pressure of 110 kPa (16 psig), and deactivates at a rising pressure of 83 kPa (12 psig) Set Point. (When the engine is not running, the Low Oil Pressure Lamp will be illuminated). When a Low Oil Pressure condition exists, the Low Oil Pressure Lamp on the Engine Control Panel will illuminate.

IMPORTANT: If oil pressure is not present or if the Low Oil Pressure Lamp does not go out, stop the engine and troubleshoot per the instructions in [Section 7 - Troubleshooting](#).



CAUTION

If the engine oil pressure drops below the minimum oil pressure set point, the low oil pressure warning Lamp is illuminated. The engine will continue to operate but immediate attention is necessary in order to prevent extensive damage to the engine or catastrophic engine failure.

4.1.12 CRANK BATT A/B Switch

The fire pump engine requires (2) sets of 12 VDC lead/acid core batteries, with each pair wired in series to produce 24 VDC. The batteries can be supplied by Cummins Inc. or by the customer.

The CRANK BATT A and CRANK BATT B Momentary Start Switches initiate an immediate engine start using the selected A or B Crank Battery.

4.1.13 ECM Fault Code Lamps

The AMBER Engine Warning Lamp and the RED Engine Shutdown Lamp serve three purposes:

1. To alert the operator of an engine malfunction. Refer to [Figure 4-2](#).

An illuminated AMBER Lamp indicates an engine malfunction that requires timely operator attention.

2. An illuminated RED Lamp indicates an engine malfunction that requires immediate and decisive operator response.
3. To flash out a 3-digit diagnostic fault code, which can then be used to help describe the nature of the engine malfunction. Refer to [Section 5 - Operation](#) for Fault Code Information.


4.1.14 ECM A/B Indicator Lamps

The two ECM Indicator Lamps show the position of the ECM Selector Switch. If the ECM Selector Switch is in the ECM A (normal) position, ECM A is controlling the engine, and the ECM A lamp is illuminated. Refer to [Figure 4-2](#) and [Figure 4-4](#).

If the ECM Selector Switch is in the ECM B (alternate) position, ECM B is controlling the engine, and the ECM B lamp is illuminated. Terminal 301 will be active (ground) for remote annunciation.

4.2 Electronic Control Module (ECM)

The system has an electronically controlled fuel injection system that optimizes fuel economy and reduces exhaust emissions. It does this by controlling the torque and horsepower curve, AFC function, engine high speed, low idle, and load speed. Refer to [Figure 4-5](#).



1. ECM Selector Panel
2. ECM Harness Connections
3. ECM A/B Selector Switch

Figure 4-4 ECM Selector Panel and Switch

The engine control system is an electronically operated fuel control system that also provides many operator or equipment features. The base functions of the control system include: Fueling and timing control, limiting the engine speed operating range between the low and high-idle set points and reducing exhaust emissions while optimizing engine performance.

The control system uses inputs from the operator and engine sensors to determine the fuel amount and timing required to operate at the desired engine speed. The ECM is the control center of the system. It processes all of the inputs and sends commands to the fuel system, vehicle, and engine control devices.

The ECM performs diagnostic tests on most of its circuits and will activate a fault code if a problem is detected in one of these circuits.

Active fault codes will cause a diagnostic lamp to activate to signal the driver. The ECM can communicate with the Insite™ service tool and some other engine controllers.


4.2.1 ECM Data Plate

The ECM Data Plate shows information about the ECM and how the ECM was programmed. The data

plate is located on the front of the ECM. Refer to [Figure 4-6](#).

The following information is available on the ECM Data Plate: ECM Part Number (PN), ECM Serial Number (SN), ECM Date Code (DC), Engine Serial Number (ESN), ECM Code: Identifies the software in the ECM.

NOTE: Have the ECM code for your engine available when communicating with a Cummins Authorized Repair Location.




1. Electronic Control Module (ECM) A
2. ECM Cooling Plate
3. Electronic Control Module (ECM) B
4. ECM Harness Connections
5. ECM Data Plate
6. ECM Selector Plate and Switch

Figure 4-5 Electronic Control Modules (ECMs)

4.3 Overspeed Switch

The overspeed switch senses engine speed during normal operation and during the start cycle. The switch deactivates the fuel pump solenoid valve and shuts off the engine whenever the speed exceeds the overspeed set point. Refer to [Figure 4-6](#).

NOTE: The overspeed switch is set during manufacture and test procedures and typically does not require setup at installation.



1. Spring Clamp Terminal Blocks
2. Speed Increase/Decrease Toggle Switch
3. RESET Button
4. TEST Button
5. Diagnostic ON/OFF Toggle Switch
6. CRANK Termination or Run Signal Indicator LED (factory use only)
7. Overspeed Indicator LED
8. Pre-wired Terminals
9. Crank Terminate Potentiometer Cover
10. Overspeed Potentiometer Cover


Figure 4-6 Engine Overspeed Control Module

1. Use the Adjustment and Test Procedure in [Section 6 - Maintenance](#) to change the set point.
2. Repeat the adjustments and checks until the desired set point is demonstrated. When the overspeed set point is set, check that the engine operates normally while not in the Test Mode.

NOTE: The overspeed set point must be set at between 115 and 120% of the engine's rated speed.

The speed switch located on the engine's local control panel has a TEST button which lowers the currently adjusted overspeed by 20%.

Thus, an overspeed set point of 2112 rpm would be reduced to $(2112 * 0.8) = 1689$ RPM when the test button is pressed.



1. Bypass Water Outlet Valve
2. Bypass Water Inlet Valve
3. Normal Water Inlet Valve
4. Normal Water Outlet Valve
5. Normal Water Solenoid Valve

Figure 4-7 Raw Water Flow Control Valves

4.4 Raw Water Flow Control Valves

The engine controller opens the raw water Normal Loop Solenoid Valve in either Manual or Automatic Mode. In the OPEN position, raw water can flow through the heat exchangers.

The manual valves control whether the Automatic or Bypass lines are supplying water.

1. Manual valves for the Automatic Loop should remain OPEN at ALL times.
2. Manual valves for the Bypass Loop should be CLOSED during Automatic (pump controller) operation.

4.5 Engine Protection System

The engine ECM monitors any engine abnormalities, and displays active faults via the AMBER Warning Lamp and the RED Shutdown Lamp on the operator instrument panel. Refer to [Section 7 - Troubleshooting](#) for additional Fault Code information.



CAUTION

Normally, Cummins engines with ECMs have derate and shutdown protection calibrated into the ECM. However, the ECM on this Cummins engine has no such derate or shutdown protection. The engine will run to destruction. Therefore, preventive maintenance is essential.

4.5.1 Engine Protection Fault

When an Engine Protection Fault (EPF) occurs, a corresponding Warning Lamp is illuminated on the operator's instrument panel. If an overspeed situation exists, the EPF automatically shuts down the fuel supply solenoid valve.

The EPF System uses a combination of any of the following engine controller sensor inputs:

1. Low Coolant Temperature (lamp warning).
2. High Coolant Temperature (lamp warning).
3. Low Coolant Level (lamp warning).
4. Low Oil Pressure (lamp warning)
5. Low Oil Level (lamp warning)
6. Engine Overspeed (engine shutdown).



Section 5 - Operation

5.1 Start-up Procedures

This section provides the operator with the information required to prepare the fire pump engine for normal operation, in a safe manner. This Operator's Manual is provided for your specific equipment and should be considered a part of that equipment. All personnel responsible for the operation and maintenance of the equipment should read and thoroughly understand this manual.



WARNING

Before preparing the machine for normal production, complete all safety checks, remove all tools and foreign objects from the machine, ensure that all guards are in place and securely fastened, and alert area personnel that the equipment will be starting.

5.2 General Operating Information

Cummins Fire Pump Engines are tested before being shipped from the factory. The engine operating speed must be set per the pump RPM requirements.

NOTE: The engine speed set points are displayed on the Factory Setting Plate, located on the power takeoff end of the engine.

5.3 Remote Starting Procedure

If the AUTO/MANUAL Mode Switch is in the AUTO Mode position, the pump engine starts automatically upon receipt of the start command from the customer installed pump controller panel. The AUTO Mode position is the default switch position.


NOTE: The AUTO/MANUAL Mode Switch Locking Button must be disengaged to place the switch in the MANUAL Mode.

The remote start command consists of a CRANK Signal from the pump controller. When the pump has started, the CRANK TERMINATE Signal is sent to the pump controller to indicate that the engine is running and to discontinue the CRANK Signal.

NOTE: How the crank and crank terminate signals are displayed depends upon the fire pump controller manufacturer. This indication should be checked in the event that an automatic start is initiated. If the signal is not present, the engine can be started locally using the Local Starting Procedure in this section.

To start the engine from the Fire Pump Controller Panel:

1. Place the AUTO/MANUAL Mode Switch on the Operator's Control Panel in the AUTO Mode position. Refer to [Figure 5-1](#).
2. Start the engine by initiating an engine CRANK Signal from the Fire Pump Controller.
 - a. When the engine starts, a CRANK TERMINATE Signal is sent to the fire pump control panel, indicating that the engine is running.



1. AUTO/MANUAL Mode Switch
2. STOP/RESET Switch
3. Low Oil Pressure Warning Lamp
4. Battery A/B Switch
5. Overspeed Warning Lamp

Figure 5-1 Operator Control Panel Switches

CAUTION


If the Crank Terminate Signal is absent, the engine starter motor will continue to operate. Shut the engine off immediately to avoid damaging the starter motor or the starter motor gears.

- b. If the crank terminate signal is not present, the engine can be started locally using the Local Starting Procedure in this section.
3. The engine continues to operate as long as the RUN signal is present. When the RUN signal is terminated by the fire pump controller, the engine stops immediately.
4. The engine may be stopped locally by pressing the and holding the STOP/RESET Rocker Switch until the engine stops.

5.4 Local Starting Procedure

The fire pump engine can be started locally from the operator control panel for testing and maintenance. To start the engine from the Operator Control Panel:

1. Place the ECM A/B Selector Switch in the desired operating position (ECM A is the normal position, ECM B is the alternate position). Refer to [Figure 5-2](#).



1. ECM Selector Panel
2. ECM A/B Selector Switch

Figure 5-2 ECM Selector Panel and Switch

IMPORTANT: *Never switch from ECM-A to ECM-B while the engine is running.*

2. Disengage the AUTO/MANUAL Mode Switch Locking Button.
3. Place the AUTO/MANUAL Mode Switch in the MANUAL position. Refer to [Figure 5-1](#).
4. Observe the battery voltages displayed on the engine instrument panel. Use the battery with the highest indicated voltage.
5. Press either the CRANK BATT A or CRANK BATT B Switch to start the engine.
 - a. Depress the selector switch for up to 15 seconds or until the engine starts. Repeat up to three times if necessary.

CAUTION

To prevent damage to the starter, do not engage the starting motor more than 15 seconds. Wait 15 seconds between each start attempt.

IMPORTANT: *If the engine does not start after three attempts, check the fuel supply system. Absence of blue or white exhaust smoke during cranking indicates no fuel is being delivered.*


NOTE: *Engines used in fire pumps or standby service are expected to accelerate from crank to full load within a short period of time.*

- b. Engine oil pressure must be indicated on the gauge within 15 seconds after starting.
6. Stop the engine locally by pressing and holding STOP/RESET Rocker Switch until the engine stops.

5.5 Emergency Starting Procedure

The engine starts automatically in the event of a fire emergency. However, if it fails to start automatically, the engine can be started locally. The following procedure outlines an Emergency Manual Mode Electrical Start.

1. Open both manual bypass valves in the raw water supply loop.
2. Place the ECM A/B Selector Switch into the desired operating position. Refer to [Figure 5-2](#).



1. Battery A Starter Contactor
2. Battery B Starter Contactor

Figure 5-3 Manual Starter Contactors

3. Disengage the AUTO/MANUAL Mode Switch Locking Button.
4. Place the AUTO/MANUAL Mode Switch on the Operator's Control Panel in the MANUAL position. Refer to [Figure 5-1](#).
5. Observe the battery voltages displayed on the engine instrument panel. Use the battery with the highest indicated voltage.
6. Press downward on either Battery A or Battery B Contactor Lever to start the engine. Refer to [Figure 5-3](#).
 - a. If Crank Solenoid Lever A does not engage the starter, repeat using Crank Solenoid Lever B.
 - b. Release the Contactor Lever immediately after the engine starts.



CAUTION

To prevent damage to the starter, do not engage the starting motor more than 15 seconds. Wait 15 seconds between each start attempt.

IMPORTANT: If the engine does not start after three attempts, check the fuel supply system. Absence of blue or white exhaust smoke during cranking indicates no fuel is being delivered.

7. Check that the engine starts and operates at rated speed.

Engine oil pressure must be indicated on the gauge within 15 seconds after starting.

8. The engine may be stopped locally by pressing the STOP/RESET Rocker Switch.

5.6 Engine Operating Speed

The Engine Operating Speed was factory set during manufacturing and test procedures. It may, however, be necessary to adjust the operating speed based on the fire pump application.

If the speed does not match the Engine RPM shown on the Factory Settings Plate, refer to [Section 6 - Maintenance](#) for adjustment procedures.

5.7 Overspeed Set Point

The Engine Overspeed Set Point was set during manufacturing and test procedures. It may, however, be necessary to adjust the overspeed set point based on the actual fire pump application. Refer to [Section 6 - Maintenance](#) for adjustment procedures.

5.8 Crank Terminate Set Point

The Crank Terminate Signal informs the pump controller that the engine has started and discontinues the pump controller crank signal. The crank terminate signal was factory set at the manufacturer. Refer to [Section 6 - Maintenance](#) for set point adjustment and testing procedures.


5.9 ECM Fault Code Lamps

The Electronic Control Module (ECM) can display and record operation irregularities, which are displayed as fault codes on the operator control panel. Fault codes can be read using the two ECM lamps on the operator instrument panel or with an Insite™ Diagnostic Reader. Refer to [Figure 5-4](#).

NOTE: Not all engine irregularities are shown as fault codes.

The AMBER engine warning lamp and the RED engine shutdown lamp serve three purposes:

1. An illuminated AMBER Lamp indicates an engine malfunction that requires timely operator attention. Refer to [Figure 5-5](#).




1. ECM Harness Connections
2. Electronic Control Module (ECM) A
3. Diagnostic Reader Plug-ins

Figure 5-4 ECM Diagnostic Reader Plug-ins

2. An illuminated RED Lamp indicates an engine malfunction that requires immediate and decisive operator response.
3. To flash out a 3-digit diagnostic fault code, which can then be used to help describe the nature of the engine malfunction. When either of the RED or AMBER lamps is illuminated, the fault code can be determined as follows:
 - a. The AUTO/MANUAL Mode Switch must be placed in the MANUAL position with the engine NOT running.
 - b. Open the operator control panel and place the Diagnostic ON/OFF Switch on the engine speed control panel in the ON position. Refer to [Figure 5-6](#).
 - c. The RED and AMBER Fault Code Lamps will immediately begin to flash the 3-digit diagnostic code.

The AMBER lamp will blink once to indicate the beginning of a 3-digit code.



1. High Coolant Temperature Warning Lamp
2. Low Oil Pressure Warning Lamp
3. Crank Battery A/B Momentary Start Switch
4. ECM Engine Shut Down Lamp (red)
5. ECM Warning Lamp (amber)
6. ECM A/B Indicator Lamps


Figure 5-5 Control Panel Indicator Lamps

For example: For a fault code of 241, the RED Lamp will blink 2 times to indicate the first digit, pause, blink 4 times to indicate the second digit, pause, then blink 1 time to indicate the third and final digit.

The AMBER lamp will then flash once, indicating the end of the three digit code.

4. If there is more than one fault code present, press the Speed Increase/Decrease Toggle Switch on the engine speed control panel to the INC position to proceed to the next 3-digit fault code. Refer to the Fault Code Chart in [Section 7 - Troubleshooting](#) to identify the 3-digit code.
5. If the Diagnostic ON/OFF Switch is placed in the ON position and both the RED and AMBER Lamps remain lit (do not flash), then there are no active fault codes present.

IMPORTANT: Return the Diagnostic ON/OFF Switch to the OFF position before attempting to start the engine.



1. Diagnostic ON/OFF Switch
2. Speed INC/DEC (Increase/Decrease) Switch

Figure 5-6 Engine Speed Control Panel

5.10 Isolated Acceptance Testing

The following tests demonstrate the MANUAL Local Start, operation, and shutdown of the fire pump from the engine's local Starter Solenoid Controls.

1. Demonstrate that the engine will not operate in the event of blown fuses or other faults in the local control panel.
2. Demonstrate manual engine speed control.
3. Demonstrate manual raw water valve operations to the engine cooling system.
4. Demonstrate the manual local start, operation, and shutdown of the fire pump from the operator's control panel.
5. Demonstrate that the engine starts, operates at speed, and stops in the event that the fire pump controller is not functioning.
6. Demonstrate the start of the fire pump engine using each battery set separately.
7. Demonstrate that the fire pump engine alternator operates while the engine is running.
8. Demonstrate that any customer supplied battery charging systems operate when the engine is not running.
9. Demonstrate engine start-up, operation, and shutdown of the engine with each of the redundant ECMs.
10. Check that engine fault codes are not being set during normal operations.

5.10.1 Integrated Acceptance Testing

The following tests outline integrated acceptance testing.

1. Demonstrate the start-up, operation, and shutdown of the fire pump engine in response to operations of the customer-installed fire pump controller. Perform this testing with the testing of the fire pump controller.
2. Demonstrate that the fire pump controller provides design indications and/or alarms for simulated engine oil pressure, water temperature, and overspeed faults.
3. Demonstrate the actual operation of the crank terminate output from the overspeed switch.
4. Participate in any flushing, pressure testing, flow testing, or capacity testing required for the fire protection system.
5. Complete the Cummins Fire Power Start-Up Inspection (SUI) Checklist. This is available on the Cummins Fire Power web site (www.CumminsFirePower.com).
6. When these items have been demonstrated, contact operating personnel responsible for fire protection system that engine is ready for service.



Section 6 - Maintenance

6.1 Introduction

Before performing maintenance procedures, read and understand the Safety Section of this manual. Improper performance or lack of critical information could result in personal injury or equipment damage.

Cummins encourages our customers to perform maintenance and repairs whenever necessary. However, servicing complex components within the normal warranty period may void the Cummins warranty and any specified warranty extended by the manufacturer of OEM products.

Cummins recommends that the engine be maintained according to the Maintenance Schedule in this Section.

Maintenance procedures should be performed by skilled technicians, who are familiar with the equipment, local regulations and service procedures for fire pump engine and pump systems. Improper maintenance can damage the engine, the fire pump or cause severe personal injury.

IMPORTANT: *If your engine is equipped with a component or accessory not manufactured by Cummins Inc, refer to the component manufacturer's Vendor supplied literature for specific maintenance recommendations.*

6.2 Engine Operation Report

The engine must be maintained in top mechanical condition if the operator is to get optimum satisfaction from its use. The maintenance department needs daily running reports from the operator to make necessary adjustments in the time allocated.

The weekly running report also helps to make provisions for more extensive maintenance, as the reports indicate the necessity.

Comparison and intelligent interpretation of the weekly report, along with a practical follow-up action, will eliminate most failures and emergency repairs. Report to the maintenance department any of the following conditions:

1. Low engine oil pressure
2. Low power
3. Power increases or engine surge
4. Erratic or no speed control or frequent shut-downs
5. Any warning lamps flashing or staying illuminated
6. Abnormal coolant or oil temperature
7. Unusual engine noise
8. Excessive smoke
9. Excessive use of coolant, fuel, or engine oil
10. Any fuel, raw water, engine coolant, or engine oil leaks
11. Loose or damaged parts
12. Worn or damaged belts

Maintenance Chart

Task	Period	Page
6.3 Weekly Maintenance	Weekly (40-60 Hrs)	6-4
6.3.1 General Walk Around Inspection	Weekly (40-60 Hrs)	6-4
6.3.2 Air Filter and Piping	Weekly (40-60 Hrs)	6-4
6.3.3 Cooling System	Weekly (40-60 Hrs)	6-4
6.3.4 Engine Oil System	Weekly (40-60 Hrs)	6-5
6.3.5 Fuel System Inspections	Weekly (40-60 Hrs)	6-6
6.3.6 Engine Exhaust System	Weekly (40-60 Hrs)	6-7
6.3.7 Electrical Supply and Controls	Weekly (40-60 Hrs)	6-7
6.3.8 Crankcase Breather Tube	Weekly (40-60 Hrs)	6-7
6.3.9 Clean Raw Water Strainers	Weekly (40-60 Hrs)	6-7
6.3.10 Check Battery Condition	Weekly (40-60 Hrs)	6-7
6.3.11 Engine Run Testing	Weekly (40-60 Hrs)	6-8
6.3.12 Engine Coolant Heater	Weekly (40-60 Hrs)	6-9
6.3.13 Check Antifreeze	Weekly (40-60 Hrs)	6-9
6.3.14 Air Cleaner Service Indicator	Weekly (40-60 Hrs)	6-9
6.4 Annual Maintenance	Annual (1000 Hrs)	6-10
6.4.1 Electrical Components	Annual (1000 Hrs)	6-10
6.4.2 Turbocharger Mounting Nuts	Annual (1000 Hrs)	6-11
6.4.3 Engine Mounting Bolts	Annual (1000 Hrs)	6-11
6.4.4 Inspect Fuel Pump	Annual (1000 Hrs)	6-11
6.4.5 Engine Oil and Oil Filter Change	Annual (1000 Hrs)	6-12
6.4.6 Change Fuel Filter or Filter Separator	Annual (1000 Hrs)	6-13
6.4.7 Output Shaft Lubrication	Annual (1000 Hrs)	6-14
6.4.8 Engine Operation Checks	Annual (1000 Hrs)	6-15
6.4.8.1 Crank Termination Set Point	Annual (1000 Hrs)	6-15
6.4.8.2 Engine Speed Calibration	Annual (1000 Hrs)	6-15
6.4.8.3 Overspeed Set Point Adjustment	Annual (1000 Hrs)	6-16
6.4.9 Coolant Pump Belt Inspection	Annual (1000 Hrs)	6-17
6.4.10 Coolant Pump Belt Tension	Annual (1000 Hrs)	6-17
6.4.11 Alternator Belt Inspection	Annual (1000 Hrs)	6-18
6.4.12 Alternator Belt Tension	Annual (1000 Hrs)	6-18
6.4.13 Heat Exchanger Pressure Test	Annual (1000 Hrs)	6-19
6.4.14 Turbocharger Inspection	Annual (1000 Hrs)	6-19
6.5 Every 2 Years or 2000 Hours	2 Years (2000 Hrs)	6-20
6.5.1 Coolant Pump Inspection	2 Years (2000 Hrs)	6-20
6.5.2 Drain and Flush Cooling System	2 Years (2000 Hrs)	6-20
6.6 Every 4 Years or 5000 Hours	4 Years (5000 Hrs)	6-22
6.6.1 Coolant Thermostat Removal/Installation	4 Years (5000 Hrs)	6-22
6.6.2 Coolant Pump Belt Replacement	4 Years (5000 Hrs)	6-23
6.6.3 Alternator Belt Replacement	4 Years (5000 Hrs)	6-24
6.6.4 Charge Air Cooler Heat Exchanger	4 Years (5000 Hrs)	6-25

NOTE: All maintenance and inspections intervals are accumulative. When performing annual maintenance, also perform maintenance listed under daily, weekly, monthly, and 3 month intervals.

Maintenance Record Form

[illegible]

6.3 Weekly Maintenance

When the engine is running, to be alert for mechanical problems that could create unsafe or hazardous conditions.

6.3.1 General Walk Around Inspection

The following areas should be inspected weekly to maintain safe and reliable operation.

1. Check fluid levels, oil pressure and coolant temperatures frequently. Most engine problems give an early warning.
 - a. Look and listen for changes in engine performance, sound, or appearance that will indicate that service or repair is needed. Be alert for misfires, vibration, excessive exhaust smoke, loss of power, or increases in oil or fuel consumption.
 - b. Check the engine appearance for excessive heat, wiring short circuits, excessive end-play, vibrations, excessive wear, excessive abrasion, damaged electrical wiring or loose electrical wiring.
 - c. Check the engine for odors of diesel fuel, burning rubber, electrical system failure, exhaust fumes or smoke.



WARNING

Engine fuel is highly flammable and represents an extreme hazard for fire or explosion when exposed to electrical sparks or open flame. Clean up spilled fuel immediately. Keep sources of electrical spark or open flame away from a fuel source.

6.3.2 Air Filter and Piping

1. The frequency of cleaning or replacing the air cleaner filter element is determined by the conditions in which the engine operates. Refer to [Figure 6-1](#). Visually inspect the air intake filter and piping daily for blockage, damage to piping, loose clamps, or punctures that can allow debris to enter the engine. Refer to [Figure 6-1](#).
 - a. Some serviceable filter elements can be cleaned and reused if not damaged.

NOTE: Cummins Inc. recommends using K&N Serviceable RC-3070.




Figure 6-1 Air Filter

- a. Check that the filter blockage indicator has not popped up, indicating a filter blockage.
 - b. Check for corrosion under the clamps and hoses of the intake system piping. Corrosion can allow corrosive products and dirt to enter the intake system. Disassemble and clean as required.
2. Replace damaged air filter or pipes, and tighten loose clamps, as necessary, to prevent the air system from leaking. Torque hose clamps to 8 N-m (72 in-lb).

6.3.3 Cooling System



CAUTION


Do not remove a pressure cap from a hot engine. Shut down the engine and wait until the coolant temperature is below 50° C (120° F) before removing the pressure cap. Heated coolant spray or steam can cause severe personal injury.



CAUTION

Never use a sealing additive to stop leaks in the cooling system. This can result in cooling system plugging and inadequate coolant flow, causing the engine to overheat.

1. Inspect the raw water piping, heat exchangers tanks, charge air cooling system, engine coolant hoses and hose clamps for loose fittings, leaks, holes, damage and corrosion.



1. Coolant Pressure/Fill Cap
2. Coolant Expansion Tank
3. Charge Air Cooler (CAC) Heat Exchanger
4. Raw Water Inlet Pipe
5. Coolant/Fuel Cooler Heat Exchanger
6. Raw Water Outlet Pipe
7. Coolant Level Sight Gauge

Figure 6-2 Heat Exchanger Tanks

- a. Tighten the hose clamps as necessary.
- b. Check for cracks, holes or other damage. Repair or replace as necessary.
2. With the coolant expansion tank at ambient temperature, press down, unscrew and remove the pressure/fill cap. Refer to [Figure 6-2](#).
 - a. Ensure that the coolant level is visible at the center of the coolant level sight gauge.
 - b. Add coolant as required. **DO NOT OVER-FILL!**

NOTE: Supplemental engine coolant should be a mixture of 50% ethylene glycol antifreeze and 50% water to avoid engine damage. Refer to Antifreeze information in [Section 6.5.2](#).

NOTE: Cummins recommends using Fleetguard® ES Compleat™ Ethylene-Glycol (EG) or Fleetguard® Propylene-Glycol (PG) Plus™ Antifreeze/Coolants. Both products are available in concentrated or pre-mixed formulations.

3. Drain a small amount of coolant from the return line petcock and inspect the coolant for excessive rust or particulate matter. Change the coolant more frequently if particles are present.

CAUTION

Do not mix coolant brands or chemical solutions, as this could damage the cooling system. Keep a record of the coolant concentration and manufacturer with the engine maintenance records.

4. Check for soft, overly pliant hoses, oxidation, and loose hose clamps. Torque hose clamps to 8 N-m (72 in-lb). Replace damaged hoses and clamps as required.
5. Check the coolant/fuel heat exchanger for leaks, damage, and dirt buildup. Clean and repair as required.

6.3.4 Engine Oil System


WARNING

Perform the specific checks in this section only after the engine is fully stopped. Unless tests require engine operation, disconnect the battery leads from the batteries (negative terminal first). Contact with exposed or moving components can cause severe personal injury.

CAUTION

Never operate the engine with the oil level below the L (low) mark or above the H (high) mark. Poor engine performance or engine damage can occur.

1. For accurate dipstick readings, shut off the engine and wait approximately 10 minutes to allow the oil in the upper portions of the engine to drain back into the crankcase.
2. Check the oil level at the engine dipstick. Refer to [Figure 6-3](#).
 - a. If the oil level is excessively high, refer to Oil Level Rises in [Section 7 - Troubleshooting](#).
 - b. If the oil level is greater than the high mark (H), drain excess oil and recheck the level.



1. Oil Filler Tube
2. Crankcase Breather Tube
3. Oil Level Dipstick

Figure 6-3 Engine Oil Dipstick

- c. If the oil levels are consistently below normal after a fill, check for leaks, loose or damaged gaskets, or oil in the coolant system. Troubleshoot per Engine Oil Consumption Excessive in [Section 7 - Troubleshooting](#).

3. If the oil level is below the low mark (L), add the equivalent type oil.

Keep the oil level as near as possible to the “full” mark on the dipstick by adding the same quality and brand of oil.


NOTE: Cummins recommends using Valvoline® Premium Blue S.A.E. 15W-40 Multi-viscosity Lubricating Oil or equivalent. Refer to the oil change interval and the procedures in [Section 6.4.5 Engine Oil and Oil Filter Change](#).

6.3.5 Fuel System Inspections



WARNING

Engine fuel is highly flammable and represents an extreme hazard for fire or explosion when exposed to electrical sparks or open flame. Clean up spilled fuel immediately. Keep sources of electrical spark or open flame away from a fuel source.



1. Fuel Filter/Water Separator Canister
2. Drain Valve

Figure 6-4 Engine Fuel Filter/Water Separator

1. Shut off the engine.
2. Inspect the fuel supply line, return line, filter and fittings for cracks or abrasions.
 - a. Ensure the lines are not rubbing against anything that could damage the fuel system hoses. Repair any leaks or alter line routing to eliminate wear immediately.
 - b. Relieve fuel line pressure by carefully loosening the fuel inlet line.
3. Drain the Fuel Filter/Water Separator.

NOTE: A Water Separator must be integrated into the fuel delivery system of the fire pump engine. A Fuel Filter/Water Separator may be installed directly on the unit in the primary fuel filter location, or a separate filter/separator may be installed in the fuel delivery system near the fire pump engine assembly.

- a. Open the drain valve: Turn the valve counter-clockwise approximately 3-1/2 turns until the valve drops down 25.4 mm (1 in.) and draining occurs. Drain the Fuel Filter/Water Separator until clear fuel is visible. Refer to [Figure 6-4](#).
- b. Close the drain valve: Lift the valve and turn it clockwise until it is hand-tight. Do not over-tighten the valve. Overtightening can damage the threads.

- c. Dispose of the contaminated fuel in accordance with local environmental regulations.

NOTE: Cummins recommends using Fleetguard (Cummins) fuel filter/water separator FS1041 or equivalent in the primary fuel filter location.

6.3.6 Engine Exhaust System

With the engine operating, inspect the entire exhaust system including the exhaust manifold, exhaust flex pipe, muffler and piping.

Check for leaks at all connections, welds, gaskets and joints, and make sure that the exhaust pipes are not heating surrounding areas excessively. Repair any leaks immediately.

6.3.7 Electrical Supply and Controls

Check the terminals on the starting batteries for clean and tight connections. Loose or corroded connections create resistance which can hinder starting.


6.3.8 Crankcase Breather Tube

1. Inspect the crankcase breather tube for a worn or damaged hose, sludge, blockage, or dirt buildup. Refer to [Figure 6-3](#).
2. Clean the breather tube if obstructed or blocked. Replace worn or damaged hose as required.

6.3.9 Clean Raw Water Strainers

Each raw water strainer (one on the normal line and one on the bypass line) is part of the raw water pressure regulator/strainer assembly and should be cleaned weekly, to remove sediment. Refer to [Figure 6-5](#).

1. Ensure that the bypass raw water line valves are closed and the normal raw water line valves are open.
2. For each raw water strainer, remove the plug.
3. Inspect and remove any debris.
4. Install the strainer plug.



1. Bypass Pressure Regulator/Strainer
2. Bypass Raw Water Line
3. Normal Pressure Regulator/Strainer
4. Normal Raw Water Line

Figure 6-5 Raw Water Strainers

6.3.10 Check Battery Condition

Weak or undercharged starting batteries are the most common cause of standby power system failures. Even when kept fully charged and maintained, lead-acid starting batteries are subject to deterioration over time and must be periodically replaced when they no longer hold a proper charge.

Only a regular schedule of inspection and testing under load can prevent engine starting problems. Use a manual battery load tester to verify the condition of each starting battery. Inspect the condition of the batteries, the electrical cables and the engine ground lug. Refer to [Figure 6-6](#).




CAUTION

Batteries can emit explosive gases during charging. To reduce the possibility of personal injury, always ventilate the battery compartment before servicing the batteries.



CAUTION

To reduce the possibility of arcing, remove the negative (-) battery cable first and attach the negative (-) battery cable last.



1. Battery Cell Covers
2. Negative Battery Terminal
3. Positive Battery Terminal

Figure 6-6 24 VDC Series Battery Connection

1. Keep the batteries clean by wiping them with a damp cloth whenever dirt appears excessive. Refer to [Figure 6-6](#).
2. Use a battery hydrometer to check the specific gravity of the electrolyte in each battery cell. A fully charged battery will have a specific gravity of 1.260. Charge the battery if the specific gravity reading is below 1.215.
3. Check battery wiring and cable connections for loose, corroded, worn or damaged cables. Include both connectors at the alternator, battery connections and engine grounding lug (near starter motor).
 - a. If the battery cables are corroded, remove the battery cable clamps, starting with the negative (-) battery cable.
 - b. Use fine emery cloth or a wire brush to clean the cable clamps and battery cables. The metal should be shiny.
 - c. Wash the battery terminals with a solution of baking soda and water (1/4 lb. baking soda to one quart of water).
 - d. Be careful to prevent the solution from entering the battery cells, and flush the batteries with clean water when done.

- e. After cleaning the connections, coat the terminals with a light application of petroleum jelly.
- f. Reinstall the positive (+) battery cable first followed by the negative (-) battery cable. Tighten the cable clamps.



WARNING

Battery electrolyte (sulfuric acid) is highly caustic and can burn clothing, the skin or cause blindness. Wear protective clothing, impervious neoprene gloves, safety goggles or full-face shield, when working with the batteries.

4. Check the electrolyte level in the batteries monthly. If low, fill the battery cells to the bottom of the filler neck with distilled water.
5. Check for continuity between terminals using a digital multimeter or other test equipment. Check also the insulation resistance to ground. Correct any electrical faults.

Continuity should be in the single digit ohms or less. Resistance to ground should be in the mega-ohm range. Refer to the Vendor supplied literature for additional information.

6.3.11 Engine Test Run

Fire pump engines on continuous standby must be able to go from a cold start to being fully-operational in a matter of seconds. This can impose a severe burden on engine parts. The engine normally starts automatically in an emergency situation, upon receipt of the start command from the fire pump controller.

Regular operation keeps engine parts lubricated, prevents oxidation of electrical contacts, uses up fuel before it deteriorates, and, in general, helps provide reliable engine starting.

1. Start at least once a week for a minimum of 30 minutes with as much load as possible. Periods of no-load operation should be held to a minimum, because unburned fuel tends to accumulate in the exhaust system.
2. Refer to the instructions in [Section 5 - Operation](#).
3. Check that the engine starts and operates at the recommended fire pump speed specification.

4. Engine oil pressure must be indicated on the gauge within 15 seconds after starting.
5. Run the engine no less than 30 minutes to attain normal running temperature. Observe that the engine is operating at proper operating speed.
6. Check unusual engine noise. Listen for any unusual engine noise which can indicate that service is required.
7. Ensure oil pressure is greater than 10 PSI.
8. Check coolant temperature is between 70° C (158° F) and 107° C (225° F).
9. Check that both battery voltmeters indicate 24 VDC.
10. Check that the inlet air restriction indicator has not popped-up; indicating an air filter blockage. Replace the air filter as required.
11. Shut off the engine by pressing and holding the RESET/STOP Switch until the engine stops.
12. When finished, set the AUTO/MANUAL Mode Switch to AUTO.

6.3.12 Engine Coolant Heater

NOTE: Perform this inspection procedure 24 hours after shutting off the engine.




Figure 6-7 Engine Heater

The engine coolant heater must maintain an engine coolant temperature of 49° C (120° F) or above. The engine block must be warm to the touch in the water jacket areas. Refer to [Figure 6-7](#).

If the heater does not appear to be working correctly, contact a Cummins Authorized Repair Location.

6.3.13 Check Antifreeze

Antifreeze is essential in any climate. It broadens the operating temperature range by lowering the coolant freezing point and raising its boiling point. The corrosion inhibitors also protect the cooling system components from corrosion and provide longer component life.



CAUTION

Coolant is toxic. Avoid prolonged and repeated skin contact with used antifreeze - wash thoroughly after contact. Prolonged, repeated contact can cause skin disorders. Dispose of waste antifreeze in accordance with local environmental regulations.



CAUTION

Over concentration of antifreeze or use of high-silicate antifreeze can damage the engine. Do not use more than 50% antifreeze in the mixture unless additional freeze protection is required. Antifreeze at 68% concentration provides the maximum freeze protection, and must never be exceeded under any condition. Antifreeze protection decreases above 68%.

1. Check the antifreeze concentration using a refractometer (such as Fleetguard® Part No. CC2800).
 - a. At least twice per year.
 - b. At every subsequent oil drain interval, if the concentration is above 3 units.
 - c. Whenever coolant is added to the cooling system between filter changes.

IMPORTANT: Floating-ball type density testers or hydrometers are not accurate enough for use with heavy-duty diesel cooling systems.

6.3.14 Air Cleaner Service Indicator

Turbocharged engines must be operated at rated RPM and full load to check maximum intake air restriction. Clean or replace the air filter element per the manufacturer's recommendation as required.

CAUTION

Never operate the engine without an air cleaner. Intake air must be filtered to prevent dirt and debris from entering the engine and causing premature wear. Dirt or foreign objects could cause engine damage. Contact with exposed or moving components can cause personal injury.

IMPORTANT: Maximum intake air restriction is 762 mm H₂O (25.0 in H₂O) for turbocharged engines.

NOTE: Follow the manufacturer's instructions when cleaning or replacing the air cleaner element. Do not remove the felt washer from the indicator. The felt washer absorbs moisture.

1. The air cleaner service indicator is actuated when excessive air restriction has occurred at the air cleaner. Refer to [Figure 6-8](#).
 - a. If the red indicator flag is at the raised position in the window, clean or replace the air filter per the manufacturer's recommendation as required.

NOTE: Cummins recommends using K&N Serviceable/Disposable Air Cleaner Element RC-3070.

- b. After the air cleaner has been serviced, push the flag IN, to reset the service indicator.




Figure 6-8 Air Cleaner Service Indicator

6.4 Annual Maintenance

All checks or inspections listed under previous maintenance intervals must also be performed at this time, in addition to those listed under this maintenance interval.

6.4.1 Electrical Components


CAUTION

AVOID SERVICING complex components such as: ECM controllers, printed circuit boards, and, programmable controllers, not specifically authorized by the manufacturer. Contact the local Cummins Authorized Repair Location before performing any extensive maintenance.

CAUTION

To reduce the possibility of arcing, remove the negative (-) battery cable first and attach the negative (-) battery cable last.

1. Remove the battery terminal cables, starting with the (-) negative cable first.
2. Inspect the electrical wiring harness, terminal panels, and electrical plug-ins, for secure, clean electrical contacts, worn or damaged insulation, burnt wires, broken wires and loose connections. Refer to [Figure 6-9](#).



1. ECM A
2. ECM B
3. Operator's Control Panel
4. ECM Selector Panel and Switch

Figure 6-9 Electrical Control Modules

- Clean and tighten any loose electrical connections.
- Replace worn, damaged, burnt or poorly insulated wiring immediately.
- Refer to the OEM Vendor supplied literature for recommended maintenance procedures.


IMPORTANT: Solid state or sealed electrical components have no user serviceable parts. Contact your local Cummins Authorized Repair Location for additional information.

- Repair or replace damaged components using recommended Recon® or Cummins service parts only. Refer to [Section 8 - Component Parts and Assemblies](#) or contact a Cummins Authorized Repair Location.
- Inspect electrical terminal connectors on the instrument panel for burnt, loose, damaged or broken contacts.
 - Inspect the function of all gauges, voltmeters, switches, warning lamps and circuit breakers. Replace panel components, breakers and warning lamps as required.

6.4.2 Turbocharger Mounting Nuts


Check the turbocharger mounting bolts. Refer to [Figure 6-10](#).

Torque the mounting nuts to 65 -m (50 ft-lb).



- Filtered Intake Air Pipe to Turbocharger
- Turbocharger Mounting Nuts (4)
- Exhaust Manifold
- Turbocharger

Figure 6-10 Turbocharger



- Engine Mounting Bracket
- Flywheel Housing

Figure 6-11 Engine Mounting Bracket

6.4.3 Engine Mounting Bolts




CAUTION
Loose engine mount bolts or damaged brackets can cause engine misalignment or excessive vibration. These conditions can cause engine or pump damage.

- Inspect all engine mounts for cracks or loose bolts. Refer to [Figure 6-11](#).
- Check the torque on the engine mounting bolts. Torque the support bracket to engine mounting cap screws to 244 N-m (180 ft-lb).

6.4.4 Inspect Fuel Pump

- Inspect the fuel injection pump mounting nuts, including the support bracket, for loose or damaged hardware. Refer to [Figure 6-12](#). Inspect the fuel lines and hoses for wear damage, loose fittings and leaks. Repair or replace damaged lines and hoses as required.



1. Fuel Return Hose
2. Fuel Supply Hose
3. Lift Pump
4. Fuel Filter or Filter/Separator Canister
5. Fuel Cooling Line From Heat Exchanger
6. Fuel Cooling Line To Heat Exchanger

Figure 6-12 Fuel Pumps, Filter, Lines and Hoses

6.4.5 Engine Oil and Oil Filter Change

Engine oil becomes contaminated and essential oil additives are depleted with use. The amount of contamination is related to the total amount of fuel and oil consumed. Change the oil at least once annually.

NOTE: For composite oil pans, always use a new sealing washer on the oil drain plug. Hold the external locking nut in place while tightening the oil drain plug.

1. Change the oil and the oil filter to remove the contaminants suspended in the oil.



WARNING

To reduce the possibility of personal injury, avoid direct contact of hot oil with your skin. Some state and federal agencies have determined that used engine oil can be carcinogenic. Prolonged, repeated contact can cause skin disorders or other bodily injury. Wash thoroughly after contact. Avoid inhalation of vapors, and ingestion of used engine oil. Dispose of the oil in accordance with local environmental regulations.




Figure 6-13 Oil Pan Drain Plug (right side shown)

IMPORTANT: If the engine oil is drained from the oil pan to make an engine repair, new oil must be used. Do not use oil that has been drained from the oil pan.

NOTE: Cummins does not recommend exceeding 600 hours on oil change intervals.

2. Operate the engine until the coolant temperature reaches 70° C (158° F). Shut the engine off.
3. Place an appropriate container under the oil pan drain plug. For improved access, the unit has a drain plug located on each side of the unit. Refer to [Figure 6-13](#).

The CFP15E engine models have a 13 gal oil capacity (48 - 52 qts (47 - 49 liters)).

4. Remove the oil drain plug and drain the oil immediately to make sure all the oil and suspended contaminants are removed from the engine.
5. Remove the oil filter. Refer to [Figure 6-14](#).
 - a. Clean the area around the oil filter canister.
 - b. Use a filter wrench to remove the filter.
 - c. Remove and discard the O-ring seal if it has remained attached to the mounting flange. Clean the filter, mounting flange with a clean lint-free cloth.
 - d. Apply a light film of 15W-40 lubricating oil to the replacement filter gasket before installing the filter.




Figure 6-14 Oil Filter Canister

6. Fill the oil filter with a high-quality 15W-40 multi-viscosity lubricating oil, such as Cummins Premium Blue®, or its equivalent.
7. Center the filter ring on the threaded mounting nipple. Screw the filter canister onto the mounting flange until the gasket is snug against the mounting flange. Then tighten an additional 1/4 turn.

! CAUTION


Mechanical over tightening can distort the threads or damage the filter element seal.

NOTE: Cummins recommends using Fleetguard Lube Oil Filter LF9000.

8. Check and clean the oil pan drain plug threads and sealing surface. Install the oil pan drain plug. Torque the plug to 50 N-m (37 ft-lb).
9. Add a high-quality 15W-40 multi-viscosity lubricating oil, such as Cummins Premium Blue®, or its equivalent.
10. Fill the engine to the proper level with clean oil at the fill port. Refer to [Figure 6-15](#).

The CFP15E engine models have a 13 gal oil capacity (48 - 52 qts (47 - 49 liters)).

NOTE: Capacities assume standard pan. Total system assumes standard pan plus filter.



1. Oil Level Dipstick
2. Oil Fill Port

Figure 6-15 Oil Fill Port and Oil Level Dipstick

! CAUTION

If no oil pressure is noted within 15 seconds after the engine is started, shut down the engine to reduce the possibility of internal damage.

11. Stop the engine.
12. Wait approximately 15 minutes to let the oil drain from the upper parts of the engine.
13. Check the oil level again. Add oil as necessary to bring the oil level to the H (high) mark on the dipstick. Refer to [Figure 6-15](#).


6.4.6 Change Fuel Filter or Filter Separator

! WARNING

Engine fuel is highly flammable and represents an extreme hazard for fire or explosion when exposed to electrical sparks or open flame. Clean up spilled fuel immediately. Keep sources of electrical spark or open flame away from fuel source.

! WARNING

Do not open the fuel filter/water separator drain valve or dismantle the fuel lines on the high-pressure fuel system with the engine running. High pressure fuel spray from an operating engine can cause serious personal injury, fire hazard or fatality.



1. Fuel Return Hose
2. Fuel Supply Hose
3. Lift Pump
4. Fuel Filter or Filter/Separator Canister
5. Fuel Cooling Line From Heat Exchanger
6. Fuel Cooling Line To Heat Exchanger

Figure 6-16 Engine Fuel Filter or Filter/Separator

1. Shut off the engine.
2. Close any fuel valves (if equipped) to prevent fuel from draining or siphoning.
3. Clean the area around the fuel filter head.
4. Remove the spent filter canister using a filter wrench. Refer to [Figure 6-16](#).
5. Clean the filter mounting head surface of sludge buildup and foreign particles. Ensure mating gasket surfaces are clean.
6. Lubricate the gasket seal with clean S.A.E. 15W-40 lubricating oil.

NOTE: Cummins recommends using Fleetguard (Cummins) fuel filter/water separator FS1041 or equivalent in the primary fuel filter location.

7. Center the filter on the threaded mounting stud. Screw the filter canister onto the mounting stud until the gasket is snug against the mounting flange, then tighten an additional 1/4 turn.

CAUTION

Mechanical over tightening can distort the threads or damage the filter element seal.

8. Open the fuel supply valves (if equipped).
9. Press either the CRANK BATT A or CRANK BATT B Switch to start the engine.
10. Depress the selector switch for up to 15 seconds or until the engine starts. Repeat up to three times, if necessary.

CAUTION

To prevent damage to the starter, do not engage the starting motor more than 15 seconds. Wait 15 seconds between each start attempt.

IMPORTANT: If the engine does not start after three attempts, check the fuel supply system. Absence of blue or white exhaust smoke during cranking indicates no fuel is being delivered.

NOTE: Engines used in fire pumps or standby service, are expected to immediately ramp accelerate from crank to full load.

6.4.7 Output Shaft Lubrication

It is recommended that proper lubrication to drive shafts and output shafts is to be completed on a regular schedule.

1. Remove the output shaft guards.




Figure 6-17 Drive Coupling Grease Fittings

2. Wipe the grease fittings and grease gun nozzle with a clean cloth to avoid contamination.
3. Add grease to the universal joint grease fittings. Refer to [Figure 6-17](#).

NOTE: Cummins, Inc recommends using a good quality semi-synthetic, molybdenum-fortified NLGI #2 lithium complex grease which protects from -54° to 400° F such as Valvoline Durablend®.

4. Wipe excess grease from the grease fittings.



WARNING

Before equipment operation, ALL guards, covers and protective devices MUST BE in place and securely fastened. Serious personal injury could result from contact with exposed or moving components.

6.4.8 Engine Operation Checks

The following service procedures ensure that the engine starts and operates properly under normal conditions.

6.4.8.1 Crank Termination Set Point


The Speedswitch Crank Termination Set Point is factory set at 650 rpm, and should not be changed from this value. Refer to [Figure 6-18](#).

If the crank termination set point must be set, proceed as follows:

1. Open the engine control panel and remove the crank terminate potentiometer cover.

There will be 2 potentiometers visible. The Crank Terminate Potentiometer is the upper one.

2. This is a 30-turn potentiometer. The Crank Terminate Potentiometer must be set to 14 turns clockwise.
3. To ensure that the potentiometer is set at 0 turns: Rotate the potentiometer 30 turns counterclockwise. The potentiometer will not be damaged by turning it past its zero-point.
4. After setting the Crank Terminate Potentiometer at 0 turns, turn the potentiometer 14 turns clockwise.



1. Spring Clamp Terminal Blocks
2. Speed Increase/Decrease Toggle Switch
3. RESET Button
4. TEST Button
5. Diagnostic ON/OFF Toggle Switch
6. CRANK Termination or Run Signal Indicator LED (factory use only)
7. Overspeed Indicator LED
8. Pre-wired Terminals
9. Crank Terminate Potentiometer Cover
10. Overspeed Potentiometer Cover

Figure 6-18 Engine Overspeed Control Module

5. Replace the cover. The Crank Terminate Potentiometer is now set at approximately 650 rpm.

6.4.8.2 Engine Speed Calibration

If the speed does not match the Engine RPM shown on the Factory Settings Plate, use the following method to set the engine speed using the INC/DEC Speed Switch on the engine speed control panel.

1. Remove the cap screw from the operator's control face plate, allowing the face plate to gently drop down supported by the hinge.
2. Start the engine using the local start method.
3. Observe that the engine starts and accelerates to the speed set point listed on the Factory Settings Plate.

-
4. Monitor engine speed on the tachometer. Record the observed engine speed.

If the speed does not ramp up to the setting shown on the Factory Settings Plate, the engine operating speed set point must be calibrated.

5. Move the INC/DEC Speed Switch to the required INC (increase) or DEC (decrease) pole position. Refer to [Figure 6-18](#).

NOTE: Each time the Speed INCREASE/DECREASE Toggle Switch is briefly moved to the minus (-) position, the idle speed is decreased by 10 RPM. When the switch is briefly moved to the plus (+) position, the idle speed is increased by 10 RPM. Holding the toggle switch in either the INC or DEC position ramps the engine speed in the selected direction.

- a. To increase the speed, move the INC/DEC Speed Switch to the INC position until the rated speed is reached. Refer to [Figure 6-18](#).
- b. To decrease the speed, move the INC/DEC Speed Switch to the DEC position until the rated speed is reached.

6. Stop the engine.

7. Start the engine.

8. Observe that the engine starts and accelerates to the rated speed set point.

9. The engine speed set point calibration is required for both the ECM A and ECM B sub-systems.

10. Repeat steps 2 through 8 while the ECM selector switch is set to ECM B.

11. Close the panel and tighten the enclosure cap screw to secure the panel face.

IMPORTANT: Never switch from ECM A to ECM B while the engine is running.

6.4.8.3 Overspeed Set Point Adjustment

The Engine Overspeed Set Point was set by Cummins Firepower during manufacturing and test procedures. It may be necessary to adjust the overspeed set point based on the actual fire pump application.

1. Open the engine instrument panel and remove the Overspeed Potentiometer Cover. Refer to [Figure 6-18](#).

2. Place the engine in the MANUAL position by switching the MANUAL/AUTO Mode Switch to the MANUAL position.

NOTE: The Test Button reduces the actual overspeed set point by a value of 20%.

3. Start the engine and adjust the engine speed to the system design pump speed. Refer to [Section 6.4.8.2 Engine Speed Calibration](#) for additional information.

4. Press and hold the test button. If the engine remains running, slowly turn the Over Speed Potentiometer counterclockwise until the engine stops. Remember to keep the test button depressed during this adjustment procedure. The speed switch is now set for the correct overspeed RPM.

NOTE: Turning the potentiometer clockwise raises the set speed and counterclockwise lowers the set speed.

5. Press the Reset button on the speed switch or front panel so the engine can be restarted.

IMPORTANT: The final pump speed is typically set while the pump is flowing 150%.

Alternate Overspeed Set Point Adjustment procedure (without the test button)

1. Remove the drive-shaft or stub-shaft coupling to prevent overspeeding the pump. Refer to appropriate driveline drawings in [Section 8 - Component Parts and Assemblies](#).

2. Open the engine instrument panel and remove the Overspeed Potentiometer Cover. Refer to [Figure 6-18](#).

3. Place the engine in MANUAL position by switching the MANUAL/AUTO Switch to the MANUAL position.

4. Calculate the actual overspeed setting.

- a. Determine required pump speed (example: 1760 RPM).

- b. Calculate actual overspeed setting
(example: $1760 \times 120\% = 2112$ RPM).


5. Start the engine and adjust the engine speed to the calculated overspeed. (2112 RPM in the example above). Refer to Section [6.4.8.2 Engine Speed Calibration](#) for additional information.
6. If the engine remains running, slowly turn the Over Speed Potentiometer counterclockwise until the engine stops. The speed switch is now set for the correct overspeed RPM.

NOTE: Turning the potentiometer clockwise raises the set speed and counterclockwise lowers the set speed.

7. Press the Reset button on the speed switch or front panel so the engine can be restarted.
8. Readjust the engine speed to the proper pump speed (1760 RPM in the example above).
9. Reconnect the pump drive-shaft or stub-shaft coupling. Refer to appropriate driveline drawings in [Section 8 - Component Parts and Assemblies](#).

IMPORTANT: The final pump speed is typically set while the pump is flowing 150%.

6.4.9 Coolant Pump Belt Inspection



1. Coolant Pump
2. Coolant Pump Drive Belt
3. Tensioner Arm

Figure 6-19 Coolant Pump Drive Belt



CAUTION

Belt damage can be caused by, incorrect tension, incorrect size or length, pulley misalignment, incorrect installation, severe operating environment and oil or grease on the belt surface or pulley.

1. Place the AUTO/MANUAL Mode Switch in the MANUAL position.
2. Disconnect both batteries at their terminals. Remove (-) negative cable first. Install the (-) negative cable last.



CAUTION

Disconnect both batteries (negative cable first) before performing service on the Fire Pump Engine or on any of its controls.

3. Remove the belt guard bolts and the belt guard. Set aside for later installation.
4. Visually inspect the Coolant Pump Belt for frayed, worn, missing pieces or cracked belt surfaces. Check the belt for intersecting cracks. Refer to [Figure 6-19](#).

NOTE: Transverse cracks (across the belt width) are acceptable. Longitudinal cracks (direction of belt length) that intersect with transverse cracks are not acceptable. Replace the belt if it is cracked, frayed or has pieces of material missing.

5. If the belt condition is acceptable, check the coolant pump belt tension.

NOTE: Belts with glazed or shiny surfaces indicates belt slippage. Correctly installed and tensioned belts will show even pulley and belt wear.

6.4.10 Coolant Pump Belt Tension

Use the following procedure to properly tension the poly-vee, coolant pump belt.

1. Check the coolant pump belt tension. Refer to [Figure 6-19](#).
2. Use the Cummins belt tension gauge, Part No. 3822524, to measure the tension in the coolant pump drive belt.

- a. Measure the belt tension in the center span of the coolant pump belt pulleys.
- b. Belt tension should be between 360 to 490 N-m (266 to 361 ft-lb).

NOTE: The belt must not touch the bottom of the pulley grooves nor protrude more than 3 mm (3/32 in) above the top of the groove.

3. Verify that the tensioner arm stop is not in contact with the spring casing stop. If either stop is touching, the tensioner must be replaced.
 4. Inspect the tensioner for evidence of the tensioner arm contacting the tensioner cap. If there is evidence of the two areas making contact, the pivot tube bushing has failed and the tensioner must be replaced.
 5. Check the tensioner arm, pulley, and stops for cracks. If any cracks are noted, the tensioner must be replaced.
 6. Use a 3/8" drive ratchet or breaker bar to rotate the tensioner slowly away from the belt.
- If the arm rotates with any roughness or hesitancy, replace the tensioner.
7. Check the belt tensioner cap screw torque. The screw should be torqued to 43 N-m (32 ft-lb).
 8. With the belt guard still removed, perform the alternator belt inspection.

6.4.11 Alternator Belt Inspection




CAUTION

Belt damage can be caused by, incorrect tension, incorrect size or length, pulley misalignment, incorrect installation, severe operating environment and oil or grease on the belt surface or pulley.



CAUTION

Disconnect both batteries (negative cable first) before performing service on the Fire Pump Engine or on any of its controls.



1. Alternator Drive Belt
2. Idler Pulley
3. Tensioner Arm
4. Alternator

Figure 6-20 Alternator Drive Belt

1. Visually inspect the alternator belt for frayed, worn, missing pieces or cracked belt surfaces. Check the belt for intersecting cracks. Refer to and [Figure 6-20](#).

NOTE: Transverse cracks (across the belt width) are acceptable. Longitudinal cracks (direction of belt length) that intersect with transverse cracks are not acceptable. Replace the alternator belt if it is cracked, frayed or has pieces of material missing.

2. If the belt condition is acceptable, check the belt tension.

NOTE: Belts with glazed or shiny surfaces indicates belt slippage. Correctly installed and tensioned belts will show even pulley and belt wear.

6.4.12 Alternator Belt Tension

An automatic tensioning arm controls the alternator belt tension. The belt-driven coolant pump drives the alternator using a belt, automatic tensioner, and idler pulley.



CAUTION

Disconnect both batteries (negative cable first) before performing service on the Fire Pump Engine or on any of its controls.

1. Determine the belt tension using Cummins belt tensioner gauge, Part No. 3822524, to measure drive belt tension. Belt tension should be in the range of, 360 to 490 N-m (266 to 361 ft-lb) at the center of the shaft span.

NOTE: *The belt must not touch the bottom of the pulley grooves nor protrude more than 3 mm (3/32 in) above the top of the groove.*

2. Verify that the tensioner arm stop is not in contact with the spring casing stop. If either stop is touching, the tensioner must be replaced.
3. Inspect the tensioner for evidence of the tensioner arm contacting the tensioner cap. If there is evidence of the two areas making contact, the pivot tube bushing has failed and the tensioner must be replaced.
4. Check the tensioner arm, pulley, and stops for cracks. If any cracks are noted, the tensioner must be replaced.
5. Use a breaker bar with a 3/8" ratchet to rotate the tensioner slowly away from the belt.

If the arm rotates with any roughness or hesitancy, replace the tensioner. Torque the tensioner arm to 43 N-m (32 ft-lb).

6. Check the belt tensioner cap screw torque. The screw should be torqued to 43 N-m (32 ft-lb).

6.4.13 Heat Exchanger Pressure Test

NOTE: *This test is required if internal leakage in either the charge air cooler (CAC) heat exchanger or coolant/fuel heat exchanger is suspected. It may be performed prior to the removal from the engine.*

NOTE: *Use Teflon tape or other pipe sealant when installing the test setup in order to prevent leaks.*

1. Install a 1-1/2" tubing adapter at the raw water outlet of the heat exchanger.
2. Install a pressure test setup with 700 kPa (100 psi) pressure gauge at the 1-1/4" tubing adapter raw water inlet to the heat exchanger.
3. Apply air pressure at 414 kPa (60 psig).
 - a. Isolate the pressure source and monitor the pressure gauge for 5 minutes.
 - b. There should be no change in pressure for the duration of the test.
4. After testing, release the pressure. Remove the tubing adapters, plug and the test equipment.
5. If leakage is detected, the heat exchanger must be replaced.


6.4.14 Turbocharger Inspection

1. Visually inspect the air filter and piping for dirt buildup, blockage, wear points, soft hoses, loose clamps, or punctures. Refer to [Figure 6-21](#).

Replace damaged air filter or pipes, and tighten loose clamps, as necessary, to prevent the air system from leaking.

2. Check that the air filter pop-up service indicator has not indicated a filter blockage. Clean or replace blocked filters.
3. Check for corrosion under the clamps and hoses of the intake system piping. Corrosion can allow foreign particles and dirt to enter the intake system.

Disassemble and clean, as required.
4. Remove the air intake and the exhaust piping.



CFP-147

1. Filtered Air Plumbing to Turbocharger
2. Turbocharger
3. Air Pipe to Charge Air Cooler
4. Air Pipe to Exhaust Flex Connection


Figure 6-21 Turbocharger Connections

5. Remove the exhaust pipe from the turbocharger.
6. Inspect the turbocharger turbine wheel for cracks in the housing or turbine blades, missing blades, mechanical binding, eccentric motion or excessive end-play. Refer to [Figure 6-22](#).

Replace the turbocharger if damage excessive end-play, binding, wear or eccentric motion is found. Contact a Cummins Authorized Repair Location for replacement.

IMPORTANT: *The turbocharger must be removed for replacement or rebuild, if the clearance is beyond the limits, the housing is cracked or the turbine wheel is damaged.*

7. Reinstall the air intake filter and the exhaust piping. Tighten the clamps. Torque loosened clamps to 8 N-m (72 in-lb).



CFP-048

1. Turbocharger Turbine Wheel
2. Turbocharger Intake Housing
3. Air Intake Tube and Clamp

Figure 6-22 Turbocharger Turbine Wheel

6.5 Every 2 Years or 2000 Hours

All checks or inspections listed under daily or previous maintenance intervals must also be performed at this time, in addition to those listed under this maintenance interval.

6.5.1 Coolant Pump Inspection

1. Inspect the Coolant pump for eccentric motion, mechanical binding, excessive end play, seal damage and grease or coolant leakage around the pump shaft.
2. Replace with a new or rebuilt, pre-lubricated unit as necessary. Contact a Cummins Authorized Repair Location for replacement.


6.5.2 Drain and Flush Cooling System

The cooling system must be clean to work properly. If the system shows excessive mineral buildup, particulate matter, scale, oxidation or oil contamination, drain and flush the cooling system. If the coolant is excessively dirty or is mixed with oil, contact a Cummins Authorized Repair Facility.

WARNING

Do not remove the pressure cap from a hot engine. Shut down the engine and wait until the coolant temperature is below 50° C (120° F) before removing the pressure cap. Heated coolant spray or steam can cause severe personal injury.

1. Press down, unscrew and remove the pressure/fill cap. The cap must be removed to allow air to vent the cooling system during the draining process.
2. Disconnect the engine heater power supply before draining the cooling system. Refer to [Figure 6-23](#).
3. Place a container that will hold at least 15 gallons of liquid, under the engine heater coolant hose. Refer to [Figure 6-23](#).
4. Disconnect either end of the engine heater coolant hose and allow the coolant to drain into the waste container. Refer to [Figure 6-23](#).
5. Flush with clean fresh water or heavy-duty heat exchanger cleaner. Follow the manufacturer's directions on the product container.




1. Engine Heater
2. Engine Heater Coolant Hose
3. Coolant Filter
4. Lower Coolant Hose

Figure 6-23 Engine Coolant Drains

NOTE: Some cooling system cleaners or commercial solvents require a soapy water rinse after use. Follow the directions on the cleaning solution or solvent.

6. When the flushing water has fully drained, use a filter wrench to remove the coolant filter from the filter housing.
 - a. Clean the filter housing gasket mount of dirt buildup, oxidation or particulate matter with a clean cloth. Refer to [Figure 6-24](#).



CFP9-037

Figure 6-24 Filter Housing Gasket Mount

- b. Coat the replacement filter gasket with a light coating of 15W-40 lubrication oil.
- c. Center the filter ring on the threaded mounting nipple. Screw the filter canister onto the mounting flange until the gasket is snug against the mounting flange. Then tighten an additional 1/4 turn.

NOTE: Cummins recommends using Fleetguard Coolant Filter WF2126.

CAUTION

Mechanical over tightening can distort the threads or damage the filter element seal.

7. If using a soapy water solution, flush again with clear water. Allow the water to fully drain.
8. Connect any disconnected lines or hoses.

CAUTION

Handling and disposing of used antifreeze can be subject to federal, state, and local laws and regulations. Use authorized waste disposal facilities, including civic amenity sites and garages providing authorized facilities for the receipt of used antifreeze. If in doubt, contact local authorities or the EPA for guidance as to proper handling of used antifreeze. Reconnect the engine heater coolant hose and close the drain petcock and the lower coolant tube petcock.

NOTE: During filling, air must be vented from the engine coolant passages. The air vents through the coolant filler port. The system has a design fill rate of 10 liters/minute (2.8 gal/min).

9. Fill the coolant tanks with low-silicate antifreeze that meets ASTM 4985 test (GM 6038 M spec.) criteria. Use a mixture of 50% water and 50% ethylene-glycol base or propylene-glycol antifreeze (or pre-mixed solution) to protect the engine to -37° C (-34° F) year-around.

CAUTION

Use soft or distilled water in the coolant mixture. Contaminants in hard water neutralize the corrosion inhibitor components. Water must not exceed 300-ppm hardness or contain more than 100 ppm of either chloride or sulfate.

NOTE: Cummins Inc. recommends using Fleetguard® ES COMPLEAT™ Ethylene-Glycol (EG) or Fleetguard® Propylene-Glycol (PG) Plus™ Antifreeze/Coolants. Both products are available in concentrated or pre-mixed formulations. Use a 50% concentration level (40% to 60% range) of ethylene-glycol or propylene-glycol in most climates. Contact your local Cummins Authorized Repair Location for additional information.

Ethylene-Glycol

40% = -23° C (-10° F)
50% = -37° C (-34° F)
60% = -54° C (-65° F)
68% = -71° C (-90° F)

Propylene-Glycol

40% = -21° C (-6° F)
50% = -33° C (-27° F)
60% = -54° C (-65° F)
68% = -63° C (-82° F)

CAUTION

Never use a sealing additive to stop leaks in the cooling system. This can result in cooling system blockage or restricted coolant flow, causing the engine to overheat.

CAUTION

The system must be filled properly to prevent air locks. During filling, air must be vented from the engine coolant passages.

10. Check the condition of the filler cap.
 - a. If the filler cap seal is worn, damaged, missing or the pressure spring is damaged or shows signs of sticking, replace the filler cap.
 - b. Install the expansion tank filler cap.
11. Operate the engine until it reaches a temperature of 82° C (180° F), and check for coolant leaks.
12. Ensure that the coolant level is just below the filler neck.

6.6 Every 4 Years or 5000 Hours

All maintenance checks and inspections listed in previous maintenance intervals must also be performed at this time.

Cummins recommends performing maintenance on valve lash settings. The recommended maintenance is beyond the scope of this manual.

CAUTION

Valve lash maintenance should be performed by a skilled technician. Improper maintenance can damage the engine or cause severe personal injury. Contact your local Cummins Authorized

Repair Location before performing any extensive maintenance.


6.6.1 Coolant Thermostat Removal/Installation

The thermostat regulates the temperature of the engine coolant circulating through the engine cooling system.

CAUTION

Always use the correct thermostat, and never operate the engine without a thermostat installed. The engine can overheat if operated without a thermostat because the path of least resistance for the coolant is through the bypass to the pump inlet.

1. Remove the upper coolant hose clamps and remove the upper coolant hose from the thermostat housing.
2. Remove the (2) thermostat housing flange cap screws and the thermostat flange. Refer to [Figure 6-25](#).



1. Upper Coolant Hose
2. Hose Clamps
3. Thermostat Housing

Figure 6-25 Thermostat Housing

3. Remove the thermostat and gasket from the housing.
4. Clean the housing flange faces of dirt buildup, oxidation and sludge.
5. Install the thermostat EC1722 or equivalent in the housing.

NOTE: EC 1722 Kit contains Cummins approved thermostat and thermostat seal.

6. Install a new thermostat seal on the thermostat housing flange surface.
7. Replace the thermostat flange and cap screws.

6.6.2 Coolant Pump Belt Replacement


Replace the Coolant Pump Belt if it is cracked, frayed or has pieces of material missing.

CAUTION

Disconnect both batteries (negative cable first) before performing service on the Fire Pump Engine or on any of its controls.

1. Remove the belt guard. Refer to [Figure 6-26](#).
2. Use a 3/8" drive ratchet or breaker bar to rotate the tensioner arm away from the belt and remove the belt.
3. Check the belt tensioner cap screw torque. The screw should be torqued to 43 N-m (32 ft-lb).
4. Check the tensioner arm, pulley, and stops for cracks. If any cracks are noticed, the tensioner must be replaced.
5. Verify that the tensioner arm stop is not in contact with the spring casing stop.

If either stop is touching, the tensioner must be replaced.



CFP-097

1. Coolant Pump
2. Coolant Pump Drive Belt
3. Tensioner Arm

Figure 6-26 Coolant Pump Drive Belt

6. Inspect the tensioner for evidence of the tensioner arm contacting the tensioner cap.

If there is evidence of the two areas making contact, the pivot tube bushing has failed and the tensioner must be replaced.

7. Check the tensioner bearing.
 - a. Rotate the tension pulley. The pulley should spin freely with no mechanical binding, eccentric motion or excessive end-play.
 - b. If the arm rotates with mechanical binding, eccentric movement or excessive end play, replace the tensioner.

8. Inspect the clearance between the tensioner spring case and the tensioner arm for uneven bearing wear.

If the clearance exceeds 3 mm (0.12 in) at any point, the tensioner must be replaced as a complete assembly. Contact a Cummins Authorized Repair Location for replacement.

NOTE: Experience has shown that tensioners generally will show a larger clearance gap near the lower

portion of the spring case, resulting in the upper portion rubbing against the tensioner arm. Always replace the belt when a tensioner is replaced.

9. After checking the torque, use a 3/8" drive ratchet or breaker bar to rotate the tensioner slowly away from the area of belt contact.
10. Install the replacement drive belt.



CAUTION

To prevent pulley or belt damage, do not roll a belt over the pulley or pry it on with a tool. Move the tensioner arm away from the belt area before installing the drive belt.

11. Check the location of the drive belt on the belt tensioner pulley. The belt should be centered on, or centered close to the middle of, the pulley.



CAUTION

Unaligned belts, either too far forward or backward, can cause belt wear, belt roll-off failures, or increase uneven tensioner bushing wear.

12. Proceed to [6.6.3 Alternator Belt Replacement](#) or reinstall the belt guard.

6.6.3 Alternator Belt Replacement

Replace the drive belt if it is cracked, frayed or has pieces of material missing.




CAUTION

Disconnect both batteries (negative cable first) before performing service on the Fire Pump Engine or on any of its controls.

Replace the Alternator Belt if it is cracked, frayed or has pieces of material missing.

1. Use a 3/8" drive ratchet or breaker bar to rotate the tensioner arm away from the belt and remove the belt. Refer to [Figure 6-27](#).
2. Rotate the backside idler pulley. The pulley should spin freely with no mechanical binding, eccentric motion or excessive end-play. Replace the idler pulley assembly if necessary.



CFP-098

1. Alternator Drive Belt
2. Idler Pulley
3. Tensioner Arm
4. Alternator

Figure 6-27 Alternator Drive Belt

3. Check the belt tensioner cap screw torque. The screw should be torqued to 43 N-m (32 ft-lb).
4. Check the tensioner arm, pulley, and stops for cracks. If any cracks are noticed, the tensioner must be replaced.

5. Verify that the tensioner arm stop is not in contact with the spring casing stop.

If either stop is touching, replace the tensioner.

6. Inspect the tensioner for evidence of the tensioner arm contacting the tensioner cap.

If there is evidence of the two areas making contact, the pivot tube bushing has failed and the tensioner must be replaced.

7. Check the tensioner bearing.
 - a. Rotate the tension pulley. The pulley should spin freely with no mechanical binding, eccentric motion or excessive end-play.
 - b. If the arm rotates with mechanical binding, eccentric movement or excessive end play, replace the tensioner.

8. Inspect the clearance between the tensioner spring case and the tensioner arm for uneven bearing wear.

If the clearance exceeds 3 mm (0.12 in) at any point, the tensioner must be replaced as a complete assembly. Contact a Cummins Authorized Repair Location for replacement.

NOTE: Experience has shown that tensioners generally will show a larger clearance gap near the lower portion of the spring case, resulting in the upper portion rubbing against the tensioner arm. Always replace the belt when a tensioner is replaced.

9. Use a 3/8" drive ratchet or breaker bar to rotate the tensioner slowly away from the area of belt contact.

10. Install the replacement drive belt.



CAUTION

To prevent pulley or belt damage, do not roll a belt over the pulley or pry it on with a tool. Move the tensioner arm away from the belt area before installing the drive belt.

11. Check the location of the drive belt on the belt tensioner pulley. The belt should be centered on, or centered close to the middle of, the pulley.



CAUTION

Unaligned belts, either too far forward or backward, can cause belt wear, belt roll-off failures, or increase uneven tensioner bushing wear.

12. Replace the belt guard and tighten the cap screws to the proper torque value.

6.6.4 Charge Air Cooler Heat Exchanger

The charge air cooler heat exchanger should be removed and cleaned internally at least once every four years.

1. Place the AUTO/MANUAL Mode Switch in the MANUAL position.
2. Disconnect both batteries at their terminals. Remove (-) negative cable first. Install the (-) negative cable last.

CAUTION

Both batteries must be disconnected before performing service on the Fire Pump Engine or on any of its controls. Wear safety glasses when disconnecting batteries!

3. Shut off the normal and bypass raw water hand valves on the raw water manifold.
4. Disconnect the charge air inlet and outlet piping from the charge air cooler (CAC) heat exchanger. Refer to [Figure 6-28](#).
5. Disconnect raw water inlet and outlet fittings from the charge air cooler (CAC) heat exchanger. Refer to [Figure 6-28](#).
6. Provide support for the CAC heat exchanger in order to avoid dropping it.


7. Remove the CAC heat exchanger mounting bracket bolts from the mounting bracket and remove the CAC heat exchanger from the mounting brackets.

WARNING

Cleaning chemicals may be caustic and cause skin irritation. Follow the instructions on cleaning containers for protective clothing. Wear protective clothing, eye wear, and rubber gloves when working with cleaning solutions. Dispose of solvents and cleaning solutions properly.

CAUTION

Do not use caustic cleaners to clean the charge air cooler. Damage to the charge air cooler will result. Follow the directions provided by the cleaning solution manufacturer.



CFP-100

- | | |
|---|--|
| 1. Coolant Expansion Tank | 6. Charge Air Tubing to Engine |
| 2. Mounting Bracket Nuts | 7. Coolant/Fuel Cooling Heat Exchanger |
| 3. Charge Air Cooler Mounting Brackets | 8. Raw Water Inlet Fitting |
| 4. Raw Water Outlet Fitting | 9. Charge Air Tubing from Turbocharger (not shown) |
| 5. Charge Air Cooler (CAC) Heat Exchanger | |

Figure 6-28 Charge Air Cooler (CAC) Heat Exchanger

-
8. Flush the charge air cooler internally with cleaning solution in the opposite direction of normal air-flow.
 9. Shake the charge air cooler and lightly tap on the tank ends with a rubber mallet to dislodge trapped debris. Continue flushing until all debris or oil is removed.
 14. Provide support for the coolant heat exchanger in order to avoid dropping it.
 15. Position the heat exchanger and clamps on the engine's mounting bracket and hand tighten the mounting bolts.
 16. Align the heat exchanger with the required air hose connections and tighten the hose clamp fasteners. Refer to [Figure 6-28](#).



CAUTION

Wear appropriate eye and face protection when using compressed air. Flying debris and dirt can cause personal injury.

10. After the charge air cooler has been thoroughly cleaned of all oil and debris with solvent, wash the charge air cooler internally with hot, soapy water to remove the remaining solvent.
11. Rinse thoroughly with clean water.
12. Blow compressed air into the charge air cooler in the opposite direction of normal air-flow until the charge air cooler is dry internally.
13. If internal water leakage is suspect, perform a pressure test on the heat exchanger. Refer to [6.4.13 Heat Exchanger Pressure Test](#).
17. Reinstall all water supply and drain fittings. Use Teflon™ pipe tape to prevent leaks. Torque the hose clamp screws to 8 N-m (71 in-lb).
18. When the charge air heat exchanger hose clamps and cooling water lines are secure, tighten the mounting bracket bolts.
19. Open the cooling loop raw water supply manual valves and check for leaks.
20. After completing all service work, start the engine and check for air leaks, loose clamps, and blowby.



Section 7 - Troubleshooting

7.1 Troubleshooting

The following information is intended as a guide to troubleshooting some common nontechnical equipment problems. Many problems can be resolved using corrective maintenance, adjustment or minor repair. Refer to the Vendor supplied literature, electrical schematics and mechanical prints for additional information.

For engine related issues, refer to Operation and Maintenance Manual, Industrial and Power Generation QSX15 Engines, Bulletin No. 3666423 or contact the Cummins Customer Assistance Center at 1-800-DIESELS (1-800-343-7357).

It is beyond the scope of this manual to cover all of the various problems that may affect engine performance.

WARNING

*The status checks should be performed **ONLY** by a qualified technician. Contact with exposed electrical components could cause extreme personal injury or death.*

WARNING

*Before equipment operation, **ALL** guards, covers and protective devices **MUST BE** in place and **securely fastened**. Serious personal injury could result from contact with exposed or moving components.*

CAUTION

***AVOID SERVICING** complex components such as: printed circuit boards, and, ECM's, not specifically authorized by Cummins Inc. Contact a Cummins Fire Power Customer Service Department toll free at 1-800-343-7357 before performing any extensive maintenance.*

CAUTION

Never climb or stand on the equipment frame, guards, or enclosures. Contact with exposed or moving components can cause personal injury or equipment damage.

Table of Contents

7.1 Fault Code Table	7-3
----------------------------	-----

7.1 Troubleshooting Chart	7-8
---------------------------------	-----

Problem	Page
7.1.1 Alternator Overcharging with the Engine Running . . .	7-8
7.1.2 Neither Battery is Charging with the Engine Running.	7-8
7.1.3 Only One Battery is Charging with the Engine Running	7-9
7.1.4 Voltage Indications Differ	7-9
7.1.5 Coolant Contamination	7-10
7.1.6 Excessive Coolant Loss	7-11
7.1.7 Coolant Temperature Above Normal	7-12
7.1.8 Coolant Temperature Below Normal.	7-13
7.1.9 Raw Water Drain Steaming	7-14
7.1.10 Raw Water Solenoid Valve fails to Operate	7-14
7.1.11 Auto Start failure - Does not Crank on BATT A or B.	7-15
7.1.12 Auto Start failure - Cranks but does not Start	7-15
7.1.13 Auto Start failure - Engine Starts but Crank Terminate Does Not Occur	7-16
7.1.14 Manual Start Failure from Solenoid Lever - Does not Crank on A or B	7-17
7.1.15 Manual Start Failure from Control Panel - Does not Crank on A or B	7-17
7.1.16 Engine Cranks Normally But Will Not Start (No Exhaust Smoke)	7-18
7.1.17 Engine Cranks Slowly But Does Not Start	7-19
7.1.18 Engine Stops During Operation	7-20
7.1.19 Engine Will Not Reach Rated Speed (RPM).	7-21
7.1.20 Engine Will Not Shut Off Remotely	7-22
7.1.21 Engine Will Not Shut Off Locally	7-23
7.1.22 Fuel Consumption is Excessive	7-23
7.1.23 Fuel or Engine Oil Leaking From Exhaust Manifold .	7-24
7.1.24 Engine Oil is Contaminated	7-24
7.1.25 Engine Oil Consumption is Excessive	7-25
7.1.26 Lubrication Oil in the Coolant	7-26
7.1.27 Engine Overspeed Trip	7-26
7.1.28 Tachometer Does not Indicate Engine Speed	7-27

CFP15E Fault Code Table

FAULT CODE (LAMP)	SID(S) PID(S) FMI	SPN FMI	Cummins DESCRIPTION
111 (Red)	S254 12	629 12	Engine Control Module - Critical Internal Failure
115 (Red)	P190 2	190 2	Engine Speed/Position Sensor Circuit - Lost both of two signals from the Magnetic Pickup Sensor
121 (Yellow)	P190 10	190 10	Engine Speed/Position Sensor Circuit - Lost one of two signals from the Magnetic Pickup Sensor
122 (Yellow)	P102 3	102 3	Intake Manifold Pressure Sensor #1 Circuit - Shorted High
123 (Yellow)	P102 4	102 4	Intake Manifold Pressure Sensor #1 Circuit - Shorted Low
131 (Red)	P091 3	091 3	Accelerator Pedal Position Sensor Circuit - Shorted High
132 (Red)	P091 4	091 4	Accelerator Pedal Position Sensor Circuit - Shorted Low
133 (Red)	P029 3	974 3	Remote Accelerator Pedal Position Sensor Circuit - Shorted High
134 (Red)	P029 4	974 4	Remote Accelerator Pedal Position Sensor Circuit - Shorted Low
135 (Yellow)	P100 3	100 3	Engine Oil Pressure Sensor Circuit - Shorted High
141 (Yellow)	P100 4	100 4	Engine Oil Pressure Sensor Circuit - Shorted Low
143 (Yellow)	P100 1	100 18	Engine Oil Pressure Low - Warning
144 (Yellow)	P110 3	110 3	Engine Coolant Temperature Sensor Circuit - Shorted High
145 (Yellow)	P110 4	110 4	Engine Coolant Temperature Sensor Circuit - Shorted Low
147 (Red)	P091 8	091 8	Accelerator Pedal Position Sensor Circuit - Low Frequency
148 (Red)	P091 8	091 8	Accelerator Pedal Position Sensor Circuit - High Frequency
151 (Yellow)	P110 0	110 0	Engine Coolant Temperature High - Critical
153 (Yellow)	P105 3	105 3	Intake Manifold Temperature Sensor #1 Circuit - Shorted High
154 (Yellow)	P105 4	105 4	Intake Manifold Temperature Sensor #1 Circuit - Shorted Low
155 (Red)	P105 0	105 0	Intake Manifold Temperature #1 High - Critical
187 (Yellow)	S232 4	620 4	Sensor Supply Voltage #2 Circuit - Shorted Low
211 (None)	S216 11	1484 31	Additional OEM/Vehicle Diagnostic Codes have been logged. Check other ECM's for DTC's.
212 (Yellow)	P175 3	175 3	Engine Oil Temperature Sensor Circuit - Shorted High
213 (Yellow)	P175 4	175 4	Engine Oil Temperature Sensor Circuit - Shorted Low

CFP15E Fault Code Table (Continued)

FAULT CODE (LAMP)	SID(S) PID(S) FMI	SPN FMI	Cummins DESCRIPTION
214 (Yellow)	P175 0	175 0	Engine Oil Temperature High - Critical
219 Maint.	P17 1	1380 17	Low Oil Level in the Centinel Makeup Oil Tank
221 (Yellow)	P108 3	108 3	Ambient Air Pressure Sensor circuit - Shorted High
222 (Yellow)	P108 4	108 4	Ambient Air Pressure Sensor circuit - Shorted Low
223 (Yellow)	S085 4	1265 4	Engine Oil Burn Valve Solenoid Circuit - Shorted Low
227 (Yellow)	S232 3	620 3	Sensor Supply Voltage #2 Circuit - Shorted High
234 (Red)	P190 0	190 0	Engine Speed High - Critical
235 (Yellow)	P111 1	111 1	Engine Coolant Level Low - Critical
241 (Yellow)	P084 2	084 2	Vehicle Speed Sensor circuit - Data Incorrect
242 (Yellow)	P084 10	084 10	Vehicle Speed Sensor Circuit - Tampering has Been Detected
245 (Yellow)	S033 4	647 4	Fan Clutch Circuit - Shorted Low
254 (Red)	S017 4	632 4	Fuel Shutoff Valve Circuit - Shorted Low
255 (Yellow)	S017 3	632 3	Fuel Shutoff Valve Circuit - Shorted High
259 (Yellow)	S017 7	632 7	Fuel Shutoff Valve - Stuck Open
284 (Red)	S221 4	1043 4	Engine Speed/Position Sensor #1 (Crankshaft) Supply Voltage Circuit - Shorted Low
285 (Yellow)	S231 9	639 9	SAE J1939 Multiplexing PGNTimeout Error
286 (Yellow)	S231 13	639 13	SAE J1939 Multiplexing Configuration Error
287 (Red)	P091 2	091 19	SAE J1939 Multiplexing Accelerator Pedal Sensor System Error
288 (Red)	P029 2	974 19	SAE J1939 Multiplexing Remote Throttle Data Error
293 (Yellow)	S154 3	1083 3	Auxiliary Temperature Sensor Input #1 Circuit - Shorted High
294 (Yellow)	S154 4	1083 4	Auxiliary Temperature Sensor Input #1 Circuit - Shorted Low
295 (Yellow)	P108 2	108 2	Ambient Air Pressure Sensor Circuit - Data Incorrect
297 (Yellow)	P223 3	1084 3	Auxiliary Pressure Sensor Input #2 Circuit - Shorted High
298 (Yellow)	P223 4	1084 4	Auxiliary Pressure Sensor Input #2 Circuit - Shorted Low

CFP15E Fault Code Table (Continued)

FAULT CODE (LAMP)	SID(S) PID(S) FMI	SPN FMI	Cummins DESCRIPTION
299 (Yellow)	S117 11	1384 31	Engine Shutdown Commanded by J1939
311 (Yellow)	S001 6	651 6	Injector Solenoid Valve Cylinder #1 Circuit - Grounded Circuit
312 (Yellow)	S005 6	655 6	Injector Solenoid Valve Cylinder #5 Circuit - Grounded Circuit
313 (Yellow)	S003 6	653 6	Injector Solenoid Valve Cylinder #3 Circuit - Grounded Circuit
314 (Yellow)	S006 6	656 6	Injector Solenoid Valve Cylinder #6 Circuit - Grounded Circuit
315 (Yellow)	S002 6	652 6	Injector Solenoid Valve Cylinder #2 Circuit - Grounded Circuit
319 Maint.	P251 2	251 2	Real Time Clock - Power Interrupt
341 (Red)	S253 2	630 2	Engine Control Module - Data Lost
343 (Red)	S254 12	629 12	Engine Control Module - Warning Internal Hardware Failure
346 (Yellow)	S253 12	630 12	Engine Control Module - Warning Software Error
349 (Yellow)	P191 0	191 16	Transmission Output Shaft (Tailshaft) Speed High - Warning
352 (Yellow)	S232 4	1079 4	Sensor Supply Voltage #1 Circuit - Shorted Low
378 (Red)	S018 5	633 5	Fueling Actuator #1 Circuit - Open Circuit
379 (Red)	S018 6	633 6	Fueling Actuator #1 Circuit - Grounded Circuit
386 (Yellow)	S232 3	1079 3	Sensor Supply Voltage #1 Circuit - Shorted High
387 (Yellow)	S221 3	1043 3	Accelerator Pedal Position Sensor Supply Voltage Circuit - Shorted High
394 (Red)	S020 5	635 5	Timing Actuator #1 Circuit - Open Circuit
395 (Yellow)	S020 6	635 6	Timing Actuator #1 Circuit - Grounded Circuit
396 (Yellow)	S083 5	1244 5	Fueling Actuator #2 Circuit - Open Circuit
397 (Yellow)	S083 6	1244 6	Fueling Actuator #2 Circuit - Grounded Circuit
398 (Yellow)	S084 5	1245 5	Timing Actuator #2 Circuit - Open Circuit
399 (Red)	S084 6	1245 6	Timing Actuator #2 Circuit - Grounded Circuit
415 (Yellow)	P100 1	100 1	Engine Oil Pressure Low - Critical
418 WIF/Maint.	P097 0	097 15	Water in Fuel Indicator High - Maintenance

CFP15E Fault Code Table (Continued)

FAULT CODE (LAMP)	SID(S) PID(S) FMI	SPN FMI	Cummins DESCRIPTION
422 (Yellow)	P111 2	111 2	Engine Coolant Level Sensor Circuit - Data Incorrect
426 (None)	S231 2	639 2	SAE J1939 datalink - Cannot Transmit
428 (Yellow)	P097 3	097 3	Water in Fuel Sensor Circuit - Shorted High
429 (Yellow)	P097 4	097 4	Water in Fuel Sensor Circuit - Shorted Low
431 (Yellow)	S230 2	558 2	Accelerator Pedal Idle Validation Circuit - Data Incorrect
432 (Yellow)	S230 13	558 13	Accelerator Pedal Idle Validation Circuit - Out of Calibration
433 (Yellow)	P102 2	102 2	Intake Manifold Pressure Sensor Circuit - Data Incorrect
434 (Yellow)	S251 2	627 2	Power Lost without Ignition Off
435 (Yellow)	P100 2	100 2	Engine Oil Pressure Sensor Circuit - Data Incorrect
441 (Yellow)	P168 1	168 18	Battery #1 Voltage Low - Warning
442 (Yellow)	P168 0	168 16	Battery #1 Voltage High- Warning
443 (Yellow)	S221 4	1043 4	Accelerator Pedal Position Sensor Supply Voltage Circuit - Shorted Low
449 (Red)	P094 0	094 16	Fuel Pressure High - Warning
451 (Red)	P157 3	157 3	Injector Metering Rail #1 Pressure Sensor Circuit - Shorted High
452 (Red)	P157 4	157 4	Injector Metering Rail #1 Pressure Sensor Circuit - Shorted Low
466 (Yellow)	S032 4	1188 4	Turbocharger #1 Wastegate Control Circuit - Shorted Low
482 (Red)	P094 1	94 18	Fuel Pressure Low - Warning
483 (Red)	P129 3	1349 3	Injector Metering Rail #2 Pressure Sensor Circuit - Shorted High
484 (Red)	P129 4	1349 4	Injector Metering Rail #2 Pressure Sensor Circuit - Shorted Low
485 (Red)	P129 0	1349 16	Injector Metering Rail #2 Pressure High - Warning
486 (Red)	P129 1	1349 18	Injector Metering Rail #2 Pressure Low - Warning
489 (Yellow)	P191 1	191 18	Transmission Output Shaft (Tailshaft) Speed Low - Warning
496 (Red)	S221 11	1043 11	Engine Speed/Position Sensor #2 (Camshaft) Supply Voltage
527 (Yellow)	P154 3	702 3	Auxiliary Input/Output #2 Circuit - Shorted High

CFP15E Fault Code Table (Continued)

FAULT CODE (LAMP)	SID(S) PID(S) FMI	SPN FMI	Cummins DESCRIPTION
528 (Yellow)	P093 2	093 2	OEM Alternate torque validation switch - Data Incorrect
529 (Yellow)	S051 3	703 3	Auxiliary Input/Output #3 Circuit - Shorted High
546 (Red)	P094 3	094 3	Fuel Delivery Pressure Sensor Circuit - Shorted High
547 (Red)	P094 4	094 4	Fuel Delivery Pressure Sensor Circuit - Shorted Low
551 (Yellow)	S230 4	558 4	Accelerator Pedal Idle Validation Circuit - Shorted Low
553 (Red)	P157 0	157 16	Injector Metering Rail #1 Pressure High - Warning Level
559 (Red)	P157 1	157 18	Injector Metering Rail #1 Pressure Low - Warning Level
581 (Yellow)	P015 3	1381 3	Fuel Supply Pump Inlet Pressure Sensor Circuit - Shorted High
582 (Yellow)	P015 4	1381 4	Fuel Supply Pump Inlet Pressure Sensor Circuit - Shorted Low
583 (Yellow)	P015 1	1381 18	Fuel Supply Pump Inlet Pressure Low - Warning Level
595 (Yellow)	P103 0	103 16	Turbocharger #1 Speed High - Warning Level
596 (Yellow)	P167 0	167 16	Electrical Charging System Voltage High - Warning Level
597 (Yellow)	P167 1	167 18	Electrical Charging System Voltage Low - Warning Level
598 (Red)	P167 1	167 1	Electrical Charging System Voltage Low - Critical Level
611 (None)	S151 11	1383 31	Engine Hot Shutdown
753 (Red)	S064 2	723 2	Engine Speed/Position #2 - Cam Sync Error
755 (Yellow)	P157 7	157 7	Injector Metering Rail #1 Pressure Malfunction
758 (Yellow)	P129 7	1349 7	Injector Metering Rail #2 Pressure Malfunction
951 (None)	P166 2	166 2	Cylinder Power Imbalance Between Cylinders

Troubleshooting Chart

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.1 Alternator Overcharging with the Engine Running NOTE: <i>If the batteries are overcharged while the engine is not running, troubleshoot the customer supplied battery charging system.</i>	<p>Batteries have failed.</p> <p>Voltage regulator malfunction.</p>	<p>Check the condition of the batteries. Replace any defective batteries.</p> <p>Test the alternator electrically. Contact an Authorized Cummins Repair Facility.</p> <p>Replace alternator as necessary.</p>
7.1.2 Neither Battery is Charging with the Engine Running NOTE: <i>If one or both batteries do not charge with the engine stopped, troubleshoot the customer supplied battery charging system.</i> NOTE: <i>If only one battery is maintaining charge, go to Only One Battery is Charging with the Engine Running.</i>	<p>Battery cables or connections are loose, broken, or corroded (excessive resistance).</p> <p>Alternator rotor is not rotating.</p> <p>Battery isolator input has faulted.</p> <p>Alternator excitation is lost.</p>	<p>Check the battery cables and connections. Ensure that all connections are free of corrosion and that no cables are broken.</p> <p>Test the alternator mechanically. If the alternator shaft does not spin freely because of a bad bearing, replace the alternator.</p> <p>If the alternator does not turn because of a bad drive belt, replace the drive belt. Refer to Section 6 - Maintenance.</p> <p>If the alternator does not charge because of poor drive belt tension, adjust belt tension. Refer to Section 6 - Maintenance.</p> <p>If the alternator pulley spins freely on the shaft because of a broken key, replace the alternator. Contact an Authorized Cummins Repair Facility.</p> <p>Test continuity from the alternator to the battery isolator input. Repair any open circuit.</p> <p>Test continuity through the battery isolator. If an internal open circuit exists, replace battery isolator.</p> <p>Test the alternator electrically. Replace the alternator diode as necessary.</p> <p>Speed Failed - Fused relay</p> <p>Locate and repair the open circuit or short to ground in the alternator excitation wiring as necessary.</p>

[illegible]

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.5 Coolant Contamination	Coolant is rusty and has debris.	<p>Drain and flush the cooling system per the instructions in Section 6 - Maintenance.</p> <p>Replace the coolant filter per the instructions in Section 6 - Maintenance.</p> <p>Refill with correct mixture of anti-freeze and water per the instructions in Section 6 - Maintenance.</p> <p>Drain and flush the cooling system per the instructions in Section 6 - Maintenance.</p>
	Engine oil cooler is leaking oil into the coolant. Coolant begins to have the texture and color of chocolate pudding.	<p>Check the engine oil cooler for coolant leaks and cracks. The engine oil cooler is part of the Coolant/Fuel Heat Exchanger</p> <p>Replace the oil cooler, gaskets, or other parts as necessary.</p> <p>Refill with correct mixture of anti-freeze and water.</p> <p>If the problem persists, the cylinder block may be cracked or porous. Contact the Cummins Authorized Repair Facility.</p>
	Coolant Heat Exchanger is leaking raw water into the coolant. Coolant volume increases and pressure is relieved when the unit is operating. Antifreeze concentration decreases.	<p>Drain and flush the cooling system per the instructions in Section 6 - Maintenance.</p> <p>Perform a pressure test of the raw water side of the heat exchanger. If the heat exchanger leaks, it should be replaced.</p> <p>Check and adjust raw water pressure regulator set points.</p> <p>Check and, if required, replace the zinc plug.</p> <p>Refill with correct mixture of anti-freeze and water per the instructions in Section 6 - Maintenance.</p>

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.5 Coolant Contamination (continued)	Coolant is inadvertently contaminated with unknown liquids.	<p>Drain and flush the cooling system. Refill with correct mixture of antifreeze and water per the instructions in Section 6 - Maintenance.</p> <p>Contact an Authorized Cummins Repair Facility.</p>
7.1.6 Excessive Coolant Loss	<p>Adequate coolant was not added following previous maintenance activities.</p> <p>Inadvertent coolant leak is present.</p> <p>Cooling system hose is leaking.</p> <p>Pressure cap is malfunctioning or has low-pressure rating.</p> <p>Mechanical coolant leak.</p>	<p>Check the coolant level. Add coolant as required and check engine operation. If coolant loss persists, check for other problems.</p> <p>Inspect the engine for coolant leaking from drain cocks or vents. Close the leaking drain or vent. Add coolant as required and check engine operation.</p> <p>Check the condition of the hoses. Replace and/or tighten loose hose clamps. Replace any damaged hoses as necessary. Add coolant as required and check engine operation.</p> <p>Check that the pressure/fill cap does not relieve coolant under normal operating conditions. Replace a leaking pressure cap, (Cummins Fire Power Part No. 11407). Add coolant as required and check engine operation.</p> <p>Inspect the engine for coolant leaking from manifold, expansion and pipe plugs, fittings, oil cooler, coolant pump seal, cylinder block, and other components that have coolant flow. Repair leaking components. Add coolant as required and check engine operation.</p>

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
<p>7.1.7 Coolant Temperature Above Normal</p> <p>NOTE: <i>The thermostat's normal operating temperature range is 82-95° C (180-203° F) The High Coolant Temperature lamp is on the operator control panel. The lamp only illuminates if the engine is running. If the lamp is illuminated or if temperature is otherwise excessive, the engine should be stopped as soon as practical and the problem corrected.</i></p>	<p>Engine is overheating.</p> <p>Raw water flow (valves) are improperly aligned.</p> <p>Raw water pressure regulator is improperly adjusted.</p> <p>NOTE: <i>Pressure should not exceed 414 kPa [60 psig].</i></p> <p>Raw water solenoid has failed.</p> <p>Raw water piping or heat exchanger is plugged.</p> <p>Coolant level is below specification.</p> <p>Cooling system hose is collapsed, restricted, or leaking.</p>	<p>Refer to the Coolant Temperature Above Normal in this section.</p> <p>Check that the raw water valves are aligned for normal flow through the solenoid valve (preferred) or bypass flow around the solenoid valve (alternative). Align flow/valves if required.</p> <p>Check the raw water pressure gauge. If pressure is indicated but is low, adjust the regulator. If pressure is not indicated or is excessively low, go to raw water solenoid has failed.</p> <p>If pressure is excessively low when aligned for normal flow, open the bypass valves. When practical, troubleshoot the raw water solenoid valve. Refer to Raw Water Solenoid Valve Fails to Operate in this section. If the solenoid valve operates, replace the pressure regulator.</p> <p>If pressure is excessively low when aligned for bypass flow, open the normal valves.</p> <p>Check the raw water strainer for blockage per the instructions in Section 6 - Maintenance. Clean the strainer if necessary.</p> <p>Check the raw water piping for blockage. Clean the piping if necessary.</p> <p>Remove any blockage. Check for flow through the heat exchanger. Replace the heat exchanger as necessary.</p> <p>Check the coolant level. If coolant level is excessively low, go to Excessive Coolant Loss in this section.</p> <p>Inspect the hoses. Replace any damaged hoses as necessary.</p>

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.7 Coolant Temperature Above normal (continued)	Coolant thermostat is malfunctioning.	Remove and test the coolant thermostat per the instructions in Section 6 - Maintenance . Replace the defective thermostat.
	Coolant pump is malfunctioning.	Remove and inspect the coolant pump. Replace the defective coolant pump. Contact an Authorized Cummins Repair Facility.
	Engine oil is contaminated with coolant or fuel.	Check the appearance of the engine oil. If the color and texture is abnormal, refer to the Engine Oil Contaminated in this section.
	Coolant mixture of antifreeze and water is not correct.	Verify the concentration of antifreeze in the coolant. Add antifreeze or water to correct the concentration.
	Engine oil level is above or below specification.	Check the oil level per the instructions in Section 6 - Maintenance .
	Coolant temperature sender is malfunctioning.	Replace the temperature sender as necessary.
	Coolant temperature gauge is malfunctioning.	Replace the temperature gauge as necessary.
7.1.8 Coolant Temperature Below Normal	Coolant temperature switch is malfunctioning.	Remove the temperature switch. Test the temperature switch. Repair or replace the switch, if necessary.
	The standard 120 VAC or optional 240 VAC power supply to the coolant heater is not connected.	Connect the power supply. Correct any electrical faults in the supply circuit.
	The heater's overload thermostat has operated.	Ensure that there is coolant in the heater. Allow time for the automatic overload reset to occur.
	Coolant temperature sender is malfunctioning.	Replace the temperature sender.
	Coolant temperature gauge is malfunctioning.	Replace the temperature gauge.
	Coolant is not free to circulate through the heater.	Ensure that the coolant hoses are clear. Repair or replace hoses as necessary.
	The coolant heater has failed electrically.	Replace the coolant heater.

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.8 Coolant Temperature Below Normal (continued)	<p>Electronic fault codes are active.</p> <p>Coolant thermostat has failed open.</p>	<p>For instructions on how to read active fault codes, see Section 5 - Operation, the fault code table in this chapter, or contact a Cummins Authorized Repair Facility.</p> <p>Test operation of the thermostat. Replace the thermostat per instructions in Section 6 - Maintenance as necessary.</p>
7.1.9 Raw Water Drain Steaming NOTE: <i>The raw water drain from the Coolant/Fuel Heat Exchanger may steam if raw water flow is inadequate when the engine is running. It may also steam shortly after the engine is stopped. If coolant is leaking into the raw water drain piping, the steaming may last for some time while the engine cools. Antifreeze may also be observed in the raw water drain.</i>	<p>Raw water flow did not start when the engine started.</p> <p>Engine coolant is leaking into the raw water piping in the coolant heat exchanger.</p> <p>Raw water flow not adequate.</p>	<p>Check engine coolant temperature. Go to, Coolant Temperature Above Normal in this section.</p> <p>Remove the coolant heat exchanger and perform the pressure test. Refer to Section 6 - Maintenance. If pressure is not maintained, replace the heat exchanger.</p> <p>Compare actual flow rate against required flow rate - adjust regulators to required flow.</p>
7.1.10 Raw Water Solenoid Valve fails to Operate NOTE: <i>The raw water solenoid failure may fail to open or to close. The normally closed valve may fail to open when the engine starts. This fault will prevent raw water flow through the normal valves. Bypass flow should be aligned in this event. The valve may also fail to close because of mechanical blockage. In this event, the raw water flow from the heat exchanger does not stop when it should. Depending upon the fire protection system piping, the open solenoid valve may drain all water from the fire protection system piping that is higher than the engine's piping.</i>	<p>Solenoid valve fails to close when the engine stops.</p> <p>Solenoid valve fails to energize.</p> <p>Solenoid fails to open mechanically.</p> <p>NOTE: <i>Apply 24 VDC.</i></p>	<p>Replace the solenoid valve. Clean the raw water strainer more frequently. Increase the frequency of operational testing.</p> <p>Check electrical continuity and insulation from ground to the solenoid. Repair any open or short circuits in the wiring.</p> <p>Apply temporary voltage to the solenoid. If the solenoid fails to operate, replace it. Contact an Authorized Cummins Repair Facility.</p>

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.11 Auto Start failure - Does not Crank on BATT A or B	<p>The electrical connection from the fire protection system controller to terminal board has failed.</p> <p>The electrical connection from terminal board to relay has failed.</p> <p>Relay has failed.</p> <p>The Fire Protection System Controller fails to produce either redundant start signal to the fire pump.</p>	<p>Test continuity and insulation from ground between the fire protection system controller and the operator control panel. Locate and repair any electrical fault in the field wiring or in the fire protection system controller panel.</p> <p>Test continuity and insulation from ground between the terminal board and the relay. Locate and repair any electrical fault.</p> <p>Check de-energized continuity at relay. Replace relay if the circuit is open. Contact an Authorized Cummins Repair Facility.</p> <p>Locate and correct the common mode fault in the Fire Protection System Controller.</p>
7.1.12 Auto Start failure - Cranks but does not Start NOTE: <i>The fire pump engine will crank automatically when either solenoid A or solenoid B is selected at the fire protection system controller. However, the engine does not start. The engine will start locally. If local starting problems are identified, go to the applicable Manual Start Failure troubleshooting table.</i>	<p>The overspeed switch has activated. The overspeed lamp is illuminated on the operator control panel.</p> <p>Control power from the Fire Protection System Controller is not available at operator control panel TB-1.</p> <p>Circuit Breaker CB is open in the operator control panel.</p> <p>The AUTO/MANUAL Mode Switch fails to select AUTO mode.</p>	<p>Press the RESET switch on the operator control panel.</p> <p>Locate and correct the fault in the Fire Protection System Controller or the field wiring to the operator control panel as necessary.</p> <p>Check whether Circuit Breaker CB at the operator control panel is open.</p> <p>If open, reset the circuit breaker. Locate and correct any electrical faults in the control panel. Press the RESET Switch on the operator control panel.</p> <p>Open Circuit Breaker CB at the operator control panel and test switch operation electrically as necessary.</p> <p>Replace the switch or repair other electrical faults as necessary. When done, close Circuit Breaker CB at the operator control panel.</p>

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.12 Auto Start failure - Cranks but does not Start (continued)	<p>The overspeed switch has failed.</p> <p>NOTE: <i>Check system basics</i></p> <ul style="list-style-type: none"> - Battery voltage level - Fuel supply - Crank speed <p><i>Reference base engine T/R manual.</i></p>	<p>Check power and grounding to the overspeed switch. Repair any electrical faults.</p> <p>Test and adjust the overspeed setting. Refer to Overspeed Set Point Adjustment and Testing in Section 6 - Maintenance. Replace switch as necessary.</p>
7.1.13 Auto Start failure - Engine Starts but Crank Terminate Does Not Occur	<p>The overspeed switch not correctly adjusted or has failed.</p> <p>Breaker has tripped. The raw water solenoid valve fails to open.</p> <p>The speed sensor has failed. The tachometer indicates zero RPM.</p> <p>An electrical fault is present in the Fire Protection System Controller.</p> <p>An electrical fault is present between Operator Control Panel and the Fire Protection System Controller.</p>	<p>With the engine running, verify speed sensor input to the over-speed switch.</p> <p>If signal is not present, see Speed Sensor Has Failed. The tachometer also indicates zero speed.</p> <p>Adjust the overspeed switch crank terminate set point. Replace the overspeed switch as necessary.</p> <p>Open the raw water bypass valves. RESET breaker switch. Locate and repair any local electrical fault.</p> <p>Locate and repair any electrical fault in the speed sensor circuitry. Replace the speed sensor as necessary.</p> <p>Test continuity and insulation from ground between the fire protection system controller and the operator control panel. Locate and repair any electrical fault in the field wiring.</p> <p>Test continuity and insulation from ground between the fire protection system controller and the operator control panel. Locate and repair any electrical fault in the field wiring.</p>

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.14 Manual Start Failure from Solenoid Lever - Does not Crank on A or B NOTE: <i>The fire pump engine will not crank locally when either solenoid lever is actuated.</i>	<p>Crank Battery A and B switches failed to make contact.</p> <p>Both batteries dead.</p> <p>Solenoid A/B failed to operate.</p> <p>Starter motor has failed.</p> <p>An electrical fault is present in the power or ground circuit for the starter motor.</p> <p>Engine is seized.</p>	<p>Test electrical operation of Crank Batt A and B Switches. Replace the faulty switches as necessary.</p> <p>Charge or replace batteries.</p> <p>Test the electrical operation of the Solenoid A and Solenoid B. Replace the faulty solenoids as necessary.</p> <p>Replace the starter motor.</p> <p>Test continuity and insulation from ground between the battery splice, the ground connection, and the starter motor. Locate and repair any electrical fault.</p> <p>Bar the engine over to break the seizure. Contact an Authorized Cummins Repair Facility.</p>
7.1.15 Manual Start Failure from Control Panel - Does not Crank on A or B NOTE: <i>The fire pump engine will not crank locally from the control panel when either CRANK BATT A or CRANK BATT B is selected, however, it does start when a solenoid lever is actuated.</i>	<p>The AUTO/MANUAL Mode Switch contact fails to close.</p> <p>An electrical fault exists in the signal power circuit or the ground to the Relays.</p> <p>Breaker Switch has tripped. The raw water solenoid valve also fails to open.</p> <p>An electrical fault exists in the signal power circuit or the ground to the overspeed switch's crank circuit.</p> <p>Overspeed switch crank circuit fails to reset with engine shut-down.</p>	<p>Test the electrical operation of the AUTO/MANUAL Mode Switch. Replace the faulty switch as necessary.</p> <p>Test continuity and insulation from ground between the AUTO/MANUAL Mode Switch and the Relays. Check the relay connection to ground. Locate and repair any electrical fault.</p> <p>Open the raw water bypass valves. Locate and repair any local electrical fault. RESET the Breaker Switch.</p> <p>Test continuity and insulation from ground between breaker and the overspeed switch's crank circuit. Check the crank circuit output to the CRANK BATT Switches. Locate and repair any electrical fault.</p> <p>Test and adjust the crank setting as necessary. Refer to Overspeed Set Point Adjustment and Testing in Section 6 - Maintenance. Replace the overspeed switch as necessary.</p>

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.16 Engine Cranks Normally But Will Not Start (No Exhaust Smoke)	Electronic fault codes are active.	For instructions on how to read active fault codes, see Section 5 - Operation , the fault code table in this chapter, or contact a Cummins Authorized Repair Facility.
	Electronic control module (ECM) is locked up.	Disconnect the battery cables for 30 secs. Reconnect the battery cables, and start the engine.
	Battery voltage supply to the electronic control module (ECM) is low, interrupted, or open.	Check the battery connections, the fuses, and the battery supply circuit.
	No fuel in supply tank.	Check and replenish fuel supply. Check fittings and hose connections and hose conditions.
	Air is in the fuel system.	Check for air in the fuel system. Tighten or replace the fuel connections, fuel lines, fuel tank stand pipe and fuel filters as necessary. Vent air from the system.
	Fuel drain line is restricted.	Check the fuel drain lines for restriction. Clear or replace the fuel lines, check valves, or tank vents as necessary.
	Fuel filter is clogged.	Replace the fuel filter. Refer to Change Fuel Filter in Section 6 - Maintenance .
	Fuel grade is not correct for the application or fuel quality is poor.	Operate the engine from a separate tank of high-quality no. 2 diesel fuel.
	Fuel injection pump is malfunctioning. Pump timing incorrect.	Contact an Authorized Cummins Repair Facility.
	Fuel tank is empty.	Fill the fuel supply tank.
	Fuel pump overflow valve is malfunctioning.	Check the overflow valve. Replace if necessary.
	Fuel suction line is restricted.	Check the fuel suction line for restriction.
	Fuel connections on the suction side of the fuel lift pump are loose.	Tighten all the fuel fittings and connections between the fuel tanks and fuel lift pump.
	Fuel suction stand pipe in the fuel tank is broken.	Check and repair the stand pipe, if necessary.

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.16 Engine Cranks Normally But Will Not Start (No Exhaust Smoke) (continued)	<p>Fuel supply is not adequate.</p> <p>Fuel tank air breather is blocked.</p> <p>Fuel lift pump is malfunctioning.</p> <p>Injection pump drive shaft or drive shaft key is damaged.</p> <p>Fuel injectors are plugged.</p> <p>Moisture is in the wiring harness connectors.</p> <p>Starter motor rotation is not correct or not turning engine.</p>	<p>Locate and correct the restriction in the customer supplied fuel lines to the engine.</p> <p>Clean the fuel tank breather.</p> <p>Check the fuel lift pump for correct operation. Check the pump output pressure. Replace the fuel lift pump if necessary.</p> <p>Repair or replace the injection pump.</p> <p>Replace the fuel injectors.</p> <p>Dry the connectors with Cummins electronic cleaner, Part Number 3824510.</p> <p>Check the direction of crankshaft rotation. Replace the starter motor as necessary. Contact an Authorized Cummins Repair Facility.</p>
7.1.17 Engine Cranks Slowly But Does Not Start NOTE: <i>Typical engine cranking speed is 120 RPM. Engine cranking speed can be checked with a hand-held tachometer, stroboscope, or electronic service tool</i>	<p>The battery cable connections are loose, broken, or corroded creating excessive resistance.</p> <p>The battery is not properly charged or has failed.</p> <p>Engine oil level is too high.</p> <p>Engine oil is the wrong grade or type.</p> <p>Engine temperature is too low.</p> <p>Starter motor is malfunctioning.</p>	<p>Check the battery cables and connections. Ensure that connections are clean and tight.</p> <p>Recharge the battery. If the battery does not take the charge, replace it.</p> <p>Check the oil level per instructions in Section 6 - Maintenance. Drain any excess oil.</p> <p>Check the grade and type of oil. Refer to Engine Oil Recommendations and Specifications in Section 6 - Maintenance.</p> <p>If the wrong type or grade of oil is present, drain and replace it. Refer to Change Engine Oil and Filters in Section 6 - Maintenance.</p> <p>Troubleshoot per Coolant Temperature Below Normal (Engine Off) in this section.</p> <p>Replace the starter motor. Contact an Authorized Cummins Repair Facility.</p>

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.18 Engine Stops During Operation	Normal automatic mode shut-down occurs when the fire protection system controller removes the signal power feed to the local control panel.	No action required. This is a desirable outcome.
	The selected engine control module (ECM) has detected a serious fault condition. The ECM's STOP light is displayed.	For instructions on how to read active fault codes, see Section 5 - Operation , the fault code table in this chapter, or contact a Cummins Authorized Repair Facility.
	In AUTO mode, the signal power feed is lost from the fire protection system controller to the operator control panel.	Locate and correct the electrical fault in the fire protection system controller or the field wiring to the operator control panel.
	Circuit breaker on operator control panel tripped.	Locate and correct the electrical fault in operator control panel. RESET the tripped breaker.
	An overspeed trip has occurred. The overspeed trip lamp illuminated on the operator control panel.	Remote indications may also be present. Overspeed switch failure has occurred. The trip indications may not be present. Go to Engine Overspeed Trip in this section.
	Power supply or grounding fault exists at the Electronic Control Module (ECM).	Locate and correct the electrical fault in the power supply or grounding for the ECM.
	The selected ECM has failed.	Select the alternate ECM. Replace the failed ECM. Contact an Authorized Cummins Repair Facility.
	Fuel tank level is low.	Fill the fuel tank. Fill and bleed the fuel lines to the engine.
	Clogged fuel tank air breather hole.	Clean the fuel tank breather.
	Fuel piping to engine is clogged.	Clean and repair engine fuel piping.
	The fuel filter is clogged.	Replace the fuel filter. Refer to Change Fuel Filter in Section 6 - Maintenance .
	Air is trapped in the low pressure fuel lines at the engine.	Bleed the fuel lines. Refer to Air in Fuel in Section 6 - Maintenance .

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.18 Engine Stops During Operation (continued)	Fuel lift pump has failed	Check the fuel lift pump for correct operation. Check the pump output pressure. Replace the fuel lift pump if necessary. Contact an Authorized Cummins Repair Facility.
	Fuel injection pump has failed.	Replace the fuel injection pump. Contact an Authorized Cummins Repair Facility.
	Electronic fault codes are active.	For instructions on how to read active fault codes, see Section 5 - Operation , the fault code table in this chapter, or contact a Cummins Authorized Repair Facility.
	Programmable parameters or selected features are not correct.	Check the programmable parameters and the selected features with an electronic service tool. Set the parameters and features again if necessary. Refer to a Cummins Authorized Repair Facility.
7.1.19 Engine Will Not Reach Rated Speed (RPM)	Tachometer is not calibrated. Compare the tachometer reading with a hand held tachometer or an electronic service tool reading.	If out of calibration, calibrate the tachometer as necessary at the CAL adjustment on the back of the gauge. Refer to the Vendor supplied literature for additional information. Tachometer is malfunctioning. Replace the tachometer. Contact an Authorized Cummins Repair Facility.
	Engine power output is low.	Refer to the Engine Acceleration or Response Poor in this section.
	Fuel filter requires replacement.	Refer to Change Fuel Filter per the instructions in Section 6 - Maintenance .
	Fuel grade not correct for the application, or fuel quality is poor.	Operate the engine with a good quality no. 2 diesel fuel.
	Fuel suction line is restricted.	Check the fuel suction line for restriction.
	Air-fuel tube leaking, waste gate diaphragm ruptured, or waste gate plumbing damaged.	Tighten the fittings, repair plumbing, replace waste gate diaphragm.

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.19 Engine Will Not Reach Rated Speed (RPM) (continued)	Charge air cooler (CAC) heat exchanger restricted.	Inspect the charge air cooler/heat exchanger for internal and external restrictions. Replace the restricted cooler if necessary.
	Fuel supply is not adequate.	Locate and correct the restriction in the fuel lines to the engine.
	Stop circuit malfunction in the fire pump controller or field wiring.	In AUTO mode operation, the fire pump engine stops upon loss of signal power from the fire pump controller. Check stop circuit in Fire Pump Controller.
7.1.20 Engine Will Not Shut Off Remotely	Stop circuit malfunction in the fire pump controller or field wiring.	Correct any faults. Check for short to voltage on the signal wiring from the fire pump controller to the engine control panel. Correct any faults. Check operation of the switch contacts of the AUTO/MANUAL mode switch at the operator control panel. Replace the switch if the switch contacts fail to operate properly.
	Electronic fault codes are active.	For instructions on how to read active fault codes, see Section 5 - Operation , the fault code table in this chapter, or contact a Cummins Authorized Repair Facility.
	Engine running on fumes drawn into the air intake.	Identify and isolate the source of the combustible fumes. Contact an Authorized Cummins Repair Facility.

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.21 Engine Will Not Shut Off Locally	Inadvertent power source is present from the fire pump controller.	In MANUAL Mode operation, the fire pump engine stops when the AUTO/MANUAL Mode Switch is returned to the AUTO Mode.
	Electronic fault codes are active.	Check for inadvertent voltage on the wiring to terminal board at the operator control panel. For instructions on how to read active fault codes, see Section 5 - Operation , the fault code table in this chapter, or contact a Cummins Authorized Repair Facility.
	Engine running on fumes drawn into the air intake.	Identify and isolate the source of the combustible fumes.
7.1.22 Fuel Consumption is Excessive	Fuel is leaking.	Check the fuel lines, fuel connections, and fuel filters for leaks. Check the fuel lines to the supply tanks. Repair any leaks.
	Poor-quality fuel is being used.	Assure good-quality no. 2 diesel fuel is being used.
	Defective or clogged injection nozzle.	Replace the defective or clogged injection nozzle.
	Incorrect injection timing.	Adjust injection timing.
	Injection pump is adjusted incorrectly causing excessive injection.	Adjust or replace the injection pump.
	Air intake or exhaust leaks.	Check for loose or damaged piping connections and missing pipe plugs. Check the turbo-charger and exhaust manifold mounting. Repair any leaks.
	Air intake system restriction is above specification.	Check the air intake system for restriction. Refer to Check Air Cleaner Service Indicator in Section 6 - Maintenance . Replace the air filter as necessary.

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.23 Fuel or Engine Oil Leaking From Exhaust Manifold	Intake air restriction is high.	Check the air intake system for restriction. Refer to Check Air Cleaner Service Indicator in Section 6 - Maintenance . Replace the air filter if required.
	Turbocharger drain line is restricted.	Remove the turbocharger drain line and check for restriction. If required, clean or replace the drain line.
	Turbocharger oil seal is leaking.	Check the turbocharger for oil seals and for leaks. Refer to the Turbocharger Leaks Engine Oil or Fuel symptoms entries in this section.
7.1.24 Engine Oil is Contaminated	Bulk oil supply is contaminated.	Check the oil supply. Replace it is necessary. Drain the oil and replace with non-contaminated oil. Also, replace the oil filter. Refer to Change Engine Oil and Filters in Section 6 - Maintenance .
	Fuel is present in the engine oil.	Refer to the Fuel in Engine Oil in this section.
	Coolant is present in the engine oil.	Refer to the Coolant in Engine Oil symptom tree in this section.
	Metal is present in the engine oil.	Contact an Authorized Cummins Repair Facility.

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.25 Engine Oil Consumption is Excessive	Verify the oil consumption rate.	Check the amount of oil added versus the operating hours.
	Engine crankcase overfilled.	Remove excess oil and recalibrate dipstick.
	External engine leak is present.	Inspect the engine and its components for seal, gasket, tappet cover, oil cooler, or drain cocks leaks. Repair or correct any leaks.
	Crankcase ventilation system is plugged.	Check and clean the crank case breather and vent tube per the instructions in Section 6 - Maintenance .
	Turbocharger oil seal is leaking.	Check the turbocharger compressor and turbine seals. Contact an Authorized Cummins Repair Facility.
	Lubricating oil cooler is leaking.	Check for engine oil in the coolant. Refer to the Engine Oil in the Coolant in this section. Contact an Authorized Cummins Repair Facility.
	Engine oil does not meet specifications for operating conditions.	Change the oil and filters per the instructions in Section 6 - Maintenance .
	Engine oil drain interval is excessive.	Verify the correct engine oil drain interval. Refer to Change Engine Oil and Filters in Section 6 - Maintenance .
	Piston, cylinder liner, or piston rings are worn or damaged.	Check for air intake system leaks. Contact an Authorized Cummins Repair Facility.
	Piston rings are not seated correctly (after an engine rebuild or piston installation).	Check blowby. If blowby is excessive, check the piston rings for correct seating. Contact an Authorized Cummins Repair Facility.

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.26 Lubrication Oil in the Coolant	Bulk coolant supply is contaminated.	Check the coolant expansion tank per the instructions in Section 6 - Maintenance . Drain the coolant and replace with non-contaminated coolant. Refer to Drain and Flush Cooling System in Section 6. Replace the coolant filter. Refer to Change Coolant Filter in Section 6 - Maintenance .
	Engine oil cooler is malfunctioning.	Check the oil cooler. Contact an Authorized Cummins Repair Facility.
	Cylinder head gasket damaged or leaking.	Contact an Authorized Cummins Repair Facility.
	Cylinder head is cracked or porous.	Remove intake manifold. Remove exhaust manifold. Check for evidence of coolant leak. If necessary, operate engine at idle. Pressure-test the cylinder head. Contact an Authorized Cummins Repair Facility.
	Cylinder block is cracked or porous.	Remove the oil pan. Pressure-test the cooling system to check for leaks. Contact an Authorized Cummins Repair Facility.
7.1.27 Engine Overspeed Trip NOTE: <i>An engine overspeed trip occurs when the engine's speed exceeds the value specified on the Factory Setting Tag described in Section 2 - Description. The trip isolates the fuel supply to the engine and it stops immediately. The trip is indicated on the local control panel and inside the local control panel on the speed switch. Additionally, a trip output is supplied to the fire protection system controller for remote display.</i>	Engine operated at too great a speed due to catastrophic load failure such as pipe break, pump mechanical failure, or loss of suction.	Correct the cause of the load failure. Contact a Cummins Authorized Repair Facility.
	Engine actually operated at too great a speed due to configuration error.	Check rated speed setting as specified on the Factory Setting Tag. Refer to Rated Speed Set Point Adjustment and Testing in Section 6 - Maintenance .
	Overspeed switch is set at too low a set point.	Check overspeed speed setting as specified on the Factory Setting Tag. Refer to Overspeed Set Point Adjustment and Testing in Section 6 - Maintenance .
	Speed switch wiring failure has occurred.	Check continuity and insulation from ground for the signal power wiring and ground wiring to the speed switch. Replace defective components and repair electrical faults.

Troubleshooting Chart (Continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
7.1.27 Engine Overspeed Trip (continued)	Speed switch failure has occurred.	If the speed switch fails to operate as per Overspeed Set Point Adjustment and Testing in Section 6 - Maintenance , replace the speed switch. Contact an Authorized Cummins Repair Facility.
7.1.28 Tachometer Does not Indicate Engine Speed	<p>An electrical fault exists in the tachometer power and grounding circuits.</p> <p>An electrical fault exists in the speed sensor input circuit.</p>	<p>Check continuity and insulation from ground for the power wiring and ground wiring to the tachometer. Contact an Authorized Cummins Repair Facility. Replace defective components and repair electrical faults.</p> <p>This fault may also cause a failure in the crank terminate signal to the fire protection system controller. Check continuity and insulation from ground for the speed sensor circuit. Contact an Authorized Cummins Repair Facility. Replace defective components and repair electrical faults.</p>
7.1.28 Tachometer Does not Indicate Engine Speed (continued)	<p>The speed sensor has failed.</p> <p>The tachometer has failed.</p>	<p>With the engine running, check the signal from the speed sensor with an oscilloscope or pulse counter. Replace the speed sensor if it has failed. Contact an Authorized Cummins Repair Facility.</p> <p>Check the operation of the tachometer with a pulse generator. Replace the tachometer if it has failed. Contact an Authorized Cummins Repair Facility.</p>



Section 8 - Component Parts and Assemblies

8.1 Part Ordering Information

Replacement parts for the Cummins Inc. equipment are manufactured to the same quality standards and specifications as the original equipment. Unapproved substitution may result in poor performance, reduced service life, lost production or unsafe operation.

Cummins Inc. relies on the best and most cost effective shipping methods, unless specific instructions or requirements are requested by the customer. When ordering parts please be prepared to provide the following information.

PART REQUESTS REQUIRE:

1. Model and serial number.
2. Part description by name or number
3. Quantity required.
4. Purchase order number.

NOTE: *A purchase order number is desirable, even if the part(s) are supplied on a Returned Goods Authorization (RGA) issue number. A purchase order number helps Cummins NPower Inc. and its customer track the parts and necessary credits.*

8.2 Routine Service and Parts

Personnel at Cummins Authorized Repair Locations can assist you with the correct operation and service of your engine. Cummins has a worldwide service network of more than 5,000 Distributors and Dealers who have been trained to provide sound advice, expert service, and complete parts support.

Check the telephone directory yellow pages or refer to the directory in this section for the nearest Cummins Authorized Repair Location.

8.3 Emergency Repairs and Technical Service

The Cummins Customer Assistance Center provides a 24-hour, toll free telephone number to aid in technical and emergency service when a Cummins Authorized Repair Location can not be reached or is unable to resolve an issue with a Cummins product.

If assistance is required, call Toll-Free: 1-800-DIESELS (1-800-343-7357) Includes all 50 states, Bermuda, Puerto Rico, Virgin Islands, and the Bahamas.

Outside of North America contact your Regional Office. Telephone numbers and addresses are listed in the International Directory.

Refer also to the Cummins Inc. web site at www.cummins.com

8.4 Recommended Spares Inventory

To minimize downtime and increase productivity, Cummins Inc. recommends maintaining a stock of spare parts critical to uninterrupted engine operation. Shipping costs can be lower using ground transportation rather than overnight or next day air freight. For this reason Cummins Inc. can provide a list of recommended spare parts. Contact the Cummins Authorized Repair Location for additional information.

Section 8.5 - Assembly Drawings







Description	Drawing No.	Sheet No	Revision Level
Drawing, Installation, FirePump, CFP15E-F10-F40 (Qsx)	8715		E
Options, Engine FirePump, G-Drive, CFP15E-F10-F40 (Qsx)	8742		B
Drawing, Installation, FirePump, CFP15E-F50-F70 (Qsx15-G9)	11711		E
Options, Engine FirePump, G-Drive, CFP15E-F50-F70 (Qsx-G9)	11712		-
Assembly, Engine Mounting, CFP15E	10835		C
Assembly, Heat Exchanger CFP15E CFP15E-F10-F40 (Qsx)	11492-01		N
Assembly, Heat Exchanger CFP15E CFP15E-F50-F70 (Qsx)	11492-02		N
Assembly, Coolant Heater, CFP15E	10849		G
Tube, Piping Water	10915		C
Assembly, Raw Water Loop CFP15E	10913		F
Assembly, Raw Water Horizontal Loop 1 1/4"	10912		G
Assembly, Raw Water Vertical Loop 1 1/4"	11707		E
Assembly, Fuel Plumbing CFP15E	10842		H
Assembly, Guarding, CFP15E	10844		D
Assembly, Air Cleaner, CFP15E	10856		C
Assembly, Sensor Package, CFP15E	9572-01		C
Assembly, Operator Station, CFP15E	10826		G
Assembly, Panel, Instrument, 12VDC Effective Date to 08-08	10452		E
Assembly, Panel, Instrument, 12VDC Effective Date to 09-08	13236		-
Assembly, Panel, Instrument, 24VDC Effective Date to 08-08	10453		E
Assembly, Panel, Instrument, 24VDC Effective Date to 09-08	13237		-
Exhaust, 6" ASA Flange x 18"L, CFP15E-F10-F40	9514		D
Exhaust, 6" ASA Flange x 18"L, CFP15E-F50-F70	6735-35		AW
Exhaust, 6" ASA SLIP x 18"L, CFP15E-F50-F70	7833-09		G
Kit, Loose Wires, Qsx Fire Pump	9768		F
Assembly, Redundant ECM CFP15E	10846		C
Assembly, Secondary ECM Switch	10748	1-4	D
Bracket, Lifting & ECM Mounting	10895		B
Assembly, ECM Cooler & Mount CFP15E	10900		B
Harness, CFP15E	11829-01	1-2	C
Harness, CFP15E	11829-02	1-2	C
Harness, CFP15E	11829-03	1-2	C
Harness, CFP15E	11829-04		C
Assembly, Secondary ECM, CFP15E Schematic	11829 Schem		-
Schematic, Control Panel	10423	1-6	E
Harness, Engine	8513	1-2	L
Assembly, Stub Shaft & Guard CFP15E	12590		-
Assembly, Stub Shaft	11940		A
Guard, Flywheel Stub Shaft CFP15E	12591		-
Assembly, Drive Shaft 1810	13422		
Assembly, Drive Shaft U3172	13430		-
Assembly, Telescoping Shaft Guard (1810)	14161		
Assembly, Telescoping Shaft Guard (U3172)	14156		-

The most current revisions to these drawings and related documents are accessible at: <http://www.cumminsfirepower.com/products.html>.

Section 8.5 - Assembly Drawings

THIS PAGE INTENTIONALLY LEFT BLANK

BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	ENGINE, QSX15-C665, SPEC FOR FIREPUMP	8742-QSX15-C665
2	1	EXHAUST, 90, HALF MARMON, FIREPUMP, 5" TURBO OUTLET	9514-06
3	1	ASSEMBLY, OPERATORS STATION, QSX15, FIREPUMP	10826
4	1	ASSEMBLY, SUPPORT, CFP15E FIREPUMP	10835
5	1	ASSEMBLY, FUEL PLUMBING, CFP15E	10842
6	1	ASSEMBLY, GUARDING, CFP15E FIREPUMP	10844
7	1	ASSEMBLY, REDUNDANT ECM, CFP15E FIREPUMP	10846
8	1	ASSEMBLY, COOLANT HEATER, CFP15E FIREPUMP	10849
9	1	ASSEMBLY, AIR CLEANER, CFP15E, FIREPUMP	10856-01
10	1	MISC PIPING, CFP15, FIREPUMP	10913
11	1	ASSEMBLY, HEAT EXCHANGERS, CFP15E FIREPUMP	11492-01
12	1	BRACKET, MOUNTING, GUARD, FIREPUMP	8592
13	1	BRACKET, RADIATOR TUBE	11581
14	2	FUEL LINE, 12" EXTENSION, #10 FEM JIC X #10 221FR X 3/4" NPT	14400-011



This document contains confidential and trade secret information, is the property of Cummins Fire Power LLC and is loaned to the customer in confidence. It is to be used for the purpose of manufacturing and assembly only. It is not to be reproduced, copied, or distributed in any form without the express written permission of Cummins Fire Power LLC. If you are not an authorized user, you are not to use this document. If you are an authorized user, you are to use this document in accordance with the terms and conditions of the license agreement. If you are not an authorized user, you are to return this document to Cummins Fire Power LLC. If you are an authorized user, you are to use this document in accordance with the terms and conditions of the license agreement. If you are not an authorized user, you are to return this document to Cummins Fire Power LLC. If you are an authorized user, you are to use this document in accordance with the terms and conditions of the license agreement.

Cummins Fire Power
CUMMINS FIRE POWER LLC
CORPORATE OFFICE
1600 BUEKLE ROAD
WHITE BEAR LAKE, MN
WWW.CUMMINSFIREPOWER.COM

CUSTOM DESIGN
AND UPFIT CENTER
875 LAWRENCE DRIVE
DEPERE, WISCONSIN


ASSEMBLY, POWER MODULE
CFP15E-F10/20/30/40

DWG UNITS: IN/LB/S
SCALE: 0.100
EST WEIGHT: 4310.855

DRAWN BY: S.DANFORTH
PRO-ENGINEER
SHEET 1 OF 1

DATE: -
REF DRWG:
DRAWING NO: 8715


REV	DATE	DESCRIPTION OF REVISION	REV BY	DATE
0	2009-171	VIEW UPDATES. REV PER TITLE BLOCK	DAVE N	08MAY2009
ENF				









IMPERIAL UNITS	METRIC UNITS
INCHES	MILLIMETERS
1/8"	3.175
1/4"	6.350
3/8"	9.525
1/2"	12.700
5/8"	15.875
3/4"	19.050
1"	25.400
1 1/4"	31.750
1 1/2"	38.100
2"	50.800
2 1/2"	63.500
3"	76.200
3 1/2"	88.900
4"	101.600
4 1/2"	114.300
5"	127.000
5 1/2"	139.700
6"	152.400
6 1/2"	165.100
7"	177.800
7 1/2"	190.500
8"	203.200
8 1/2"	215.900
9"	228.600
9 1/2"	241.300
10"	254.000
10 1/2"	266.700
11"	279.400
11 1/2"	292.100
12"	304.800
12 1/2"	317.500
13"	330.200
13 1/2"	342.900
14"	355.600
14 1/2"	368.300
15"	381.000
15 1/2"	393.700
16"	406.400
16 1/2"	419.100
17"	431.800
17 1/2"	444.500
18"	457.200
18 1/2"	469.900
19"	482.600
19 1/2"	495.300
20"	508.000
20 1/2"	520.700
21"	533.400
21 1/2"	546.100
22"	558.800
22 1/2"	571.500
23"	584.200
23 1/2"	596.900
24"	609.600
24 1/2"	622.300
25"	635.000
25 1/2"	647.700
26"	660.400
26 1/2"	673.100
27"	685.800
27 1/2"	698.500
28"	711.200
28 1/2"	723.900
29"	736.600
29 1/2"	749.300
30"	762.000
30 1/2"	774.700
31"	787.400
31 1/2"	800.100
32"	812.800
32 1/2"	825.500
33"	838.200
33 1/2"	850.900
34"	863.600
34 1/2"	876.300
35"	889.000
35 1/2"	901.700
36"	914.400
36 1/2"	927.100
37"	939.800
37 1/2"	952.500
38"	965.200
38 1/2"	977.900
39"	990.600
39 1/2"	1003.300
40"	1016.000
40 1/2"	1028.700
41"	1041.400
41 1/2"	1054.100
42"	1066.800
42 1/2"	1079.500
43"	1092.200
43 1/2"	1104.900
44"	1117.600
44 1/2"	1130.300
45"	1143.000
45 1/2"	1155.700
46"	1168.400
46 1/2"	1181.100
47"	1193.800
47 1/2"	1206.500
48"	1219.200
48 1/2"	1231.900
49"	1244.600
49 1/2"	1257.300
50"	1270.000
50 1/2"	1282.700
51"	1295.400
51 1/2"	1308.100
52"	1320.800
52 1/2"	1336.500
53"	1349.200
53 1/2"	1364.900
54"	1377.600
54 1/2"	1390.300
55"	1403.000
55 1/2"	1418.700
56"	1431.400
56 1/2"	1437.100
57"	1445.000
57 1/2"	1460.700
58"	1474.400
58 1/2"	1484.100
59"	1497.800
59 1/2"	1507.500
60"	1520.000
60 1/2"	1533.700
61"	1546.400
61 1/2"	1559.100
62"	1571.800
62 1/2"	1585.500
63"	1599.200
63 1/2"	1610.900
64"	1626.400
64 1/2"	1637.100
65"	1651.600
65 1/2"	1664.300
66"	1678.000
66 1/2"	1691.700
67"	1706.400
67 1/2"	1722.100
68"	1736.000
68 1/2"	1748.700
69"	1761.600
69 1/2"	1778.300
70"	1792.000
70 1/2"	1805.700
71"	1818.400
71 1/2"	1831.100
72"	1846.800
72 1/2"	1859.500
73"	1875.200
73 1/2"	1886.900
74"	1902.400
74 1/2"	1918.100
75"	1934.000
75 1/2"	1949.700
76"	1966.400
76 1/2"	1982.100
77"	1999.200
77 1/2"	2004.900
78"	2017.600
78 1/2"	2030.300
79"	2044.000
79 1/2"	2056.700
80"	2072.000
80 1/2"	2083.700
81"	2099.200
81 1/2"	2110.900
82"	2126.400
82 1/2"	2137.100
83"	2153.600
83 1/2"	2169.300
84"	2180.000
84 1/2"	2196.700
85"	2212.800
85 1/2"	2228.100
86"	2244.000
86 1/2"	2260.700
87"	2276.800
87 1/2"	2283.100
88"	2299.200
88 1/2"	2310.900
89"	2322.400
89 1/2"	2327.100
90"	2340.000
90 1/2"	2356.700
91"	2371.200
91 1/2"	2383.300
92"	2402.400
92 1/2"	2415.900
93"	2433.600
93 1/2"	2446.100
94"	2464.000
94 1/2"	2476.700
95"	2496.000
95 1/2"	2507.300
96"	2518.400
96 1/2"	2530.100
97"	2549.600
97 1/2"	2552.700
98"	2571.200
98 1/2"	2575.300
99"	2584.000
99 1/2"	2597.700
100"	2608.000
100 1/2"	2620.700
101"	2632.800
101 1/2"	2638.100
102"	2648.000
102 1/2"	2653.700
103"	2668.800
103 1/2"	2669.300
104"	2680.000
104 1/2"	2685.700
105"	2696.000
105 1/2"	2701.300
106"	2712.800
106 1/2"	2717.100
107"	2729.600
107 1/2"	2732.700
108"	2746.400
108 1/2"	2748.100
109"	2763.200
109 1/2"	2759.300
110"	2780.000
110 1/2"	2785.700
111"	2801.600
111 1/2"	2811.300
112"	2823.200
112 1/2"	2826.900
113"	2844.800
113 1/2"	2842.100
114"	2866.400
114 1/2"	2857.700
115"	2888.000
115 1/2"	2883.300
116"	2909.600
116 1/2"	2898.900
117"	2931.200
117 1/2"	2914.500
118"	2952.800
118 1/2"	2930.100
119"	2974.400
119 1/2"	2945.700
120"	2996.000
120 1/2"	2961.300
121"	3017.600
121 1/2"	2976.900
122"	3039.200
122 1/2"	2992.500
123"	3060.800
123 1/2"	3008.100
124"	3082.400
124 1/2"	3023.700
125"	3104.000
125 1/2"	3039.300
126"	3125.600
126 1/2"	3054.900
127"	3147.200
127 1/2"	3070.500
128"	3168.800
128 1/2"	3086.100
129"	3190.400
129 1/2"	3101.700
130"	3212.000
130 1/2"	3117.300
131"	3233.600
131 1/2"	3132.900
132"	3255.200
132 1/2"	3148.500
133"	3276.800
133 1/2"	3164.100
134"	3298.400
134 1/2"	3179.700
135"	3320.000
135 1/2"	3195.300
136"	3341.600
136 1/2"	3210.900
137"	3363.200
137 1/2"	3226.500
138"	3384.800
138 1/2"	3242.100
139"	3406.400
139 1/2"	3257.700
140"	3428.000
140 1/2"	3273.300
141"	3449.600
141 1/2"	3288.900
142"	3471.200
142 1/2"	3304.500
143"	3492.800
143 1/2"	3320.100
144"	3514.400
144 1/2"	3335.700
145"	3536.000
145 1/2"	3351.300
146"	3557.600
146 1/2"	3366.900
147"	3579.200
147 1/2"	3382.500
148"	3600.800
148 1/2"	3398.100
149"	3622.400
149 1/2"	3413.700
150"	3644.000
150 1/2"	3429.300
151"	3665.600
151 1/2"	3444.900
152"	3687.200
152 1/2"	3460.500
153"	3708.800
153 1/2"	3476.100
154"	3730.400
154 1/2"	3491.700
155"	3752.000
155 1/2"	3507.300
156"	3773.600
156 1/2"	3522.900
157"	3795.200
157 1/2"	3538.500
158"	3816.800
158 1/2"	3554.100
159"	3838.400
159 1/2"	3569.700
160"	3860.000
160 1/2"	3585.300
161"	3881.600
161 1/2"	3600.900
162"	3903.200
162 1/2"	3616.500
163"	3924.800
163 1/2"	3632.100
164"	3946.400
164 1/2"	3647.700
165"	3968.000
165 1/2"	3663.300
166"	3989.600
166 1/2"	3678.900
167"	4011.200
167 1/2"	3694.500
168"	4032.800
168 1/2"	3710.100
169"	4054.400
169 1/2"	3725.700
170"	4076.000
170 1/2"	3741.300
171"	4097.600
171 1/2"	3756.900
172"	4119.200
172 1/2"	3772.500
173"	4140.800
173 1/2"	3788.100
174"	4162.400
174 1/2"	3803.700
175"	4184.000
175 1/2"	3819.300
176"	4205.600
176 1/2"	3834.900
177"	4227.200
177 1/2"	3850.500
178"	4248.800
178 1/2"	3866.100
179"	4270.400
179 1/2"	3881.700
180"	4292.000
180 1/2"	3897.300
181"	4313.600
181 1/2"	3912.900
182"	4335.200
182 1/2"	3928.500
183"	4356.800
183 1/2"	3944.100
184"	4378.400
184 1/2"	3959.700
185"	4400.000
185 1/2"	3975.300
186"	4421.600

[illegible]

B	UPDATE OPTION NUMBERS	PBS	1MAY2008
REV	DESCRIPTION OF REVISION	BY	DATE

<p>ALL RIGHTS TO MANUFACTURE, COPY OR DISPOSE OF THIS DRAWING OR ITS CONTENTS ARE RESERVED UNLESS OTHERWISE SPECIFIED IN WRITING BY CUMMINS NPPOWER, LLC</p>	 <div> <p>CUMMINS NPPOWER CORPORATE OFFICE 1600 BLUERIDGE ROAD WHITE BEAR LAKE, MN WWW.NPOWER.CUMMINS.COM</p> <p>CUMMINS FIRE POWER DESIGN CENTER 875 LAWRENCE DRIVE DEPEERE, WISCONSIN WWW.CUMMINSFIREPOWER.COM</p> </div>		
<p>UNLESS OTHERWISE NOTED</p> <p>ALL DIMENSIONS ARE IN INCHES</p> <p>APPLY MACHINE TOLERANCES</p> <p>X = ± 0.06</p> <p>XX = ± 0.010</p> <p>XXX = ± 0.001</p> <p>APPLY WELDED TOLERANCES</p> <p>X = ± 0.25</p> <p>XX = ± 0.12</p> <p>XXX = ± 0.06</p>	<p>DWG SCALE: NTS</p> <p>PLLOT SCALE:</p> <p>DESCRIPTION</p> <p>SPECIFICATION, ENGINE ASSEMBLY</p> <p>REFERENCE:</p> <p>CFP15E-F10 - F40</p>		
	<p>DRAWN BY: S.DANFORTH</p> <p>APPD BY: S.DANFORTH</p>	<p>DATE: 24AUG2006</p> <p>DATE: 07JUL2007</p>	<p>DRAWING NUMBER:</p> <p>8742</p>

BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	ASSEMBLY, OPERATORS STATION, QSX15, FIREPUMP	10826
2	1	ASSEMBLY, SUPPORT, CFP15E FIREPUMP	10835
3	1	ASSEMBLY, FUEL PLUMBING, CFP15E	10842
4	1	ASSEMBLY, GUARDING, CFP15E FIREPUMP	10844-02
5	1	ASSEMBLY, REDUNDANT ECM, CFP15E FIREPUMP	10846
6	1	ASSEMBLY, COOLANT HEATER, CFP15E FIREPUMP	10849
7	1	ASSEMBLY, AIR CLEANER, CFP15E, FIREPUMP	10856-02
8	1	MISC PIPING, CFP15, FIREPUMP	10913
9	1	ASSEMBLY, HEAT EXCHANGERS, CFP15E FIREPUMP	11492-02
10	1	ENGINE, QSX15-C665, SPEC FOR FIREPUMP	11712-QSX15-G9-755
11	1	BRACKET, RADIATOR TUBE	11581
12	1	DECAL, BELT ROUTING, CFP15E	11816
13	1	DECAL, VALVE ORIENTATION, CFP15E	11818
14	1	ELBOW, FLEX, 90° FLARED x FLANGE, 6" TURBO, GTE #10-761-618	13572
15	2	FUEL LINE, 12" EXTENSION, #10 FEM JIC X #10 221FR X 3/4" NPT	14400-011



This document contains confidential and trade secret information, is the property of Cummins Fire Power LLC and is loaned to the recipient in confidence. The recipient shall not disclose, copy, reproduce, or otherwise use this document or its contents for any purpose other than that for which it was loaned. The recipient shall return this document to Cummins Fire Power LLC upon completion of the loan. If the recipient discloses, copies, reproduces, or otherwise uses this document or its contents for any purpose other than that for which it was loaned, the recipient shall be liable for all damages, including reasonable attorneys' fees, incurred by Cummins Fire Power LLC. ©2009 Cummins Fire Power LLC

Cummins Fire Power	CUMMINS FIRE POWER LLC CORPORATE OFFICE 1600 BUEKLE ROAD WHITE SEAR LAKE, MN WWW.CUMMINSFIREPOWER.COM	CUSTOM DESIGN AND UPFIT CENTER 875 LAWRENCE DRIVE DEPERE, WISCONSIN
---------------------------	---	--


ASSEMBLY, POWER MODULE
CFP15E-F50/60/70 HIGH HORSE POWER

DWG UNITS: IN/LB/S
SCALE: 0.100
EST WEIGHT: 4219.488


DRAWN BY: S.DANFORTH	DATE: -
PRO-ENGINEER	REF DRWG:
SHEET 1 OF 1	DRAWING NO: 11711

REV	DESCRIPTION OF REVISION	REV BY	DATE
D	2009-171	DAVE N	08MAY2009
ENF	VIEW UPDATES, REV PER TITLE BLOCK		

REFERENCE BOX FOR BOLT TORQUE VALUES		
FRONT LEGS-PN:10836	BOLT, 3/4"10 x 2-3/4"L - PN:1717	375 FT/LBS
BACK LEGS-PN:13486	BOLT, 5/8"11 x 1-1/4"L - PN:1658	210 FT/LBS




BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	SUPPORT, ENGINE, FRONT, CFP15E FIREPUMP	10836
C 2	2	BRACKET, REAR LEG, CFP15E	13486



NOTE:
FRONT ENGINE MOUNT
ON ENGINE IS SLOTTED.
FRONT SUPPORT TO BE
LOCATED PER DIMENSION.

		ADDED REFERENCE BOX FOR TORQUE SPEC.-NO ENF REQUIRED	MAC	01-12-2009
C	2008-501	REPLACED 10950 WITH 13486	S DUBICK	12/10/08
REV	ENF	DESCRIPTION OF REVISION	REV BY	DATE

This document contains confidential and trade secret information, is the property of Cummins Fire Power LLC and is given to the receiver in confidence. The receiver, by receiving and retaining the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins Fire Power LLC



CUMMINS FIRE POWER LLC
CORPORATE OFFICE
1600 BUERKLE ROAD
WHITE BEAR LAKE, MN
WWW.CUMMINSFIREPOWER.COM

CUSTOM DESIGN
AND UPFIT CENTER
875 LAWRENCE DRIVE
DEPERE, WISCONSIN

ASSEMBLY, SUPPORT
CFP15E FIREPUMP

DWG UNITS:
IN/LB/S

SCALE: 0.125

EST WEIGHT: 142.256

DRAWN BY: S.DANFORTH

PRO-ENGINEER

DATE: APR2006

REF DRWG:

SHEET
1 OF 1

DRAWING NO: 10835





NOTES:
ASSEMBLY DESIGNED TO BE BENCH ASSEMBLED
MOUNTING BRACKETS AND HEAT EXCHANGERS SHOULD
BE ASSEMBLED PRIOR TO MOUNTING ON ENGINE
LIFT HOLE PROVIDED FOR SUSPENDING WITH JIB CRANE

MOST PORTS ARE ORB, NOT NPT
ORB PORTS DO NOT GET THREAD SEALER
A BACKUP WRENCH IS NEEDED ON ALL PORTS
ALL ORB PORTS ARE TO HAVE O-RING GREASED PRIOR
TO ASSEMBLY OF ADAPTER INTO PORT FOR SEALING PURPOSES

ALL -20 AND -24 FITTINGS ARE TO BE TIGHTENED
TO 1 FFFT (FLAT FROM FINGER TIGHT)

ALL -6 ORB FITTINGS ARE TO BE 1.5 FFFT

CAC HOSE & CLAMPS SUPPLIED
WITH ENGINE FROM FACTORY



BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	PLUG, ZINC W/ BRASS SUPPORT, 1/2" NPT, CHAMP #500129	9750
2	1	COOLER, JACKET WATER, CFP15 E FIREPUMP	10847
3	1	HEAT EXCHANGER, CAC,, CFP15E FIREPUMP	10848
4	1	TUBE, ENGINE COOLANT, LOWER, CFP15E	10891
5	1	TUBE, COOLANT, UPPER, CFP15E FIREPUMP	10892
6	1	TUBE, CAC, TURBO SIDE, CFP15E FIREPUMP	10893
7	1	TUBE, CAC, 1M SIDE, CFP15E FIREPUMP	10894
8	2	ELBOW, RAW WATER, FLARE X HOSE BEAD, STEEL, HX TO HX	10905
9	1	WELDMENT, HEAT EXCHANGER MOUNTING, -	11486
10	1	HOSE, WATER FILL, CFP15E	12950
11	1	HUMP HOSES & SPRING CLAMPS, SUPPLIED ON ENGINE SPEC.	1C.1080
12	1	HOSE, VENT LINE, 1/4" ID x 30"	R-801-4
13	1	HOSE, VENT LINE, 1/4" ID x 14"	R-801-4
14	1	HOSE, VENT LINE, 1/4" ID x 18"	R-801-4
15	8	1/2-13 NUT, -	1.2.13.NC.NUT
16	1	ADAPTER, MALE JIC 37 DEG X MALE SAE ORB, -12	12235-12-12
17	2	ADAPTER, MALE JIC 37 DEG X MALE SAE ORB, -24-20	12235-24-20
18	2	HOSE, CONNECTION, 2.5 ID X 6", 77250GL	8933
19	1	TANK, SURGE, CFP15E, FIREPUMP	10865
20	1	DETAIL, BRKT, HX MOUNTING, CFP15E FIREPUMP	11487
21	4	BRACKET, HEAT EXCHANGER MOUNTING, BACK	11488
22	1	FTG, ORB (M) x NPT (M), 20-1 1/4	12163-20-20
23	1	FTG, ORB (M) x NPT (M), 24-1 1/2	12163-24-24
24	1	FTG, STR, -24 JIC X -20 NPT	12238-24-20
25	1	TEE, 1 1/4" NPT FEMALE, BLK STEEL	12386
26	1	TEE, M BRANCH, -4 NPT	12533-4
27	1	FITTING, REDUCER, 1 1/4 MALE NPTF X 1/2 FEMALE NPTF	12710
28	8	1/2-13X12 THREADED STUD, 1-1/2" THREAD ON EACH END	12791
29	1	BRACKET, CAC SUPPORT, CFP15E LOW HORSE POWER	12886
30	1	SIGHT GLASS, 1/2" NPT	12979
31	1	CLAMP,P-STYLE,1-1/4", CAN ORDER LTL-SCPV20627 AS ALTERNATE	13746
32	1	HOSE, SILICONE, 1.50" I.D. DAYCO 78150GL	14931
33	2	CLAMP, WORM, 1 3/4" NOM., 2 1/8" HOSE OD	14990-28
34	1	U-BOLT, 2.50 DIA, PLATED	16530
35	1	HOSE, RUBBER, 2.50 90 DEGREE, GATES 21115	21115
36	1	HOSE, RUBBER, 2.50 90 DEGREE, GATES 21891	21891
37	1	DRAIN LINE HOSE, 5/16" ID HOSE	27003_X.72INCH
38	8	CLAMP, WORM, 2 1/2" I.D. 2 7/8" O.D. HOSE, 2.06 - 3.00	14990-40
39	1	ELBOW, 90 DEG, JIC X METRIC PORT, PARKER OR EQUIV.	12275-12m27
40	6	ADAPTER, 1/4" HOSE X 1/4" NPT	R-30882-4-4
41	3	ELBOW, 3/4" NPT X #4 FLARE	R-149F-4-4
42	1	ELBOW 45°, 3/4" NPT X #4 FLARE	R-159F-4-4
43	2	ADAPTER, FLARED, 1/4" NPT x #4 FLARE	R-48F-4-4
44	3	U-BOLT, 4"	U400

NOTES:

- ALL FITTINGS TO BE POSITIONED AS SHOWN.
- ALL PARTS TO BE CLEAN BEFORE ASSEMBLY.
- ALL OPENINGS ARE TO BE CAPPED OR PLUGGED AFTER ASSEMBLY.
- CHECK ALL FITTINGS FOR O-RING BEFORE MAKING CONNECTIONS.

LOW HORSE POWER CFP15E-F10/20/30/40






N	2010-049	16530 WAS U250	DAN	29-JAN-10	<div><div>This document contains confidential and trade secret information, is the property of Cummins Fire Power LLC and is being disseminated in confidence. For internal use only. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage and retrieval system, without prior written permission from Cummins Fire Power LLC. All rights reserved. © 2010 Cummins Fire Power LLC. All other rights reserved.</div><div>ANGULAR DIMENSIONS ± 1°IMPERIAL UNITSMETRIC UNITS</div><div>THIRD ANGLE PROJECTION</div><div>DATE: 09/16/09</div></div>
M	2009-593	12533-4 WAS LTL-28282. ADDED U250	DAN	18-NOV-09	
LI	2009-537	RE-ORIENTATED PLUMBING TEE ON HX INLET	DAN	03-NOV-09	
L	2009-349	REMOVE 3071049 & 12975-0425 FROM BOW (ON ENGINE), 10915 ADDED ANODE COMPONENTS TO MAKE COOLING LOOP OPTIONAL	S DUBICK	09/16/09	
REV	ENF	DESCRIPTION OF REVISION	REV BY	DATE	<div><div>ASSEMBLY, HEAT EXCHANGER CFP15E F10-F40</div><div>DWG UNITS: IN/LB/S</div><div>SCALE: 0.166</div><div>EST WEIGHT: 436.278</div></div>

NOTES:
ASSEMBLY DESIGNED TO BE BENCH ASSEMBLED
MOUNTING BRACKETS AND HEAT EXCHANGERS SHOULD
BE ASSEMBLED PRIOR TO MOUNTING ON ENGINE
LIFT HOLE PROVIDED FOR SUSPENDING WITH JIB CRANE

MOST PORTS ARE ORB, NOT NPT
ORB PORTS DO NOT GET THREAD SEALER
A BACKUP WRENCH IS NEEDED ON ALL PORTS
ALL ORB PORTS ARE TO HAVE O-RING GREASED PRIOR
TO ASSEMBLY OF ADAPTER INTO PORT FOR SEALING PURPOSES

ALL -20 AND -24 FITTINGS ARE TO BE TIGHTENED
TO 1 FFFT (FLAT FROM FINGER TIGHT)

ALL -6 ORB FITTINGS ARE TO BE 1.5 FFFT



BILL OF MATERIAL		
ITEM	QTY	DESCRIPTION
1	1	PLUG, ZINC W/ BRASS SUPPORT, 1/2" NPT, CHAMP #500129
2	1	COOLER, JACKET WATER, CFP15 E FIREPUMP
3	1	HEAT EXCHANGER, CAC,, CFP15E FIREPUMP
4	1	TUBE, ENGINE COOLANT, LOWER, CFP15E
5	1	TUBE, COOLANT, UPPER, CFP15E FIREPUMP
6	1	TUBE, CAC, 1M SIDE, CFP15E FIREPUMP
7	2	ELBOW, RAW WATER, FLARE X HOSE BEAD, STEEL, HX TO HX
8	1	WELDMENT, HEAT EXCHANGER MOUNTING, -
9	1	TUBE, CAC OUT, CFP15E-F50 thru F70
10	1	HOSE, WATER FILL, CFP15E
11	1	HOSE, VENT LINE, 1/4" ID x 30"
12	1	HOSE, VENT LINE, 1/4" ID x 14"
13	1	HOSE, VENT LINE, 1/4" ID x 18"
14	8	1/2-13 NUT, -
15	1	ADAPTER, MALE JIC 37 DEG X MALE SAE ORB, -12
16	2	ADAPTER, MALE JIC 37 DEG X MALE SAE ORB, -24-20
17	2	HOSE, CONNECTION, 2.5 ID X 6", 77250GL
18	1	HOSE, COVOLUTED SILICONE CHARGE AIR
19	1	TANK, SURGE, CFP15E, FIREPUMP
20	1	DETAIL, BRKT, HX MOUNTING, CFP15E FIREPUMP
21	4	BRACKET, HEAT EXCHANGER MOUNTING, BACK
22	1	FTG, ORB (M) x NPT (M), 20-1 1/4
23	1	FTG, ORB (M) x NPT (M), 24-1 1/2
24	1	FTG, STR, -24 JIC X -20 NPT
25	1	TEE, 1 1/4" NPT FEMALE, BLK STEEL
26	1	TEE, M BRANCH, -4 NPT
27	1	FITTING, REDUCER, 1 1/4 MALE NPTF X 1/2 FEMALE NPTF
28	8	1/2-13X12 THREADED STUD, 1-1/2" THREAD ON EACH END
29	1	BRACKET, CAC SUPPORT, HHP, CFP15E
30	7	CLAMP, SPRING LOADED T-BOLT, 4.03-4.33
31	1	CLAMP, SPRING LOADED T-BOLT, 4.53-4.83
32	1	SIGHT GLASS, 1/2" NPT
33	1	CLAMP,P-STYLE,1-1/4", CAN ORDER LTL-SCPV20627 AS ALTERNATE
34	1	HOSE, SILICONE, 1.50" I.D. DAYCO 78150GL
35	2	CLAMP, WORM, 1 3/4" NOM., 2 1/8" HOSE OD
36	1	U-BOLT, 2.50 DIA, PLATED
37	1	HOSE, RUBBER, 2.50 90 DEGREE, GATES 21115
38	1	HOSE, RUBBER, 2.50 90 DEGREE, GATES 21891
39	1	DRAIN LINE HOSE, 5/16" ID HOSE
40	8	CLAMP, WORM, 2 1/2" I.D. 2 7/8" O.D. HOSE, 2.06 - 3.00
41	3	HOSE, HUMP, 4" ID x 7.5"L, CAC
42	1	ELBOW, 90 DEG, JIC X METRIC PORT, PARKER OR EQUIV.
43	6	ADAPTER, 1/4" HOSE X 1/4" NPT
44	3	ELBOW, 3/4" NPT X #4 FLARE
45	1	ELBOW 45°, 3/4" NPT X #4 FLARE
46	2	ADAPTER, FLARED, 1/4" NPT x #4 FLARE
47	2	U-BOLT, 4"




NOTES:

- ALL FITTINGS TO BE POSITIONED AS SHOWN.
- ALL PARTS TO BE CLEAN BEFORE ASSEMBLY.
- ALL OPENINGS ARE TO BE CAPPED OR PLUGGED AFTER ASSEMBLY.
- CHECK ALL FITTINGS FOR O-RING BEFORE MAKING CONNECTIONS.


N	2010-049	16530 WAS U250	DAN	29-JAN-10
M	2009-593	12533-4 WAS LTL-28282. ADDED U250	DAN	18-NOV-09
LI	2009-537	RE-ORIENTATED PLUMBING TEE ON HX INLET	DAN	03-NOV-09
L	2009-349	ADD ANODE COMPONENTS FOR COOLING LOOP OPTION	S DUBICK	09/16/09
REV	ENF	DESCRIPTION OF REVISION	REV BY	DATE

UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE: ANGULAR DIMENSIONS ± 1° IMPERIAL UNITS METRIC UNITS THIRD ANGLE PROJECTION DRAWN BY: S.DANFORTH DATE: 03-NOV-09 SCALE: 0.166 EST WEIGHT: 678.728		THIS DOCUMENT CONTAINS CONFIDENTIAL AND TRADE SECRET INFORMATION, IS THE PROPERTY OF CUMMINS FIRE POWER, LLC, AND IS NOT TO BE DISCLOSED OR REPRODUCED IN ANY MANNER WITHOUT THE WRITTEN PERMISSION OF CUMMINS FIRE POWER, LLC. ANY VIOLATION OF THIS POLICY WILL BE PROSECUTED TO THE FULL EXTENT OF THE LAW. CUMMINS FIRE POWER, LLC IS NOT RESPONSIBLE FOR THE CONTENTS OF ANY DOCUMENTS OR INFORMATION RECEIVED FROM ANY OTHER SOURCE. CUMMINS FIRE POWER, LLC IS NOT RESPONSIBLE FOR THE CONTENTS OF ANY DOCUMENTS OR INFORMATION RECEIVED FROM ANY OTHER SOURCE. CUMMINS FIRE POWER, LLC IS NOT RESPONSIBLE FOR THE CONTENTS OF ANY DOCUMENTS OR INFORMATION RECEIVED FROM ANY OTHER SOURCE.	
---	--	--	--



CUMMINS FIRE POWER LLC CORPORATE OFFICE 1600 BLUEPALE ROAD WHITE BEAR LAKE, MN WWW.CUMMINSFIREPOWER.COM		CUSTOM DESIGN AND UPFIT CENTER 875 LAWRENCE DRIVE DEPERE, WISCONSIN	
ASSEMBLY, HEAT EXCHANGER CFP15E F50-F70		DATE: -	
DWG UNITS: IN/LB/S		REF. DRWG:	
SCALE: 0.166		DRAWING NO:	
EST WEIGHT: 678.728		SHEET 1 OF 1	
		11492-02	




BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	TUBE, LOWER, COOLANT HEATER, QSX15-C, HOLLAND CO	10610
G 2	1	HOSE, SILICONE HI-TEMP, 1" ID, 78100GL x 30"	78100GL-30INCH
3	1	BRACKET, COOLANT HEATER, MULTI-UNIT	8143
4	2	SPACER, MOUNTING, SECONDARY ECM	9508
5	1	HEATER, COOLANT, 3000W, ADJ. VOLTAGE, WATLOW 3-10-42-5PA	11577
G 6	2	ELB, 90 DEG, -12 NPT X -12 FMNPT	12195-12-12
7	2	FTG, STR, -1.0 BEADx-.75 NPT	12545-16-12
G 8	1	CLAMP,P-STYLE,1-1/4", CAN ORDER LTL-SCPV20627 AS ALTERNATE	13746
9	6	CLAMP, WORM, 1" NOM., 1 3/8" HOSE OD	14990-16
G 10	1	BRACKET, COOLANT HEATER HOSE STAND OFF	16527
11	1	HOSE, SILICONE, HI-TEMP, 1", P/N 78100GL X LENGTH	78100GL-41NCH
12	1	HOSE, SILICONE, HI-TEMP, 1", P/N 78100GL X LENGTH	78100GL-61NCH



G	2010-049	ADDED 12195-12-12, 16527 & 13746. REV HOSE.	DAN	29-JAN-10
F	2009-349	CORRECTED FITTING ORIENTATION	S DUBICK	09/16/09
REV	ENF	DESCRIPTION OF REVISION	REV BY	DATE


This document contains confidential and trade secret information, is the property of Cummins Fire Power LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins Fire Power LLC					CUMMINS FIRE POWER LLC CORPORATE OFFICE 1600 BUERKLE ROAD WHITE BEAR LAKE, MN WWW.CUMMINSFIREPOWER.COM		CUSTOM DESIGN AND UPFIT CENTER 875 LAWRENCE DRIVE DEPERE, WISCONSIN	
			ASSEMBLY, COOLANT HEATER CFPI5E					
UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE								
ANGULAR DIMENSIONS ± 1°			DWG UNITS:		DRAWN BY: S. DANFORTH		DATE: 18NOV2005	
THIRD ANGLE PROJECTION			IN/LB/S		PRO-ENGINEER		REF DRWG:	
			SCALE: 0.125		SHEET		DRAWING NO:	
			EST WEIGHT: 24.780		1 OF 1		10849	
			MACHINE TOLERANCES .XX : ± 0.010 .XXX : ± 0.005 FORM TOLERANCES .XX : ± 0.030 .XXX : ± 0.015 FAB TOLERANCES .XX : ± 0.060 .XXX : ± 0.030		MACHINE TOLERANCES .X : ± 0.4 .X : ± 0.2 FORM TOLERANCES .X : ± 0.8 .X : ± 0.4 FAB TOLERANCES .X : ± 0.5 .X : ± 0.8			

BEND LOCATION INFO				CORRESPONDING BEND MACHINE INFO					
LOC NUM	LOC X	LOC Y	LOC Z	OFFSET	TWIST	RADIUS	ANGLE		REF MACH NUM
1	0.000	0.000	0.000						
2	0.000	0.000	4.500	2.000		2.500	90.000		1
3	-5.657	-5.657	4.500	4.464	90.000	2.500	45.000		2
4	-5.657	-25.657	4.500	18.964					3




- NOTES:
- 1) TUBE ENDS TO BE CAPPED. CAPS MUST SEAL THE TUBE ID AND REMAIN IN PLACE DURING NORMAL SHIPPING AND HANDLING.
 - 2) FINISHED TUBE MUST BE MARKED WITH CUMMINS NPOWER PART NUMBER.
 - 3) ANY BRAZED END FITTING TO BE SILVER BRAZED.



TUBE END DETAIL:



INSPECTION NOTE	
1 - TUBE ENDS TO BE CAPPED. CAPS MUST SEAL THE TUBE ID AND REMAIN IN PLACE DURING NORMAL SHIPPING AND HANDLING.	
2 - FINISHED TUBE MUST BE MARKED WITH CUMMINS NPOWER PART NO.	
3 - ANY BRAZED END FITTING TO BE SILVER BRAZED	
MATERIAL NOTE	
HYDRAULIC TUBING MATERIAL	Steel
SAE GRADE	316_SS
OUTER DIAMETER	1.500
WALL THICKNESS	0.063
CENTERLINE BEND RADIUS	2.500
TENSILE STRENGTH (PSI)	
MAX PRESSURE (PSI)	


<div>This document contains confidential and trade secret information, is the property of Cummins NPower, LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins NPower, LLC</div>				<div></div>		<div>CUMMINS NPOWER, LLC CORPORATE OFFICE 1600 BUEKLE ROAD WHITE BEAR LAKE, MN WWW.NPOWER.CUMMINS.COM</div>		<div>NPOWER SYSTEMS DESIGN CENTER 875 LAWRENCE DRIVE DEPERE, WISCONSIN</div>											
<div>UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE</div>				<div>TITLE 1: TUBE, MISC PIPING, CFP15 TITLE 2: FIREPUMP</div>															
<div>ANGULAR DIMENSIONS ± 1°</div>		<div>IMPERIAL UNITS</div>		<div>METRIC UNITS</div>		<div>DWG UNITS: IN/LB/S</div>		<div>DRAWN BY: DAVE N APPD BY: -</div>		<div>DATE: 04MAY2006 DATE: -</div>									
<div>THIRD ANGLE PROJECTION</div>		<div>MACHINE TOLERANCES XX : ± 0.005 XX : ± 0.010 XX : ± 0.015 XX : ± 0.020</div>		<div>MACHINE TOLERANCES XX : ± 0.2 XX : ± 0.3 XX : ± 0.4 XX : ± 0.5</div>		<div>FORM TOLERANCES XX : ± 0.005 XX : ± 0.010 XX : ± 0.015 XX : ± 0.020</div>		<div>EST WEIGHT: 6.620</div>		<div>SCALE: 0.380</div>		<div>DO NOT SCALE</div>		<div>SHEET 1 OF 1</div>		<div>DRAWING NO: 10915</div>		<div>REV: C</div>	

REV	DESCRIPTION OF REVISION	REV BY	DATE
C			




E

BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	ASSEMBLY, COOLING LOOP, 1-1/4", HORIZONTAL PUMP	10912
2	1	HOSE, RAW WATER, 28" O.A.L. PARKER 601	14932
3	1	BRACKET, RAW WATER COOLING, 8" LG, FIREPUMP	10916
4	1	BRACKET, RAW WATER COOLING, FIREPUMP	11579
5	2	U-BOLT, 1.75", -	517134



E	2009-171	HOSE WAS TUBE #10905	DAVE N	07MAY2009
REV	ENF	DESCRIPTION OF REVISION	REV BY	DATE

This document contains confidential and trade secret information, is the property of Cummins Fire Power LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins Fire Power LLC



CUMMINS FIRE POWER LLC
CORPORATE OFFICE
1600 BUERKLE ROAD
WHITE BEAR LAKE, MN
WWW.CUMMINSFIREPOWER.COM


CUSTOM DESIGN
AND UPFIT CENTER
875 LAWRENCE DRIVE
DEPERE, WISCONSIN

MISC PIPING, CFPI5
FIREPUMP


UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE

ANGULAR DIMENSIONS ± 1°	IMPERIAL UNITS	METRIC UNITS
THIRD ANGLE PROJECTION	MACHINE TOLERANCES .XX ± 0.010 .XXX ± 0.005	MACHINE TOLERANCES .XX ± 0.4 .XX ± 0.2
	FORM TOLERANCES .XX ± 0.030 .XXX ± 0.015	FORM TOLERANCES .XX ± 0.8 .XX ± 0.4
	FAB TOLERANCES .XX ± 0.060 .XXX ± 0.030	FAB TOLERANCES .XX ± 1.0 .XX ± 0.8



DWG UNITS: IN/LB/S	DRAWN BY: DAVE N PRO-ENGINEER	DATE: 04MAY2006 REF DRWG:
SCALE: 0.125 EST WEIGHT: 89.475	SHEET 1 OF 1	DRAWING NO: 10913




BILL OF MATERIAL			
E	ITEM	QTY	PART NUMBER
	1	1	PLUG, ZINC W/ BRASS SUPPORT, 1/2" NPT, CHAMP #500129
	2	1	CROSS, THREADED, 1-1/4" NPT
	3	4	BALL VALVE, 1-1/4 NPT MALE X FEMALE
	4	1	GUAGE, PRESSURE, 1/4" NPT, 0-100 PSI RANGE
F	5	1	FTG, STR, -24 JIC X -20 NPT
	6	2	TEE, 1 1/4" NPT FEMALE, BLK STEEL
	7	2	ELBOW, 1 1/4" NPT FEMALE, BLK STEEL
	8	2	REGULATOR/STRAINER, 1-1/4" NPT, WATTS 1-1-4_25AUB-Z3
	9	1	VALVE, SOLENOID, 1-1/4" NPT, 24VDC, 150 PSI, ASCO 8210G008
	10	1	VALVE, BALL, 1/4" NPT FEMALE, .
	11	1	BUSHING, REDUCING, 1 1/4" X 1/4" NPT, BLK STEEL
	12	1	NIPPLE, 1/4" NPT x 1 1/2", BLK STEEL
	13	6	NIPPLE, 1 1/4" NPT X 2", BLK STEEL
	14	2	NIPPLE, 1 1/4" NPT X 8", BLK STEEL
	15	1	FITTING, REDUCER, 1 1/4 MALE NPTF X 1/2 FEMALE NPTF
F	16	1	ELBOW, 45° 1-1/4" MNPTxFNPT, 150LB BLACK IRON



F	2009-171	ADDED 45 DEGREE ELBOW	DAVE N	07MAY2009
E		UPDATE WITH CNP PART NUMBERS	S DUBICK	11/11/08
REV	ENF	DESCRIPTION OF REVISION	REV BY	DATE


<div>This document contains confidential and trade secret information, is the property of Cummins Fire Power LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins Fire Power LLC</div>			<div><div>CUMMINS FIRE POWER LLC CORPORATE OFFICE 1600 BUERKLE ROAD WHITE BEAR LAKE, MN WWW.CUMMINSFIREPOWER.COM</div></div>		<div>CUSTOM DESIGN AND UPFIT CENTER 875 LAWRENCE DRIVE DEPERE, WISCONSIN</div>		
			<div>ASSEMBLY, COOLING LOOP, 1-1/4" HORIZONTAL PUMP</div>				
<div>UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE</div>							
<div>ANGULAR DIMENSIONS ± 1°</div>		<div>IMPERIAL UNITS</div>	<div>METRIC UNITS</div>	<div>DWG UNITS: IN/LB/S</div>		<div>DRAWN BY: S DUBICK PRO-ENGINEER</div>	<div>DATE: 11/11/08 REF DRWG:</div>
<div>THIRD ANGLE PROJECTION</div> <div></div>		<div>MACHINE TOLERANCES .XX : ± 0.010 .XXX : ± 0.005</div> <div>FORM TOLERANCES .XX : ± 0.030 .XXX : ± 0.015</div> <div>FAB TOLERANCES .XX : ± 0.060 .XXX : ± 0.030</div>	<div>MACHINE TOLERANCES .X : ± 0.4 .XX : ± 0.2</div> <div>FORM TOLERANCES .XX : ± 0.8 .XXX : ± 0.4</div> <div>FAB TOLERANCES .XX : ± 1.0 .XXX : ± 0.8</div>	<div>SCALE: 0.300</div> <div>EST WEIGHT: 67.265</div>		<div>SHEET 1 OF 1</div>	<div>DRAWING NO: 10912</div>



A

A

BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	PLUG, ZINC W/ BRASS SUPPORT, 1/2" NPT, CHAMP #500129	9750
2	1	CROSS, THREADED, 1-1/4" NPT	12708
3	4	BALL VALVE, 1-1/4 NPT MALE X FEMALE	12709
4	1	GUAGE, PRESSURE, 1/4" NPT, 0-100 PSI RANGE	8892
5	1	FTG, STR, -24 JIC X -20 NPT	12238-24-20
6	2	TEE, 1 1/4" NPT FEMALE, BLK STEEL	12386
7	2	ELBOW, 1 1/4" NPT FEMALE, BLK STEEL	12387
8	2	REGULATOR/STRAINER, 1-1/4" NPT, WATTS 1-1-4_25AUB-Z3	12388
9	1	VALVE, BALL, 1/4" NPT FEMALE, .	12390
10	1	BUSHING, REDUCING, 1 1/4" X 1/4" NPT, BLK STEEL	12391
11	1	NIPPLE, 1/4" NPT x 1 1/2", BLK STEEL	12392
12	4	NIPPLE, 1 1/4" NPT X 2", BLK STEEL	12394
13	2	NIPPLE, 1 1/4" NPT X 8", BLK STEEL	12395
14	1	NIPPLE, 1 1/4" NPT X 6", BLK STEEL	12396
15	1	FITTING, REDUCER, 1 1/4 MALE NPTF X 1/2 FEMALE NPTF	12710
16	1	ELBOW, 45° 1-1/4" MNPTxFNPT, 150LB BLACK IRON	14204-20



SCALE 0.150

A	2009-171	ADDED 45 DEGREE ELBOW	DAVE N	07MAY2009
REV	ENF	DESCRIPTION OF REVISION	REV BY	DATE

This document contains confidential and trade secret information, is the property of Cummins Fire Power LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins Fire Power LLC




CUMMINS FIRE POWER LLC
CORPORATE OFFICE
1600 BUERKLE ROAD
WHITE BEAR LAKE, MN
WWW.CUMMINSFIREPOWER.COM

CUSTOM DESIGN
AND UPFIT CENTER
875 LAWRENCE DRIVE
DEPERE, WISCONSIN

UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE

ANGULAR DIMENSIONS ± 1° IMPERIAL UNITS METRIC UNITS



MACHINE TOLERANCES
.XX ± 0.010
.XX ± 0.005
FORM TOLERANCES
.XX ± 0.008
.XXX ± 0.015
FAB TOLERANCES
.XX ± 0.008
.XXX ± 0.030

MACHINE TOLERANCES
.XX ± 0.2
FORM TOLERANCES
.XX ± 0.4
FAB TOLERANCES
.XX ± 0.5
.XX ± 0.8

ASSEMBLY, COOLING LOOP, 1-1/4"
VERTICAL PUMP

DWG UNITS:
IN/LB/S


DRAWN BY: S DUBICK
PRO-ENGINEER

DATE: 11/11/08
REF DRWG:

SCALE: 0.300
EST WEIGHT: 67.265

SHEET
1 OF 1

DRAWING NO:
11707



BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	HOSE, FUEL, CFPI5E FIREPUMP	10925
2	1	HOSE, FUEL, CFPI5E FIREPUMP	10926
3	1	HOSE, FUEL COOLER INPUT, CFPI5E	12523
4	1	HOSE, FUEL COOLER, RETURN, CFPI5E	12524
5	1	ADAPTER, EXPANDER, 10 JIC X 8 JIC, PARKER 10-8 XHX6 OR EQUIV.	12137-10-8
6	1	FTG, BLKHD, -10 JIC	12227-10
7	1	FTG, BLKHD, -10 JIC X -8 FMNPT	12230-10-8
8	1	FTG, STR, -10 FLR X -8 FMNPT	12552-10-8
9	4	CLAMP, LOOM, 1", LTL-SCPVI6627	13745
10	1	CLAMP, P-STYLE, 1-1/2", LTL-SCPV24627	13747
11	2	FUEL LINE, 12" EXTENSION, #10 FEM JIC X #10 22IFR X 3/4" NPT	14400-011
12	1	VALVE,CHECK,BRASS, 1/2" MNPT X MNPT	14411
13	1	CLAMP, P-STYLE, 1" W/ 0.50 HOLE, LTL-CCVI717	14554

This document contains confidential and trade secret information, is the property of Cummins Fire Power LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins Fire Power LLC

CUMMINS FIRE POWER LLC
CORPORATE OFFICE
1600 BUERKLE ROAD
WHITE BEAR LAKE, MN
WWW.CUMMINSFIREPOWER.COM

CUSTOM DESIGN
AND UPFIT CENTER
875 LAWRENCE DRIVE
DEPERE, WISCONSIN

UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE

ANGULAR DIMENSIONS ± 1°

IMPERIAL UNITS

METRIC UNITS

THIRD ANGLE PROJECTION

MACHINE TOLERANCES
.XX ± 0.010
.XXX ± 0.005

FORM TOLERANCES
.XX ± 0.030
.XXX ± 0.015

FAB TOLERANCES
.XX ± 0.060
.XXX ± 0.030

MACHINE TOLERANCES
.X ± 0.4
.XX ± 0.2

FORM TOLERANCES
.X ± 0.8
.XX ± 0.4

FAB TOLERANCES
.X ± 1.5
.XX ± 0.8

ASSEMBLY, FUEL PLUMBING
CFPI5E

DWG UNITS:
IN/LB/S


DRAWN BY: S DUBICK
PRO-ENGINEER

DATE:

SCALE: 0.125
EST WEIGHT: 76.054


SHEET
1 OF 1

DRAWING NO:
10842







10856-01 BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	ELEMENT, FILTER, CFPI5E, SPECIAL	10857
2	1	HUMP-HOSE 6" NOMINAL, NELSON 89839K OR EQUIV	89839K
3	2	CLAMP, 6" NOMINAL	AC600
4	1	RESTRICTION INDIACOR, 1/8" NPT	RAX00-2352

10856-02 BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	ELEMENT, FILTER, CFPI5E, SPECIAL	10857
2	1	HUMP-HOSE REDUCER, 6.0" TO 5.5"	89849K
3	2	CLAMP, 6" NOMINAL	AC600
4	1	RESTRICTION INDIACOR, 1/8" NPT	RAX00-2352




C	REMOVE (1) CLAMP	S DUBICK	04APR2008
B	ADDED -02 VERSION, DELETED NOTE	PBS	25JUN2007
A	ADDED NOTE	PBS	11MAY2007
REV	DESCRIPTION OF REVISION	REV BY	DATE

This document contains confidential and trade secret information, is the property of Cummins NPower, LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins NPower, LLC																<div>REF. SCALES</div> <div></div>				CUMMINS NPOWER, LLC CORPORATE OFFICE 1600 BUEKLE ROAD WHITE BEAR LAKE, MN WWW.NPOWER.CUMMINS.COM				NPOWER SYSTEMS DESIGN CENTER 875 LAWRENCE DRIVE DEPERE, WISCONSIN											
UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE																TITLE 1: ASSEMBLY, AIR CLEANER, CFP15E TITLE 2: FIREPUMP																			
ANGULAR DIMENSIONS ± 1°				IMPERIAL UNITS				METRIC UNITS				DWG UNITS:				DRAWN BY: S.DANFORTH				DATE: APR 2006															
THIRD ANGLE PROJECTION				MACHINE TOLERANCES XX ± 0.005 XX ± 0.010 XX ± 0.015 XX ± 0.030				MACHINE TOLERANCES XX ± 0.2 XX ± 0.3 XX ± 0.5 XX ± 1.0				IN/LB/S				APPD BY:				DATE:															
				FORM TOLERANCES XX ± 0.005 XX ± 0.010 XX ± 0.015 XX ± 0.030				FORM TOLERANCES XX ± 0.2 XX ± 0.3 XX ± 0.5 XX ± 1.0				EST WEIGHT: 7.562				SCALE: 0.500				DO NOT SCALE				SHEET 10F1				DRAWING NO: 10856-02				REV: C			





A

BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	SWITCH, WATER TEMP, 200F SETTING, #3408632	8860
2	1	SWITCH, OIL PRESSURE, 16 PSI, #3408607	8861
3	1	SENDER, WATER TEMPERATURE, DATCON #02022-00	8862
4	1	SENDER, OIL PRESURE, DATCON #02504-00	8863
5	1	SENSOR, MAG PICK UP, #5MT2005	9569
6	1	FTG, STR, M14 ORR X -2 FNPT	12181-M14-2
7	1	FTG, STR, M14 ORR X -4 FNPT	12181-M14-4
8	4	FTG, STR, M27 ORR X -12 FNPT	12181-M27-12
9	1	TEE,MALE BRANCH,1/4", NPT, BRASS	14409-4
10	2	BUSHING, REDUCER, -12 NPT X -2 FNPT	14783-12-2
11	2	BUSHING, REDUCER, -4 NPT X -2 FNPT	14783-4-2
12	1	CONNECTOR, QUICK DISCONNECT	3377244



SEE DETAIL B

SEE DETAIL C



This document contains confidential and trade secret information, is the property of Cummins Fire Power LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins FirePower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. ©2010 Cummins Fire Power LLC



Fire Power

CUMMINS FIRE POWER LLC
CORPORATE OFFICE
1600 BUECKLE ROAD
WHITE BEAR LAKE, MN
WWW.CUMMINSFIREPOWER.COM

CUSTOM DESIGN
AND UPGIT CENTER
875 LAWRENCE DRIVE
DEPERE, WISCONSIN

UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE

ANGULAR DIMENSIONS ± 1° IMPERIAL UNITS METRIC UNITS

THIRD ANGLE PROJECTION

MACHINE TOLERANCES
FRACTIONAL DECIMALS
FRACTIONAL DECIMALS
FRACTIONAL DECIMALS

MACHINE TOLERANCES
FRACTIONAL DECIMALS
FRACTIONAL DECIMALS
FRACTIONAL DECIMALS

ASSEMBLY, SENSOR PACKAGE
CFPI5E

DWG UNITS:

IN/LB/S

SCALE: 0.100

EST WEIGHT: 4.606

DRAWN BY: S DUBICK

PRO-ENGINEER

SHEET

1 OF 1


DATE: 04/10/09

REF DRWG:





9572-01

REV	ENF	DESCRIPTION OF REVISION	REV BY	DATE
A	2009-322	12181-M27-12 QTY WAS (3)	DAN	14-JUL-09


SEQUENCE OF ASSEMBLY
1.) ADD ISOLATOR, CONTACTORS, GROMMETS TO PANEL
2.) ADD SPACER AND ECM A-B SWITCH BRKT TO FLYWHEEL HOUSING WITH LOWER SCREWS ONLY.
3.) ADD SUB-ASMY PER STEP 1. TO ENGINE
4.) ADD GAUGE PANEL AND SENSORS
5.) ADD WIRING HARNESS




BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	HARNESS, WIRING, INSTRUMENT PANEL, B SERIES, FIREPUMP	8513
<div>G</div> 2	1	ASSEMBLY, SENSOR PACKAGE, CFPI5E	9572-01
<div>F</div> 3	2	GROMMETT	508-1057
4	2	CONTACTOR, MANUAL OVERRIDE, FIREPUMP	8824
5	1	BATTERY ISOLATOR, FIRE PUMP	8838
6	1	BRACKET, MOUNTING, OPERATORS STATION, CFPI5E FIREPUMP	10827
7	2	SPACER, OPERATORS STATION, CFPI5E FIREPUMP	10843
8	1	BRACKET, STIFFENER, OPERATOR STATION, CFPI5E FIREPUMP	11580
9	8	ISOLATOR, PLATE MOUNT, 5/16-18x1x1 NEOPRENE, TECH PRODUCTS #51272	13011
<div>F</div> 10	1	ASSEMBLY, CONTROL PANEL, 24V, FIRE PUMP	13237
<div>F</div> 11	1	GROMMETT, BUNA-N RUBBER, 1-1/2 HOLE, PN:9307K74	14188



DETAIL A
SCALE 0.400

				UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE		TITLE 2: FIREPUMP											
G	CHANGE SENSOR ASSEMBLY	S DUBICK	13APR09	ANGULAR DIMENSIONS ± 1°		IMPERIAL UNITS		METRIC UNITS		DWG UNITS:		DRAWN BY: DAVE N		DATE: 18JUN2004			
F	UPDATED PANEL & ISOLATORS PN 14188 WAS 19447	S DUBICK	07NOV08	THIRD ANGLE PROJECTION		MACHINE TOLERANCES XX ± 0.005 XX ± 0.010 XX ± 0.020 XX ± 0.030 XX ± 0.040 XX ± 0.050 XX ± 0.060 XX ± 0.070 XX ± 0.080 XX ± 0.090 XX ± 0.100		MACHINE TOLERANCES XX ± 0.005 XX ± 0.010 XX ± 0.020 XX ± 0.030 XX ± 0.040 XX ± 0.050 XX ± 0.060 XX ± 0.070 XX ± 0.080 XX ± 0.090 XX ± 0.100		IN/LB/S		APPD BY:		DATE:			
REV	DESCRIPTION OF REVISION	REV BY	DATE			FORM TOLERANCES XX ± 0.005 XX ± 0.010 XX ± 0.020 XX ± 0.030 XX ± 0.040 XX ± 0.050 XX ± 0.060 XX ± 0.070 XX ± 0.080 XX ± 0.090 XX ± 0.100		FORM TOLERANCES XX ± 0.005 XX ± 0.010 XX ± 0.020 XX ± 0.030 XX ± 0.040 XX ± 0.050 XX ± 0.060 XX ± 0.070 XX ± 0.080 XX ± 0.090 XX ± 0.100		EST WEIGHT: 56.308		SCALE: 0.200		DO NOT SCALE	SHEET 10F1	DRAWING NO: 10826	REV: G



E

D

D



D

D


BILL OF MATERIAL

ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	ENCLOSURE, FIREPUMP INSTRUMENT	10454
2	1	ASSEMBLY, SWITCH GANG, FIREPUMP	11084
3	1	MODULE, OVERSPEED, FIREPUMP	8836
4	1	DECAL, INSTRUMENT PANEL, FIREPUMP	10731
5	1	DECAL, INSTRUCTION, GAUGE PANEL	11136
6	1	ASSEMBLY, HARNESS, INSTRUMENT PANEL, FIREPUMP	11185
7	1	BRACKET, TOGGLE SWITCH MOUNTING, FIREPUMP GAUGE PANEL - E-ENG	8887
8	1	SWITCH, TOGGLE, MINIATURE, MOMENTARY (ON)-OFF-(ON)	8889
9	1	SWITCH, TOGGLE, MINIATURE, SUSTAINED ON-OFF-ON	8888
10	2	RELAY HOLDER, FIREPUMP	9528
11	2	RELAY, INSTRUMENT PANEL, 40 AMP, 12vdc	8857
12	1	GUAGE, OIL PRESSURE, 0-80 PSI, 12VDC, FIREPUMP	11194
13	1	GUAGE, WATER TEMPERATURE, 12VDC, FIREPUMP	11197
14	2	GUAGE, VOLTMETER 8-18VDC, FIREPUMP	11200
15	1	GUAGE, TACHOMETER/HOUR METER, FIREPUMP	11202
16	1	ASSEMBLY, TERMINALS, GAUGE PANEL, FIREPUMP	11137
17	1	MODULE, DIODE, INSTRUMENT PANEL, FIREPUMP	9529
19	2	CIRCUIT BREAKER, INSTRUMENT PANEL, FIREPUMP	11203

NOTES:
GAUGE PANEL EXPLOSION DEPICTED FOR SERVICE PART IDENTIFICATION. WHERE APPLICABLE, SUB-ASSEMBLY DRAWINGS MAY BE REQUIRED FOR COMPONENT DETAIL(S). WIRING HARNESS IS NOT FIELD SERVICEABLE WITHOUT TRP ISSUED BY CUMMINS FIREPOWER IF APPLICABLE.

<p>This document contains confidential and trade secret information, is the property of Cummins NPower, LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins NPower, LLC</p>					<p>CUMMINS NPOWER, LLC CORPORATE OFFICE 1600 BUERKLE ROAD WHITE BEAR LAKE, MN WWW.NPOWER.CUMMINS.COM</p>			<p>NPOWER SYSTEMS DESIGN CENTER 875 LAWRENCE DRIVE DEPERE, WISCONSIN</p>		
<p>UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE</p>					<p>TITLE 1: ASSEMBLY, INSTRUMENT PANEL 12V TITLE 2: FIREPUMP</p>					
<p>ANGULAR DIMENSIONS ± 1°</p>		<p>IMPERIAL UNITS</p>	<p>METRIC UNITS</p>	<p>DWG UNITS: IN/LB/S</p>		<p>DRAWN BY: S.DANFORTH APPD BY:</p>		<p>DATE: 10JUL2006 DATE:</p>		
<p>THIRD ANGLE PROJECTION</p> 		<p>MACHINE TOLERANCES XX ± 0.010 XXx ± 0.005</p> <p>FORM TOLERANCES XX ± 0.030 XXx ± 0.015</p> <p>FAB TOLERANCES XX ± 0.060 XXx ± 0.030</p>	<p>MACHINE TOLERANCES X ± 0.4 XX ± 0.2</p> <p>FORM TOLERANCES X ± 0.8 XX ± 0.4</p> <p>FAB TOLERANCES X ± 1.3 XX ± 0.8</p>	<p>EST WEIGHT: 21.524</p>		<p>SCALE: 0.200</p>	<p>DO NOT SCALE</p>	<p>SHEET 10F1</p>	<p>DRAWING NO: 10452</p>	<p>REV: E</p>

E	MODIFIED 10454	S DUBICK	28MAY08
D	CORRECTED GAUGE P/N'S	S.DANFORTH	02JAN07
C	REDRAWN AND RELEASED	ANTONIO G.	25SEP06
B	REVISED TERMINAL STRIP	S.DANFORTH	
A	PROTOTYPE RELEASE	S.DANFORTH	10JUL2006
REV	DESCRIPTION OF REVISION	REV BY	DATE



BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	2	RELAY, INSTRUMENT PANEL, 40 AMP, 12vdc	8857
2	1	ENCLOSURE, FIREPUMP INSTRUMENT	10454
3	1	ASSEMBLY, SWITCH GANG, FIREPUMP	11084
4	1	ASSEMBLY, TERMINALS, GAUGE PANEL, FIREPUMP	11137
5	1	ASSEMBLY, HARNESS, INSTRUMENT PANEL, FIREPUMP	11185
6	1	MODULE, OVERSPEED, FIREPUMP	8836
7	1	BRACKET, TOGGLE SWITCH MOUNTING, FIREPUMP GAUGE PANEL - E-ENG	8887
8	1	SWITCH, TOGGLE, MINIATURE, SUSTAINED ON-OFF-ON	8888
9	1	SWITCH, TOGGLE, MINIATURE, MOMENTARY (ON)-OFF-(ON)	8889
10	2	RELAY HOLDER, FIREPUMP	9528
11	1	MODULE, DIODE, INSTRUMENT PANEL, FIREPUMP	9529
12	1	DECAL, INSTRUMENT PANEL, FIREPUMP	10731
13	1	DECAL, INSTRUCTION, GAUGE PANEL	11136
14	1	GUAGE, OIL PRESSURE, 0-80 PSI, 12VDC, FIREPUMP	11194
15	1	GUAGE, WATER TEMPERATURE, 12VDC, FIREPUMP	11197
16	2	GUAGE, VOLTMETER 8-18VDC, FIREPUMP	11200
17	1	GUAGE, TACHOMETER/HOUR METER, FIREPUMP	11202
18	2	CIRCUIT BREAKER, INSTRUMENT PANEL, FIREPUMP	11203
19	4	ISOLATOR, PLATE MOUNT, 5/16-18x1x1 NEOPRENE, TECH PRODUCTS #51272	13011


NOTES:

- * GAUGE PANEL EXPLOSION DEPICTED FOR SERVICE PART ID.
- * WHERE APPLICABLE, SUB-ASSEMBLY DRAWINGS MAY BE REQUIRED FOR COMPONENT DETAILS.
- * WIRING HARNESS IS NOT FIELD SERVICEABLE WITHOUT TRP ISSUED BY CUMMINS FIREPOWER IF APPLICABLE.

REV	DESCRIPTION OF REVISION	REV BY	DATE

This document contains confidential and trade secret information, is the property of Cummins NPower, LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins NPower, LLC			
UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE			
ANGULAR DIMENSIONS ± 1°		IMPERIAL UNITS	METRIC UNITS
THIRD ANGLE PROJECTION		MACHINE TOLERANCES XX ± .005 XX ± .010 XX ± .015 XX ± .020 XX ± .030 XX ± .040 XX ± .050 XX ± .060 XX ± .070 XX ± .080 XX ± .090 XX ± .100 XX ± .125 XX ± .150 XX ± .175 XX ± .200 XX ± .250 XX ± .300 XX ± .375 XX ± .450 XX ± .560 XX ± .690 XX ± .875 XX ± 1.000 XX ± 1.250 XX ± 1.575 XX ± 1.900 XX ± 2.375 XX ± 2.900 XX ± 3.500 XX ± 4.250 XX ± 5.000 XX ± 5.750 XX ± 6.500 XX ± 7.250 XX ± 8.000 XX ± 8.750 XX ± 9.500 XX ± 10.250 XX ± 11.000 XX ± 11.750 XX ± 12.500 XX ± 13.250 XX ± 14.000 XX ± 14.750 XX ± 15.500 XX ± 16.250 XX ± 17.000 XX ± 17.750 XX ± 18.500 XX ± 19.250 XX ± 20.000 XX ± 20.750 XX ± 21.500 XX ± 22.250 XX ± 23.000 XX ± 23.750 XX ± 24.500 XX ± 25.250 XX ± 26.000 XX ± 26.750 XX ± 27.500 XX ± 28.250 XX ± 29.000 XX ± 29.750 XX ± 30.500 XX ± 31.250 XX ± 32.000 XX ± 32.750 XX ± 33.500 XX ± 34.250 XX ± 35.000 XX ± 35.750 XX ± 36.500 XX ± 37.250 XX ± 38.000 XX ± 38.750 XX ± 39.500 XX ± 40.250 XX ± 41.000 XX ± 41.750 XX ± 42.500 XX ± 43.250 XX ± 44.000 XX ± 44.750 XX ± 45.500 XX ± 46.250 XX ± 47.000 XX ± 47.750 XX ± 48.500 XX ± 49.250 XX ± 50.000 XX ± 50.750 XX ± 51.500 XX ± 52.250 XX ± 53.000 XX ± 53.750 XX ± 54.500 XX ± 55.250 XX ± 56.000 XX ± 56.750 XX ± 57.500 XX ± 58.250 XX ± 59.000 XX ± 59.750 XX ± 60.500 XX ± 61.250 XX ± 62.000 XX ± 62.750 XX ± 63.500 XX ± 64.250 XX ± 65.000 XX ± 65.750 XX ± 66.500 XX ± 67.250 XX ± 68.000 XX ± 68.750 XX ± 69.500 XX ± 70.250 XX ± 71.000 XX ± 71.750 XX ± 72.500 XX ± 73.250 XX ± 74.000 XX ± 74.750 XX ± 75.500 XX ± 76.250 XX ± 77.000 XX ± 77.750 XX ± 78.500 XX ± 79.250 XX ± 80.000 XX ± 80.750 XX ± 81.500 XX ± 82.250 XX ± 83.000 XX ± 83.750 XX ± 84.500 XX ± 85.250 XX ± 86.000 XX ± 86.750 XX ± 87.500 XX ± 88.250 XX ± 89.000 XX ± 89.750 XX ± 90.500 XX ± 91.250 XX ± 92.000 XX ± 92.750 XX ± 93.500 XX ± 94.250 XX ± 95.000 XX ± 95.750 XX ± 96.500 XX ± 97.250 XX ± 98.000 XX ± 98.750 XX ± 99.500 XX ± 100.000	

CUMMINS NPOWER, LLC CORPORATE OFFICE 1600 BUEKLE ROAD WHITE BEAR LAKE, MN WWW.NPOWER.CUMMINS.COM			
NPOWER SYSTEMS DESIGN CENTER 875 LAWRENCE DRIVE DEPERE, WISCONSIN			
TITLE 1: ASSEMBLY, INSTRUMENT PANEL 12V, ISOLATED TITLE 2: FIREPUMP			
DWG UNITS: IN/LB/S	DRAWN BY: S.DANFORTH	DATE: 10JUL2006	
EST WEIGHT: 21.524	SCALE: 0.300	DO NOT SCALE	SHEET 10F1
DRAWING NO: 13236		REV: -	




E
D


BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	ENCLOSURE, FIREPUMP INSTRUMENT	10454
2	1	ASSEMBLY, SWITCH GANG 24VDC, FIREPUMP	11085
3	1	MODULE, OVERSPEED, FIREPUMP	8836
4	1	DECAL, INSTRUMENT PANEL, FIREPUMP	10731
5	1	DECAL, INSTRUCTION, GAUGE PANEL	11136
6	1	ASSEMBLY, HARNESS, INSTRUMENT PANEL, FIREPUMP	11185
7	1	BRACKET, TOGGLE SWITCH MOUNTING, FIREPUMP GAUGE PANEL - E-ENG	8887
8	1	SWITCH, TOGGLE, MINIATURE, MOMENTARY (ON)-OFF-(ON)	8889
9	1	SWITCH, TOGGLE, MINIATURE, SUSTAINED ON-OFF-ON	8888
10	2	RELAY HOLDER, FIREPUMP	9528
11	2	RELAY, INSTRUMENT PANEL, 40 AMP, 12vdc	8857
12	1	GUAGE, OIL PRESSURE, 0-80 PSI, 24VDC, FIREPUMP	11195
13	1	GUAGE, WATER TEMPERATURE, 24VDC, FIREPUMP	11198
14	2	GUAGE, VOLTMETER 16-32VDC, FIREPUMP	11201
15	1	GUAGE, TACHOMETER/HOUR METER, FIREPUMP	11202
16	1	ASSEMBLY, TERMINALS, GAUGE PANEL, FIREPUMP	11137
17	1	MODULE, DIODE, INSTRUMENT PANEL, FIREPUMP	9529
19	2	CIRCUIT BREAKER, INSTRUMENT PANEL, FIREPUMP	11203

NOTES:
GAUGE PANEL EXPLOSION DEPICTED FOR SERVICE PART IDENTIFICATION. WHERE APPLICABLE, SUB-ASSEMBLY DRAWINGS MAY BE REQUIRED FOR COMPONENT DETAIL(S). WIRING HARNESS IS NOT FIELD SERVICEABLE WITHOUT TRP ISSUED BY CUMMINS FIREPOWER IF APPLICABLE.

E	MODIFIED 10454	S DUBICK	28MAY08
D	11085 WAS 11084	S.DANFORTH	02JAN07
C	REDRAWN AND RELEASED	ANTONIO G.	25SEP06
B	REVISED TERMINAL STRIP	S.DANFORTH	
A	PROTOTYPE RELEASE	S.DANFORTH	10JUL2006
REV	DESCRIPTION OF REVISION	REV BY	DATE

This document contains confidential and trade secret information, is the property of Cummins NPower, LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins NPower, LLC		
UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE		
ANGULAR DIMENSIONS ± 1°	IMPERIAL UNITS	METRIC UNITS
THIRD ANGLE PROJECTION	MACHINE TOLERANCES XX ± 0.010 XXX ± 0.005 FORM TOLERANCES XX ± 0.030 XXX ± 0.015 FAB TOLERANCES XX ± 0.060 XXX ± 0.030	MACHINE TOLERANCES X ± 0.4 XX ± 0.2 FORM TOLERANCES X ± 0.8 XX ± 0.4 FAB TOLERANCES X ± 1.3 XX ± 0.8

		CUMMINS NPOWER, LLC CORPORATE OFFICE 1600 BUERKLE ROAD WHITE BEAR LAKE, MN WWW.NPOWER.CUMMINS.COM		NPOWER SYSTEMS DESIGN CENTER 875 LAWRENCE DRIVE DEPERE, WISCONSIN	
TITLE 1: ASSEMBLY, INSTRUMENT PANEL TITLE 2: FIREPUMP					
DWG UNITS: IN/LB/S		DRAWN BY: S.DANFORTH		DATE: 10JUL2006	
		APPD BY:		DATE:	
EST WEIGHT: 20.096		SCALE: 0.200	DO NOT SCALE	SHEET 10F1	DRAWING NO: 10453
					REV: E



BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	ENCLOSURE, FIREPUMP INSTRUMENT	10454
2	1	ASSEMBLY, SWITCH GANG 24VDC, FIREPUMP	11085
3	1	MODULE, OVERSPEED, FIREPUMP	8836
4	1	DECAL, INSTRUMENT PANEL, FIREPUMP	10731
5	1	DECAL, INSTRUCTION, GAUGE PANEL	11136
6	1	ASSEMBLY, HARNESS, INSTRUMENT PANEL, FIREPUMP	11185
7	1	BRACKET, TOGGLE SWITCH MOUNTING, FIREPUMP GAUGE PANEL - E-ENG	8887
8	1	SWITCH, TOGGLE, MINIATURE, MOMENTARY (ON)-OFF-(ON)	8889
9	1	SWITCH, TOGGLE, MINIATURE, SUSTAINED ON-OFF-ON	8888
10	2	RELAY HOLDER, FIREPUMP	9528
11	2	RELAY, INSTRUMENT PANEL, 40 AMP, 12vdc	8857
12	1	GUAGE, OIL PRESSURE, 0-80 PSI, 24VDC, FIREPUMP	11195
13	1	GUAGE, WATER TEMPERATURE, 24VDC, FIREPUMP	11198
14	2	GUAGE, VOLTMETER 16-32VDC, FIREPUMP	11201
15	1	GUAGE, TACHOMETER/HOUR METER, FIREPUMP	11202
16	1	ASSEMBLY, TERMINALS, GAUGE PANEL, FIREPUMP	11137
17	1	MODULE, DIODE, INSTRUMENT PANEL, FIREPUMP	9529
19	2	CIRCUIT BREAKER, INSTRUMENT PANEL, FIREPUMP	11203
20	4	ISOLATOR, PLATE MOUNT, 5/16-18x1x1 NEOPRENE, TECH PRODUCTS #51272	13011

NOTES:
GAUGE PANEL EXPLOSION DEPICTED FOR SERVICE PART IDENTIFICATION. WHERE APPLICABLE, SUB-ASSEMBLY DRAWINGS MAY BE REQUIRED FOR COMPONENT DETAIL(S). WIRING HARNESS IS NOT FIELD SERVICEABLE WITHOUT TRP ISSUED BY CUMMINS FIREPOWER IF APPLICABLE.

This document contains confidential and trade secret information, is the property of Cummins NPower, LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins NPower, LLC

UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE

ANGULAR DIMENSIONS ± 1°	IMPERIAL UNITS	METRIC UNITS
THIRD ANGLE PROJECTION	MACHINE TOLERANCES XX = ± 0.010 XXX = ± 0.005	MACHINE TOLERANCES X = ± 0.4 XX = ± 0.2
	FORM TOLERANCES XX = ± 0.030 XXX = ± 0.015	FORM TOLERANCES X = ± 0.8 XX = ± 0.4
	FAB TOLERANCES XX = ± 0.060 XXX = ± 0.030	FAB TOLERANCES X = ± 1.3 XX = ± 0.8

CUMMINS NPOWER, LLC
CORPORATE OFFICE
1600 BUERKLE ROAD
WHITE BEAR LAKE, MN
WWW.NPOWER.CUMMINS.COM

NPOWER SYSTEMS
DESIGN CENTER
875 LAWRENCE DRIVE
DEPERE, WISCONSIN

TITLE 1: ASSEMBLY, INSTRUMENT PANEL 24V, ISOLATED

TITLE 2: FIREPUMP

DWG UNITS: IN/LB/S

EST WEIGHT: 20.096

DRAWN BY: S DUBICK

APPD BY:

SCALE: 0.200

DO NOT SCALE

SHEET 10FI

DRAWING NO: 13237


DATE: 08/06/08

DATE:

REV: -

REV	DESCRIPTION OF REVISION	REV BY	DATE

ITEM	QTY	DESCRIPTION	MATERIAL
01	A/R	5" MALE NPT	
02	A/R	5" I.D. CUFF	
03	A/R	5" 125# ANSI FLANGE	
04	A/R	6" MALE NPT	
05	A/R	6" I.D. CUFF	
06	A/R	6" 125# ANSI FLANGE	
07	A/R	8" (13-1/2" OD) 125# ANSI FLANGE	
08	A/R	10" (16" OD) 125# ANSI FLANGE	



This document contains confidential and trade secret information, is the property of Cummins Fire Power LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins Fire Power, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins Fire Power LLC

UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE:





ANGULAR DIMENSIONS ± 1°	IMPERIAL UNITS	METRIC UNITS
THIRD ANGLE PROJECTION	MACHINE TOLERANCES XX = ± 0.010 X = ± 0.005 XXX = ± 0.005	MACHINE TOLERANCES X = ± 0.2 XX = ± 0.1 XXX = ± 0.05
	FORM TOLERANCES XX = ± 0.030 X = ± 0.015 XXX = ± 0.015	FORM TOLERANCES X = ± 0.8 XX = ± 0.4 XXX = ± 0.4
	FAB TOLERANCES XX = ± 0.020 X = ± 0.010 XXX = ± 0.010	FAB TOLERANCES X = ± 1.0 XX = ± 0.5

CUMMINS FIRE POWER LLC
CORPORATE OFFICE
1600 BUERKLE ROAD
WHITE BEAR LAKE, MN
WWW.CUMMINSFIREPOWER.COM

CUSTOM DESIGN AND
UPFIT CENTER
875 LAWRENCE DRIVE
DEPERE, WISCONSIN

EXHAUST, 90°, HALF MARMON TABULATED
6" TURBO OUTLET

DWG UNITS: INCH/LB/S	DRAWN BY: DAVE N AUTO CAD	DATE: 23JUN2004
SCALE: 3/8	SHEET 10F1	DRAWING NO: 9514
EST WEIGHT:		



PART NO.	DESCRIPTION	END 1	END 2	DIM A	ENGINE/ASS'LY
7833 -01	FLEX CONNECTOR, 5.0"NOM BELLOWS TUBE -STYLE 4	5.00 OD	5.00 ID	13.50	QSM11/7773
7833 -02	FLEX CONNECTOR, 4.0"NOM CORRUGATED TUBE -STYLE 2	4.00 OD	4.00 ID	18.00	QSC300/7870
7833 -03	FLEX CONNECTOR, 4.0"NOM CORRUGATED TUBE -STYLE 2	4.00 ID	4.00 ID	18.00	6C8.3/7926
7833 -04	FLEX CONNECTOR, 3.0"NOM BELLOWS TUBE -STYLE 1	3.00 OD	3.00 OD	9.75	BLOUNT 7960
7833 -05	FLEX CONNECTOR, 4.0"NOM CORRUGATED TUBE -STYLE 3	4.00 ID	4.00 ID	17.00	L10-8014
7833 -06	FLEX CONNECTOR, 3.5"NOM CORRUGATED TUBE -STYLE 2	3.50 OD	3.50 ID	18.00	6BTA-7640-05
7833 -07	FLEX CONNECTOR, 3.5"NOM BELLOWS TUBE -STYLE 4	3.50 OD	3.50 ID	9.00	6BTA-7640-06
A 7833 -08	FLEX CONNECTOR, 6.0"NOM CORRUGATED TUBE -STYLE 3	6.00 ID	6.00 ID	18.00	-
B 7833 -09	FLEX CONNECTOR, 6.0"NOM CORRUGATED TUBE -STYLE 2	6.00 ID	6.00 ID	18.00	QXS15/11235
C 7833 -10	FLEX CONNECTOR, 5.0"NOM CORRUGATED TUBE -STYLE 3	5.00 ID	5.00 ID	18.00	GTA38 GS3/11420
D 7833 -11	FLEX CONNECTOR, 6.0"NOM BELLOWS TUBE -STYLE 4	6.00 OD	6.00 ID	12.00	-
E 7833 -12	FLEX CONNECTOR, 4.0"NOM CORRUGATED TUBE -STYLE 3	4.00 ID	4.00 ID	18.00	-
F 7833 -13	FLEX CONNECTOR, 4.0"NOM CORRUGATED TUBE -STYLE 3	4.00 ID	4.00 ID	20.00	-
G 7833 -14	FLEX CONNECTOR, 3.0"NOM CORRUGATED TUBE -STYLE 3	3.00 ID	3.00 ID	13.00	-
G 7833 -15	FLEX CONNECTOR, 3.0"NOM CORRUGATED TUBE -STYLE 3	3.00 ID	3.00 ID	16.00	-
G 7833 -16	FLEX CONNECTOR, 3.0"NOM CORRUGATED TUBE -STYLE 3	3.00 ID	3.00 ID	20.00	-
7833 -17	FLEX CONNECTOR, ___"NOM CORRUGATED TUBE -STYLE	-.00 ID	-.00 ID	-.00	-
7833 -18	FLEX CONNECTOR, ___"NOM CORRUGATED TUBE -STYLE	-.00 ID	-.00 ID	-.00	-
7833 -19	FLEX CONNECTOR, ___"NOM CORRUGATED TUBE -STYLE	-.00 ID	-.00 ID	-.00	-
7833 -20	FLEX CONNECTOR, ___"NOM CORRUGATED TUBE -STYLE	-.00 ID	-.00 ID	-.00	-

NOTES:

- 1) REMOVE ALL BURRS AND SHARP EDGES
- 2) ALL FLEX TUBE TO BE 409 SS UNLESS NOTED ON PURCHASE ORDER
- 3) REF 6735 FLANGED AND 7830 THREADED CONNECTORS

G	ADDED ITEMS 14 THRU 16	DWW	14APR2008
F	ADD ITEM 13	PBS	06MAR2008
E	ADD ITEM 12	PBS	24OCT2007
D	ADD ITEM 11	PBS	18APR2007
C	ADD ITEM 10	PBS	26FEB2007
B	ADD ITEM 09	CMC	20FEB2007
A	ADD ITEM 08	CMC	9OCT2006
5	ADD ITEM 07	MAS	03/28/2003
4	ADD ITEM 06	MAS	02/28/2003
3	ADD ITEM 05	MAS	01/16/2003
2	ADD ITEM 04	MAS	09/26/2002
1	ADD ITEM 03	MAS	08/28/2002
REV	DESCRIPTION OF REVISION	BY	DATE

This document contains confidential and trade secret information, is the property of Cummins NPower, LLC and is given to the recipient in confidence. The recipient, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins NPower, LLC.

UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE

ANGULAR DIMENSIONS ± 1°

THIRD ANGLE PROJECTION

IMPERIAL UNITS

METRIC UNITS

REF. SCALES

CUMMINS NPower

CUMMINS NPOWER, LLC
CORPORATE OFFICE
1600 BUERKLE ROAD
WHITE BEAR LAKE, MN
WWW.NPOWER.CUMMINS.COM

NPOWER SYSTEMS
DESIGN CENTER
875 LAWRENCE DRIVE
DEPERE, WISCONSIN



FLEX CONNECTOR, SLIP
EXHAUST (TABULATED)

DWG UNITS: DATE: 04/24/2002


APPD BY: DATE:




EST WEIGHT: SCALE: DO NOT SHEET DRAWING NO: REV:

NTS SCALE SCALE 10F1 7833 G



<u>P/N</u>	<u>DESCRIPTION</u>	<u>QTY</u>
9602A	Cable, Contactor to Starter	1
9603A	Cable, Battery Contactor Jumper	1
9763B	Cable, Isolator to Battery	2
9764	Wire, FSD Connector	1
9765B	Wire, Starter Solenoid Jumper	1
10508	Engine Ground Strap	1
9614	Battery Cable Kit (optional)	1

F	CHANGED 9602 TO REV A	KAK	26 JAN 2009	ALL RIGHTS TO MANUFACTURE, COPY OR DISPOSE OF THIS DRAWING OR ITS CONTENTS ARE RESERVED UNLESS OTHERWISE SPECIFIED IN WRITING BY CUMMINS NPPOWER, LLC		CUMMINS NPPOWER CORPORATE OFFICE 1600 BUEHLER ROAD WHITE BEAR LAKE, MN WWW.NPPOWER.CUMMINS.COM	NPPOWER SYSTEMS DESIGN CENTER 875 LAWRENCE DRIVE DEPERE, WISCONSIN
E	CHANGED 9763 TO REV B	RJS	6 NOV 06				
D	CHANGED 9765 TO REV B	RJS	25 JULY 06				
C	P/N 9603 CHG'D TO REV A	RJS	30 NOV 05				
B	ADDED ENGINE GROUND STRAP; P/N 10508	RJS	1 NOV 05				
A2	MOVED THE CR A-TO-CR B JUMPER	RJS	2 JULY 05	ALL DIMENSIONS ARE IN INCHES	DESCRIPTION KIT, LOOSE WIRES	REFERENCE: QSM11, QSX15, QSK23	DRAWING NUMBER: 9768_F
A1	ADDED REV LEAVES TO P/N'S	RJS	17 JUNE 05	APPLY MACHINE TOLERANCES X = ± 0.06 XX = ± 0.010 XXX = ± 0.001			
A	ADDED WIRING DIAGRAM	RJS	5 JAN 05	APPLY WELDED TOLERANCES X = ± 0.25 XX = ± 0.12 XXX = ± 0.06			
REV	DESCRIPTION OF REVISION	BY	DATE				
				UNLESS OTHERWISE NOTED	DMG SCALE:		
				ALL DIMENSIONS ARE IN INCHES	DRAWN BY: RJS		
				APPLY MACHINE TOLERANCES	DATE: 6 DEC 2004		
				X = ± 0.06	DATE:		
				XX = ± 0.010			
				XXX = ± 0.001			
				APPLY WELDED TOLERANCES			
				X = ± 0.25			
				XX = ± 0.12			
				XXX = ± 0.06			






BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	ASSEMBLY, ECM SWITCH	10748
2	1	PLATE, LIFTING AND ECM MTG, CFP15E FIREPUMP	10895
3	1	ASMY, ECM COOLER AND MOUNT, CFP15E FIREPUMP	10900
4	1	BRACKET, MTG, ECM SWITCH BOX, CFP11E, CFP15E	11058
5	1	HARNESS, ECM; QSX FIREPUMP	11829
6	1	ECM, CM570, CECO 3681405	3681405
7	4	ISOLATOR, #10 TAP & STUD, #AG-3904930	51156PS

HARDWARE REFENCE	
PART NUMBER	DESCRIPTION
68810	BOLT, HD CAP, M12-1.75 x 35
67519	BOLT, HD CAP, M10-1.50 x 60
67574	BOLT, HD CAP, M8-1.25 x 45




NOTE:
1. 11829 NOT SHOWN IN DRAWING VIEWS

		ADDED HARDWARE REFERENCE BLOCK NO ENF REQUIRED	MAC	01-15-2009
C	2008-501	ADDED ECM BRACKET, OBSOLETE 11502	S DUBICK	12/10/08
REV	ENF	DESCRIPTION OF REVISION	REV BY	DATE

<p>This document contains confidential and trade secret information, is the property of Cummins Fire Power LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins Fire Power LLC</p>					CUMMINS FIRE POWER LLC CORPORATE OFFICE 1600 BUERKLE ROAD WHITE BEAR LAKE, MN WWW.CUMMINSFIREPOWER.COM		CUSTOM DESIGN AND UPFIT CENTER 875 LAWRENCE DRIVE DEPERE, WISCONSIN					
UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE			ASSEMBLY, REDUNDANT ECM CFP15E FIREPUMP									
ANGULAR DIMENSIONS ± °			IMPERIAL UNITS		METRIC UNITS		DWG UNITS: IN/LB/S		DRAWN BY: S.DANFORTH PRO-ENGINEER		DATE: - REF DRWG:	
THIRD ANGLE PROJECTION 			MACHINE TOLERANCES XX ± .010 XXX ± .005 FORM TOLERANCES XX ± .020 XXX ± .015 FAB TOLERANCES XX ± .050 XXX ± .030		MACHINE TOLERANCES X ± .04 XX ± .02 FORM TOLERANCES X ± .08 XX ± .04 FAB TOLERANCES X ± .15 XX ± .08		SCALE: 0.250 EST WEIGHT: 67.605		SHEET 1 OF 1		DRAWING NO: 10846	



DESIGN INTELLECTUAL PROPERTY BY CUMMINS NPOWER, LLC
ALL PRODUCTION RUNS WILL REQUEST LATEST DOCUMENTATION
SEE SHEET 2 FOR WAVE-SOLDER ASSEMBLY
SEE SHEET 3 FOR HAND-SOLDER OF LEADS
SEE SHEET 4 FOR COVER ASSEMBLY



SCALE 1.000

BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	PC BOARD	10749
2	1	INSULATING MEMBRANE, ECM SWITCH	10750
3	1	MOUNTING PLATE, ALUMINUM	10751
4	1	SWITCH, 78 POLE	10754
6	1	BACKING PLATE, ALUMINUM	10752
7	1	SWITCH COVER, ALUMINUM	10753
8	1	GROMMET, , MCMASTER CARR P/N 9307K21 OR EQUIV	9307K21
9	1	MODULE, DIODE, INSTRUMENT PANEL, FIREPUMP	9529
10	1	LEAD 10 AWG, COPPER, GXL INSULATION, RED COLOR	10748_L1
11	1	LEAD 10 AWG, COPPER, GXL INSULATION, BLACK COLOR	10748_L2
12	1	LEAD 10 AWG, COPPER, GXL INSULATION, BLACK COLOR	10748_L3
13	1	LEAD, 10 AWG, COPPER, GXL INSULATION, GREEN COLOR	10748_L4
14	11	NUT, HEX, NO 8-32 W/ RETENTION, WASHER	NUT-RETAINING_NO-8-32
15	2	NUT, HEX, NO 10-32 W/ RETENTION, WASHER	NUT-RETAINING_NO-10-32
16	11	SCREW, NO 8-32 X 3/8, MACHINE SCREW	SCREW_MACHINE_NO-8-32_X_38
17	2	SCREW, NO 10-32 X 5/8, MACHINE SCREW	SCREW_MACHINE_NO-10-32_X_625
18	24	SCREW, SELF-TAPPING, #6 MACHINE SCREW	SCREW_SELF-TAP_NO-6_X_38
19	1	DECAL, ECM A-B SWITCH, -	11025
21	3	BOOT, INSULATING, -.025" ENTRY, RED	11052
22	1	CONNECTOR, 50 PIN	DRC20-50P-01
23	1	CONNECTOR, 50 PIN	DRC20-50P-02
24	1	CONNECTOR, 50 PIN	DRC20-50P-03
25	1	CONNECTOR, 50 PIN	DRC20-50P-04
26	1	KNOB, 0.50 DIA, 0.25 BORE, MCMASTER #6094K71 OR EQUAL	13626

C

C

C

C


D

UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE:				REV. SCALES			
ANGULAR DIMENSIONS 1°				DWG UNITS:			
THIRD ANGLE PROJECTION				IN/LB/S			
EST WEIGHT: 6.709				SCALE: 1.000			
DO NOT SCALE				SHEET 10F4			
DRAWING NO: 10748				REV: D			

BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	PC BOARD	10749
2	1	INSULATING MEMBRANE, ECM SWITCH	10750
3	1	MOUNTING PLATE, ALUMNUM	10751
4	1	SWITCH, 78 POLE	10754
6	24	SCREW, SELF-TAPPING, #6 MACHINE SCREW	SCREW_SELF-TAP_NO-6_X_38
7	1	KNOB, 0.50 DIA, 0.25 BORE, MCMASTER #6094K71 OR EQUAL	13626
22	1	CONNECTOR, 50 PIN	DRC20-50P-01
23	1	CONNECTOR, 50 PIN	DRC20-50P-02
24	1	CONNECTOR, 50 PIN	DRC20-50P-03
25	1	CONNECTOR, 50 PIN	DRC20-50P-04

Exploded view diagram of a 19-inch rack-mountable device chassis. The diagram shows the front panel (1) with four D-sub connectors (2, 23, 24, 25) and a central connector (4). The chassis (3) has mounting rails (6) and screws (14). The back panel (22) has a connector (4) and a large array of holes (24). The diagram is labeled "SCALE 1.000".

[illegible]




EACH LEAD IS TO BE HAND SOLDERED
SOLDER TO BE ROHS COMPLIANT (LEAD FREE)
ALL FLUX TO BE REMOVED AFTER SOLDERING TO PREVENT CORROSION
GREEN LEAD FOR GROUND
RED LEAD FOR DIODE ANODE
BLACK LEADS FOR BATT 1 AND BATT 2
EACH LEAD MANUFACTURED WITH GXL WIRE AND #10 AWG X #10 RING
TERMINAL. CRIMP TERMINAL ACCEPTABLE. SOLDER TERMINAL PREFERED.

BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	KNOB, 0.50 DIA, 0.25 BORE, MCMASTER #6094K71 OR EQUAL	13626
10	1	LEAD 10 AWG, COPPER, GXL INSULATION, RED COLOR	10748_L1
11	1	LEAD 10 AWG, COPPER, GXL INSULATION, BLACK COLOR	10748_L2
12	1	LEAD 10 AWG, COPPER, GXL INSULATION, BLACK COLOR	10748_L3
13	1	LEAD, 10 AWG, COPPER, GXL INSULATION, GREEN COLOR	10748_L4
21	3	BOOT, INSULATING, -.025" ENTRY, RED	11052
22	1	CONNECTOR, 50 PIN	DRC20-50P-01
23	1	CONNECTOR, 50 PIN	DRC20-50P-02
24	1	CONNECTOR, 50 PIN	DRC20-50P-03
25	1	CONNECTOR, 50 PIN	DRC20-50P-04

This document contains confidential and trade secret information. It is the property of Cummins NPPower, LLC and is given to the recipient in confidence. The recipient, by receiving and retaining of the document accepts the document in confidence and agrees to keep it confidential in writing by Cummins NPPower, LLC. It is not to be used for any other purpose or for any other confidential or trade secret information. If not copy the document, do not discuss it with others, do not enter the document in the confidential or trade secret information system, and (4) upon completion of the need to retain the document, it is to be destroyed, when the document is copied, stored, and all material copied therefrom. COPYRIGHT: Cummins NPPower, LLC				REV: SCALAS			
UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE:				TITLE 1: ASSEMBLY, ECM SWITCH			
THIRD ANGLE PROJECTION				TITLE 2:			
DWG UNITS: IN/LB/S		DRAWN BY: SCOTT D		DATE: 21FEB2006		REV: D	
EST WEIGHT: 6.709		SCALE: 1.000		DO NOT SCALE		SHEET 30F4	


BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	DETAIL, BRACKET, CFPI5E FIREPUMP	10895-01
2	4	DETAIL, BRACKET, CFPI5E FIREPUMP	10895-02




NOTES:
MATERIAL: A-36
BREAK ALL EDGES
FINISH: CUMMINS FIREPOWER RED

				REF. SCALES			
				UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE			
				ANGULAR DIMENSIONS ± 1°			
				THIRD ANGLE PROJECTION			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			
				FAB TOLERANCES			
				MACHINE TOLERANCES			
				FORM TOLERANCES			

CIRCUIT #	FROM	PIN1	TO	PIN2	WIRECOLOR	WIRESIZE	WIRE TYPE	TERM 1	TERM 2	STAMP	TWISTED PAIRS
1	R1	86	SPL A >		WHITE	18	GXL	12066614		RLY PWR	
2	R1	30	SPL A >		WHITE	18	GXL	12066614		RLY PWR	
3	W1		SPL A <		WHITE	18	GXL	30703		RLY PWR	
4	R1	85	C1	5	WHITE	18	GXL	1206614	0462-201-2031	RLY RET	
5	R1	87	C3	1	WHITE	18	GXL	1206614	0462-201-16141	LIFT PUMP SUPPLY	
6	W2		C1	4	WHITE	18	GXL	30703	0462-201-2031	FSO	
7	C2	A	C1	16	WHITE	18	GXL	JTP-1811-66AURWC	0462-201-2031	AMBIENT SUPPLY	
8	C2	B	C1	26	WHITE	18	GXL	JTP-1811-66AURWC	0462-201-2031	AMBIENT RET	
9	C2	C	C1	13	WHITE	18	GXL	JTP-1811-66AURWC	0462-201-2031	AMBIENT SIG	
10	C3	2	SPL B >		WHITE	18	GXL	0462-201-16141		LIFT PUMP RET	
11	W3		SPL B <		WHITE	14	GXL	31707		LIFT PUMP RET	
12	C4	1	C1	43	WHITE	18	GXL	0462-201-1631	0462-201-2031	RFA -	
13	C4	2	C1	8	WHITE	18	GXL	0462-201-1631	0462-201-2031	RFA +	
14	C5	1	C1	50	WHITE	18	GXL	0462-201-1631	0462-201-2031	RTA -	
15	C5	2	C1	46	WHITE	18	GXL	0462-201-1631	0462-201-2031	RTA +	
16	C6	1	C1	10	WHITE	18	GXL	0462-201-1631	0462-201-2031	FTA -	
17	C6	2	C1	21	WHITE	18	GXL	0462-201-1631	0462-201-2031	FTA +	
18	C7	1	C1	30	WHITE	18	GXL	0462-201-1631	0462-201-2031	FFA -	
19	C7	2	C1	41	WHITE	18	GXL	0462-201-1631	0462-201-2031	FFA +	
20	C8	1	C1	42	WHITE	18	GXL	0462-201-1631	0462-201-2031	OIL PRESS SUPPLY	
21	C8	2	C1	39	WHITE	18	GXL	0462-201-1631	0462-201-2031	OIL PRESS RET	
22	C8	3	C1	40	WHITE	18	GXL	0462-201-1631	0462-201-2031	OIL PRESS SIG	
23	C8	4	C1	38	WHITE	18	GXL	0462-201-1631	0462-201-2031	OIL TEMP SIG	
24	C9	A	C1	37	WHITE	18		12176860	0462-201-2031	CRANK SUPPLY	
25	C9	B	C1	27	BLACK	18		12176860	0462-201-2031	CRANK RET	
26	C9	C	C1	47	RED	18		12176860	0462-201-2031	CRANK SIG	
27			SPL B >		DRAIN	18					
28	C10	A	C1	18	WHITE	18	GXL	12124075	0462-201-2031	FUEL PRESS SUPPLY	
29	C10	B	C1	20	WHITE	18	GXL	12124075	0462-201-2031	FUEL PRESS RET	
30	C10	C	C1	19	WHITE	18	GXL	12124075	0462-201-2031	FUEL PRESS SIG	
31	C11	A	C1	15	WHITE	18	GXL	12124075	0462-201-2031	COOLANT RET	
32	C11	B	C1	7	WHITE	18	GXL	12124075	0462-201-2031	COOLANT SIG	
33	C12	A	C1	14	WHITE	18		12176860	0462-201-2031	CAM SUPPLY	
34	C12	B	C1	17	BLACK	18		12176860	0462-201-2031	CAM RET	
35	C12	C	C1	2	RED	18		12176860	0462-201-2031	CAM SIG	
36			SPL B >		DRAIN	18					
37	C13	1	C1	32	WHITE	18	GXL	0462-201-1631	0462-201-2031	IMT SUPPLY	
38	C13	2	C1	36	WHITE	18	GXL	0462-201-1631	0462-201-2031	IMT RET	
39	C13	3	C1	35	WHITE	18	GXL	0462-201-1631	0462-201-2031	IMP SIG	
40	C13	4	C1	33	WHITE	18	GXL	0462-201-1631	0462-201-2031	IMT SIG	



C	CHANGED WIRE TO SHIELDED CABLE ON PRIMARY SENSORS	K/K	26 AUG 2006	ANGULAR DIMENSIONS ± 1°	IMPERIAL UNITS	MMG UNITS:	DRAWN BY: RJS	DATE: 15 AUG 2007
B	NO CHANGE, UPDATES TO OTHER DIM'S	K/K	03 MAR 2008	THIRD ANGLE PROJECTION	SI UNITS	APPD BY:	DATE:	
A	W/ LENGTH & TIEIN CHANGE, CA LINGER CHANGE, COIN LABLES	K/K	12 NOV 2007		SI UNITS	DO NOT SCALE	DRAWING NO: 11829-01	REV: C
REV	DESCRIPTION OF REVISION	BY	DATE			EST WEIGHT:		

[illegible]

FROM		PIN1	TO	PIN2	WIRECOLOR	WIRESIZE	WIRE TYPE	TERM 1	TERM 2	STAMP	TWISTED PAIRS
J2	47	J13		2	WHITE	18	GXL	0462-201-2031	0462-201-2031	COOLANT SIG	TwST
J2	35	J13		13	WHITE	18	GXL	0462-201-2031	0462-201-2031	COOLANT RET	TwST
J2	13	J13		6	WHITE	18	GXL	0462-201-2031	0462-201-2031	AMBIENT SIG	
J2	36	J13		17	WHITE	18	GXL	0462-201-2031	0462-201-2031	AMBIENT SUPPLY	
J2	26	J13		31	WHITE	18	GXL	0462-201-2031	0462-201-2031	AMBIENT RET	
J2	34	J13		11	WHITE	18	BELDON CABLE P/N 9365	0462-201-2031	0462-201-2031	CAM SUPPLY	TwST
J2	37	J13		21	BLACK	18		0462-201-2031	0462-201-2031	CAM RET	
J2	42	J13		50	RED	18	0462-201-2031	0462-201-2031	CAM SIG		
		SPL A >			DRAIN	18					
J2	17	J13		41	WHITE	18	BELDON CABLE P/N 9365	0462-201-2031	0462-201-2031	CRANK SUPPLY	TwST
J2	27	J13		32	BLACK	18		0462-201-2031	0462-201-2031	CRANK RET	
J2	7	J13		47	RED	18	0462-201-2031	0462-201-2031	CRANK SIG		
		SPL A >			DRAIN	18					
J2	32	J13		37	WHITE	18	GXL	0462-201-2031	0462-201-2031	IMT SUPPLY	TwST
J2	33	J13		38	WHITE	18	GXL	0462-201-2031	0462-201-2031	IMT SIG	
J2	15	J13		39	WHITE	18	GXL	0462-201-2031	0462-201-2031	IMP SIG	
J2	16	J13		40	WHITE	18	GXL	0462-201-2031	0462-201-2031	IMT RET	
J2	38	J13		27	WHITE	18	GXL	0462-201-2031	0462-201-2031	FUEL PRESS SUPPLY	TwST
J2	39	J13		29	WHITE	18	GXL	0462-201-2031	0462-201-2031	FUEL PRESS SIG	
J2	40	J13		30	WHITE	18	GXL	0462-201-2031	0462-201-2031	FUEL PRESS RET	
J2	18	J13		42	WHITE	18	GXL	0462-201-2031	0462-201-2031	OIL TEMP SIG	
J2	19	J13		43	WHITE	18	GXL	0462-201-2031	0462-201-2031	OIL PRESS RET	TwST
J2	20	J13		44	WHITE	18	GXL	0462-201-2031	0462-201-2031	OIL PRESS SIG	
J2	2	J13		45	WHITE	18	GXL	0462-201-2031	0462-201-2031	OIL PRESS SUPPLY	
J2	44	J12		33	WHITE	18	GXL	0462-201-2031	0462-201-2031	FSO	
J2	10	J12		3	WHITE	18	GXL	0462-201-2031	0462-201-2031	LIFT PUMP RET	TwST
J2	21	J12		6	WHITE	18	GXL	0462-201-2031	0462-201-2031	RFA +	
J2	6	J12		16	WHITE	18	GXL	0462-201-2031	0462-201-2031	RFA -	
J2	41	J12		7	WHITE	18	GXL	0462-201-2031	0462-201-2031	FTA -	
J2	48	J12		8	WHITE	18	GXL	0462-201-2031	0462-201-2031	FTA +	TwST
J2	43	J12		9	WHITE	18	GXL	0462-201-2031	0462-201-2031	FFA -	TwST
J2	46	J12		10	WHITE	18	GXL	0462-201-2031	0462-201-2031	FFA +	
J2	3	J12		26	WHITE	18	GXL	0462-201-2031	0462-201-2031	RTA +	
J2	45	J12		36	WHITE	18	GXL	0462-201-2031	0462-201-2031	RTA -	
J2	5	J11		6	WHITE	18	GXL	0462-201-2031	0462-201-2031	STOP LAMP	TwST
J2	25	J11		16	WHITE	18	GXL	0462-201-2031	0462-201-2031	WARNING LAMP	
J2	14	J11		44	WHITE	18	GXL	0462-201-2031	0462-201-2031	DIAGNOSTIC SWITCH	
J2	4	J11		38	WHITE	18	GXL	0462-201-2031	0462-201-2031	KEYSWITCH	
J2	24	SPL B <			WHITE	18	GXL	0462-201-2031		ECM RETURN	TwST
J11	9	SPL B >			WHITE	18	GXL	0462-201-2031		ECM RETURN	
J11	23	SPL B >			WHITE	18	GXL	0462-201-2031		ISC 1	
J2	22	J11		24	WHITE	18	GXL	0462-201-2031	0462-201-2031	DECREMENT SWITCH	
J2	23	J11		14	WHITE	18	GXL	0462-201-2031	0462-201-2031	INCREMENT SWITCH	
J19	B	SPL C >			GREEN	10	GXL	12062139		ECM GND	TwST
J11	29	SPL C <			GREEN	18	GXL	0462-201-2031		ECM GND	
J11	30	SPL C <			GREEN	18	GXL	0462-201-2031		ECM GND	
J11	39	SPL C <			GREEN	18	GXL	0462-201-2031		ECM GND	
J11	40	SPL C <			GREEN	18	GXL	0462-201-2031		ECM GND	TwST
J11	50	SPL C <			GREEN	18	GXL	0462-201-2031		ECM GND	
J10	B	SPL C <			GREEN	18	GXL	12089040		ECM GND	
J19	A	SPL D >			RED	10	GXL	12062139		ECM POWER	
J11	18	SPL D <			RED	18	GXL	0462-201-2031		ECM POWER	TwST
J11	28	SPL D <			RED	18	GXL	0462-201-2031		ECM POWER	
J11	7	SPL D <			RED	18	GXL	0462-201-2031		ECM POWER	
J11	8	SPL D <			RED	18	GXL	0462-201-2031		ECM POWER	
J11	17	SPL D <			RED	18	GXL	0462-201-2031		ECM POWER	TwST
J10	A	SPL D <			RED	18	GXL	12089040		ECM POWER	
J9	A	J11		46	YELLOW	18	RAYCHEM J1939 P/N	0460-202-16141	0462-201-2031	J1939	
J9	B	J11		37	GREEN	18	2019D0309	0460-202-16141	0462-201-2031	J1939	
J9	C	J11		36	SHIELD	18		0460-202-16141	0462-201-2031	J1939	
 W1		SPL A <			WHITE	14	GXL	31707		GND	

[illegible]

TAGS	QTY	SUB	CATALOG	MFG	DESC
J3	1	1	DRC26-506-03	DEUTSCH	CONNECTOR, 50 POSITION, ECM
		1	0528-001-5005	DEUTSCH	BACKSHELL, 90 DEGREE
		39	0462-201-2031	DEUTSCH	TERMINAL, SOCKET
		11	114017	DEUTSCH	PLUG, SEALING
J14	1	1	DT04-3P	DEUTSCH	CONNECTOR, 3 POSITION
		1	W3P	DEUTSCH	WEDGE
J14A	1	3	0460-202-16141	DEUTSCH	TERMINAL, PIN
		1	DT06-3S	DEUTSCH	CONNECTOR, 3 POSITION
		1	W3S	DEUTSCH	WEDGE
J15	1	3	114017	DEUTSCH	PLUG, SEALING
		2	12010973	DELPHI	CONNECTOR, 2 POSITION
		2	12015323	DELPHI	SEALS
		2	12089040	DELPHI	TERMINAL, PIN
J15A	1	1	12015192	DELPHI	CONNECTOR, 2 POSITION
		2	12010300	DELPHI	PLUG, CAVITY
J16	1	1	DRC26-506-01	DEUTSCH	CONNECTOR, 50 POSITION, ECM
		1	0628-001-5005	DEUTSCH	BACKSHELL, 90 DEGREE
		21	0462-201-2031	DEUTSCH	TERMINAL, SOCKET
		29	114017	DEUTSCH	PLUG, SEALING
J17	1	1	DRC26-506-02	DEUTSCH	CONNECTOR, 60 POSITION, ECM
		1	0628-001-5005	DEUTSCH	BACKSHELL
		10	0462-201-2031	DEUTSCH	TERMINAL, SOCKET
		40	114017	DEUTSCH	PLUG, SEALING
J18	1	1	DRC26-506-03	DEUTSCH	CONNECTOR, 50 POSITION, ECM
		1	0528-001-5005	DEUTSCH	BACKSHELL, 90 DEGREE
		22	0462-201-2031	DEUTSCH	TERMINAL, SOCKET
		28	114017	DEUTSCH	PLUG, SEALING
J21	1	1	12052613	DELPHI	CONNECTOR, 480 METR-PACK
		2	12052139	DELPHI	TERMINAL, SOCKET
		2	12034170	DELPHI	SEALS
		1	12059897	DELPHI	TPA
W1	1	1	31707	WAYTEK	RING TERMINAL



NOTE: Loom with black nylon braid w/ red tracers; 28 mil minimum.
Prominently label all connectors as "indicated".

C	CHANGED WIRE TO SHIELDED CABLE ON PRIMARY SENSORS	KKK	28 AUG 2008
B	ADDED MATING SEALING CONNECTORS J14A AND J15A	KKK	03 MAR 2008
A	NO CHANGE - RELEASE FOR PRODUCTION	KKK	12 NOV 2007
REV	DESCRIPTION OF REVISION	BY	DATE

UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE:

ANGULAR DIMENSIONS ±	LINEAR DIMENSIONS	METRIC DIMENSIONS
± 0.5°	± 0.125mm	± 0.125mm





Fire Power

HARNNESS, ECM B
OSX15 FIREPUMP

CLARK'S IMPROVER, LLC
CORPORATE OFFICE
1600 BLUEVALE ROAD
WHITE BEAR LAKE, MN
WWW.FIREPOWERCLARKS.COM


IMPROM SYSTEMS
DESIGN CENTER
875 LAWRENCE DRIVE
DEPTFC, WISCONSIN

FROM		PIN1	TO	PIN2	WIRECOLOR	WIRESIZE	WIRE TYPE	TERM1	TERM2	STAMP	TWISTED PAIRS
J3	7	J18	2		WHITE	18	GXL	0462-201-2031	0462-201-2031	COOLANT SIG	TWIST
J3	15	J18	13		WHITE	18	GXL	0462-201-2031	0462-201-2031	COOLANT RET	
J3	13	J18	6		WHITE	18	GXL	0462-201-2031	0462-201-2031	AMBIENT SIG	
J3	16	J18	17		WHITE	18	GXL	0462-201-2031	0462-201-2031	AMBIENT SUPPLY	TWIST
J3	26	J18	31		WHITE	18	GXL	0462-201-2031	0462-201-2031	AMBIENT RET	
J3	14	J18	11		WHITE	18		0462-201-2031	0462-201-2031	CAM SUPPLY	
J3	17	J18	21		BLACK	18	BELDON CABLE P/N 9365	0462-201-2031	0462-201-2031	CAM RET	
J3	2	J18	50		RED	18		0462-201-2031	0462-201-2031	CAM SIG	
J3		SPL A >			DRAIN	18					
J3	37	J18	41		WHITE	18	BELDON CABLE P/N 9365	0462-201-2031	0462-201-2031	CRANK SUPPLY	
J3	27	J18	32		BLACK	18		0462-201-2031	0462-201-2031	CRANK RET	
J3	47	J18	47		RED	18		0462-201-2031	0462-201-2031	CRANK SIG	
		SPL A >			DRAIN	18					
J3	32	J18	37		WHITE	18	GXL	0462-201-2031	0462-201-2031	IMT SUPPLY	TWIST
J3	33	J18	38		WHITE	18	GXL	0462-201-2031	0462-201-2031	IMT SIG	
J3	35	J18	39		WHITE	18	GXL	0462-201-2031	0462-201-2031	IMP SIG	
J3	36	J18	40		WHITE	18	GXL	0462-201-2031	0462-201-2031	IMT RET	TWIST
J3	18	J18	27		WHITE	18	GXL	0462-201-2031	0462-201-2031	FUEL PRESS SUPPLY	
J3	19	J18	29		WHITE	18	GXL	0462-201-2031	0462-201-2031	FUEL PRESS SIG	
J3	20	J18	30		WHITE	18	GXL	0462-201-2031	0462-201-2031	FUEL PRESS RET	TWIST
J3	38	J18	42		WHITE	18	GXL	0462-201-2031	0462-201-2031	OIL TEMP SIG	
J3	39	J18	43		WHITE	18	GXL	0462-201-2031	0462-201-2031	OIL PRESS RET	
J3	40	J18	44		WHITE	18	GXL	0462-201-2031	0462-201-2031	OIL PRESS SIG	TWIST
J3	42	J18	45		WHITE	18	GXL	0462-201-2031	0462-201-2031	OIL PRESS SUPPLY	
J3	4	J17	33		WHITE	18	GXL	0462-201-2031	0462-201-2031	FSO	
J3	5	J17	3		WHITE	18	GXL	0462-201-2031	0462-201-2031	LIFT PUMP RET	TWIST
J3	8	J17	6		WHITE	18	GXL	0462-201-2031	0462-201-2031	RFA +	
J3	43	J17	16		WHITE	18	GXL	0462-201-2031	0462-201-2031	RFA -	
J3	10	J17	7		WHITE	18	GXL	0462-201-2031	0462-201-2031	FTA -	TWIST
J3	21	J17	8		WHITE	18	GXL	0462-201-2031	0462-201-2031	FTA +	
J3	30	J17	9		WHITE	18	GXL	0462-201-2031	0462-201-2031	FFA -	
J3	41	J17	10		WHITE	18	GXL	0462-201-2031	0462-201-2031	FFA +	TWIST
J3	46	J17	26		WHITE	18	GXL	0462-201-2031	0462-201-2031	RTA +	
J3	50	J17	36		WHITE	18	GXL	0462-201-2031	0462-201-2031	RTA -	
J3	45	J16	6		WHITE	18	GXL	0462-201-2031	0462-201-2031	STOP LAMP	TWIST
J3	25	J16	16		WHITE	18	GXL	0462-201-2031	0462-201-2031	WARNING LAMP	
J3	34	J16	44		WHITE	18	GXL	0462-201-2031	0462-201-2031	DIAGNOSTIC SWITCH	
J3	44	J16	38		WHITE	18	GXL	0462-201-2031	0462-201-2031	KEYSWITCH	
J3	24	SPL B <			WHITE	18	GXL	0462-201-2031		ECM RETURN	
J16	9	SPL B >			WHITE	18	GXL	0462-201-2031		ECM RETURN	
J16	23	SPL B >			WHITE	18	GXL	0462-201-2031		ISC 1	
J3	22	J16	24		WHITE	18	GXL	0462-201-2031	0462-201-2031	DECREMENT SWITCH	
J3	23	J16	14		WHITE	18	GXL	0462-201-2031	0462-201-2031	INCREMENT SWITCH	
J21	B	SPL C >			GREEN	10	GXL	12052139		ECM GND	
J16	29	SPL C <			GREEN	18	GXL	0462-201-2031		ECM GND	
J16	30	SPL C <			GREEN	18	GXL	0462-201-2031		ECM GND	
J16	39	SPL C <			GREEN	18	GXL	0462-201-2031		ECM GND	
J16	40	SPL C <			GREEN	18	GXL	0462-201-2031		ECM GND	
J16	50	SPL C <			GREEN	18	GXL	0462-201-2031		ECM GND	
J15	B	SPL C <			GREEN	18	GXL	12089040		ECM GND	
J21	A	SPL D >			RED	10	GXL	12052139		ECM POWER	
J16	18	SPL D <			RED	18	GXL	0462-201-2031		ECM POWER	
J16	28	SPL D <			RED	18	GXL	0462-201-2031		ECM POWER	
J16	7	SPL D <			RED	18	GXL	0462-201-2031		ECM POWER	
J16	8	SPL D <			RED	18	GXL	0462-201-2031		ECM POWER	
J16	17	SPL D <			RED	18	GXL	0462-201-2031		ECM POWER	
J15	A	SPL D <			RED	18	GXL	12089040		ECM POWER	
J14	A	J16	46		YELLOW	18	RAYCHEM J1939 P/N 2019P00309	0460-202-16141	0462-201-2031	J1939	
J14	B	J16	37		GREEN	18		0460-202-16141	0462-201-2031	J1939	
J14	C	J16	36		SHIELD	18		0460-202-16141	0462-201-2031	J1939	
W1		SPL A <			WHITE	14	GXL	31707		GND	

C	CHANGED WIRE TO SHIELDED CABLE ON PRIMARY SENSORS	KKK	28 AUG 2008	INSULATE DIMENSIONS ± 1	METRIC UNITS	IMPERIAL UNITS	
B	ADDED LAMING SEALING CONNECTORS J144 AND J154	KKK	03 MAR 2008	THIRD MADE PRODUCTION			
A	NO CHANGE, RELEASE FOR PRODUCTION	KKK	12 NOV 2007				
REV	DESCRIPTION OF REVISION	BY	DATE				
				EST WEIGHT:	SCALE:	DO NOT SCALE	
				APPD BY:	DATE:		
				DRAWN BY: RJS	DATE: 15 AUG 2007		
				DRAWING NO: 11829-03	REV: C		
				SHEET 1			

[illegible]

NOTE: Loom with black nylon braid w/ red tracers; 28 mil minimum.
Prominently label all connectors as "indicated".



FROM	TO	WIRE	WIRE LABEL	NOTE
J4/1	J5/A	18 AWG White	J5/A	J4 RED LAMP
J4/2	J5/C	18 AWG White	J5/C	YELLOW LAMP
J4/3	J5/K	18 AWG White	J5/K	DIAG
J4/4	J5/X	18 AWG White	J5/X	KEY
J4/5	J5/S	18 AWG White	J5/S	RETURN
J4/6	J5/P	18 AWG White	J5/P	DEC
J4/7	J5/M	18 AWG White	J5/M	INC
J4/8	J5/F	18 AWG White	J5/F	ECM A
J4/9	J5/H	18 AWG White	J5/H	ECM B
J4/10	not used			J20 & J22
J4/11				Delphi 480 Math-Pack Male Connector - 2
J4/12				12065863 (shroud) - 1
J4/13				w/ 12062172 (terminals) - 2
J4/14				w/ 12034170 (seals) - 2
J4/15				w/ 12059897 (TPA) - 1
J4/16				w/ 12020833 (CPA) - 1
J4/17				W1
J4/18				10 AWG 7/16" insulated ring terminal
J4/19				W2 & W3
J4/20				10 AWG 3/8" insulated ring terminal
J4/21				All wire type GXL or equiv
J4/22				
J4/23				
J4/24				
J4/25				
J4/26				
J4/27				
J4/28				
J4/29				
J4/30				
J4/31				
J4/32				
J4/33				
J4/34				
J4/35				
J4/36				
J4/37				
J4/38				
J4/39				
J4/40				
J4/41				
J4/42				
J4/43				
J4/44				
J4/45				
J4/46				
J4/47				
J4/48				
J4/49				
J4/50				

C	NO CHANGE, UPDATES TO OTHER DWGS	KVK	28 AUG 2008	ANGULAR DIMENSIONS ± 1°	IMPERIAL UNITS	METRIC UNITS	DWG UNITS:	DRAWN BY: RJS	DATE: 15 AUG 2007
B	NO CHANGE, UPDATES TO OTHER DWGS	KVK	03 MAR 2008	THIRD ANGLE PROJECTION	1:1	1:1	APD BY:		
A	NO CHANGE, RELEASE FOR PRODUCTION	KVK	12 NOV 2007		1:1	1:1	EST WEIGHT:	SCALE:	DO NOT SCALE
REV	DESCRIPTION OF REVISION	BY	DATE		1:1	1:1	SHEET 10F1	DRAWING NO: 11829-04	REV: C

CUMMINS IPPOWER, LLC


CORPORATE OFFICE
8510 WISCONSIN AVE
WHITE BEAR LAKE, MN
WWW.IPPower.CUMMINS.COM


IPPOWER SYSTEMS
REGIONAL OFFICE
8510 WISCONSIN AVE
WHITE BEAR LAKE, MN
800.441.1111

HARNESSES - OEM

QSX15 FIREPUMP

The design of this drawing is the property of Cummins IPPOWER, LLC and is not to be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage and retrieval system, without the prior written permission of Cummins IPPOWER, LLC. This drawing is for informational purposes only and is not to be used for manufacturing or assembly. The design of this drawing is the property of Cummins IPPOWER, LLC and is not to be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage and retrieval system, without the prior written permission of Cummins IPPOWER, LLC.





REV	DESCRIPTION OF REVISION	BY	DATE
A	CHANGED WIRE GAUGES, CHG'D TB 1 LABELS	RJS	27OCT05
B	ADDED CONNECTION TO TB 11 OF SPEED SWITCH	RJS	17 DEC 06
C	REMOVED 5 AMP CIRCUIT BREAKER	RJS	27 JUNE 06
D	FIN 12 WAS FIN 8	RJS	19 SEP 06
E	ADDED SHEETS 3, 4, 5, & 6	RJS	20 JAN 07

Fire Power

CLARK'S FIRE POWER
1500 ROUTE 107
WHITE BEAR LAKE, UT 84405
WWW.CLARKSFIREPOWER.COM





CLARK'S FIRE POWER
1500 ROUTE 107
WHITE BEAR LAKE, UT 84405
WWW.CLARKSFIREPOWER.COM

DWG SCALE	N/A	DATE	06_OCT_2005
PLOT SCALE	N/A	PRINTED BY	RJS

REFERENCE: SCHEMATIC, CONTROL_PANEL

DRAWING NUMBER: 10423C_SHT1

ADDITIONAL CIRCUITS FOR ELECTRONIC ENGINES



LEGEND:


K2	ECM/FUEL	FAIL	RELAY
R	RESISTOR		

NOTES: WIRE IS 14AWG UNLESS OTHERWISE NOTED
 RED TEXT = WIRE TAG
 GREEN TEXT = WIRE COLOR
 WIRE COLOR IS WHITE UNLESS OTHERWISE NOTED
 RESISTOR VALUE = 1.5kohms, 1/2w
 MINIMUM DIODE RATING: 6A/400V

[illegible]


CLAIMING FIRE POWER		CLAIMING FIRE POWER	
FIRE POWER		FIRE POWER	
1000 SCALE N/A		1000 SCALE N/A	
DESCRIPTION		DESCRIPTION	
ENGINE SCHEMATIC		ENGINE SCHEMATIC	
REFERENCE		REFERENCE	
FIREPUMP		FIREPUMP	
DRAWING NUMBER		DRAWING NUMBER	
104235C_SHT3		104235C_SHT3	


REV		REV	
A		A	
REV		REV	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV		REV	
A		A	
B		B	
C		C	
D		D	
E		E	
REV			




E	ADDED SHEETS 3, 4, 5, & 6	R/S	20 MAR 07
D	SEE SH1 FOR REV CHANGE	R/S	19 SEPT 06
C	REDRAW	R/S	3 JULY 06
B	CARD WIRING OF K2	R/S	17 DEC 05
A	REF PAGE 1 REV NOTES	R/S	27 OCT 05
	DESCRIPTION OF REVISION	BY	DATE

[illegible]

[illegible][illegible]

[illegible]



THIS HARNESS TO BE OVER-BRAIDED WITH BLACK AND RED NYLON. ALL BLACK NYLON WILL BE CONSIDERED.

THIS HARNESS TO BE USED ON THE FOLLOWING FIREPUMP ENGINES ONLY – 4B, 6B, AND 6C

ALL DIMENSIONS IN INCHES

L	REMOVED BATT ISOL EXCITE FUSE	RJS	25 OCT 06
K	W10 & W11 WERE 14 AWG	RJS	29 JUNE 06
J1	Chg'd red insulator boot p/n	RJS	21 March 05
J	REDREW TO FIT ECM ENGINES; ADDED ITEMS 19 & 20	RJS	4JUN05
REV	DESCRIPTION OF REVISION	BY	DATE

ALL RIGHTS TO MANUFACTURE, COPY, OR REPRODUCE THIS DRAWING OR ITS CONTENTS ARE RESERVED BY CLUMINS POWER, INC.

UNLESS OTHERWISE NOTED:
X = ± 0.03
XX = ± 0.01
XXX = ± 0.005
X = ± 0.03
XX = ± 0.01
XXX = ± 0.005

CLUMINS POWER
CORPORATE OFFICE
1600 BLUEHILL ROAD
WHITE BEAR LAKE, MN
WWW.CLUMINSPower.COM

CLUMINS FIRE POWER
DESIGN CENTER
875 LAWRENCE DRIVE
DEPERE, WISCONSIN
WWW.CLUMINSFIREPOWER.COM

DESCRIPTION
WIRING_HARNESS_SCHEMATIC

REFERENCE:
FIRE_PUMPS_NON-3.3LITER

DRAWING NUMBER:
8513SHT1_L




CIRCUIT DATA								
	FROM		TO					
CIRCUIT NO.	DESIG-NATOR	CAVITY POS./TERMINAL	DESIG-NATOR	CAVITY POS./TERMINAL	WIRE COLOR	WIRE SIZE (AWG)	INSUL TYPE	STAMP
<div><div><div>K</div></div><div><div>K</div></div><div><div>K</div></div></div>	C 1	B	W 5	1/2" RRG	W HT	16	SXL	FSO PULL-IN
	C 1	C	W 7	1/2" RRG	W HT	16	SXL	FSO GND
	C 2	A	C 4	B	W HT	16	GXL	OPS TO WTS
	C 3	C	S 1	-	W HT	16	SXL	EXCITE
	C 4	A	W 7	1/2" RRG	W HT	16	GXL	OPS GND
	S 1	-	W 22	1/4" RRG	W HT	16	SXL	BATT EXCITE
	C 6	1	W 16	#10 RING	W HT	16	SXL	MPU +
	C 6	2	W 17	#10 RING	W HT	16	SXL	MPU -
	C 6	3	C 1	A	W HT	16	SXL	FSO/KEY
	C 6	4	W 9	#10 RRG	W HT	16	SXL	OPG
	C 6	5	W 2	#10 RRG	W HT	16	SXL	WTG
	C 6	6	C 4	C	W HT	16	GXL	LOPL
	C 6	7	C 2	B	W HT	16	GXL	HWTL
	C 6	8	W 10	#10	W HT	10	SXL	CRANK A
	C 6	9	S 1	-	W HT	16	SXL	EXCITE
	C 6	10	W 11	#10 RING	W HT	10	SXL	CRANK B
<div><div><div>K</div></div><div><div>K</div></div></div>	C 6	13	W 23	NO TERM	W HT	14	SXL	RW SOL +
	C 6	14	W 12	1/2"	W HT	10	GXL	SYS GND
	C 6	16	W 13	3/8"	W HT	10	GXL	BATT A +
	C 6	17	W 24	NO TERM	W HT	14	SXL	RW SOL -
	C 6	18	W 14	3/8"	W HT	10	GXL	BATT B +
	W 18	#10	W 20	1/2" RRG	W HT	14	SXL	CRNK A GND
	W 19	#10	W 21	1/2" RRG	W HT	14	SXL	CRNK B GND
	W 3	5/16" RRG	W 6	1/4" RRG	W HT	6	GXL	ALTB +
	W 4	5/16" RRG	W 7	1/2" RRG	W HT	6	GXL	ALT GND

WIRING HARNESS CONTENT				
REF NO.	SUPPLIER	SUPPLIER PART NO.	QTY.	DESCRIPTION
1			8	#10 RING TERMINAL
2			2	1/4" RING TERMINAL
3			2	5/16" RING TERMINAL
4			2	3/8" RING TERMINAL
5			5	1/2" RING TERMINAL
10	DEUTSCH	HDP 26-24-19SN	1	MAIN CONNECTOR
11	PACKARD	12047950/12186566	1	ALTPUG CONN. ASMBLY
13	PACKARD	12162280	2	WTS/OPS CONN. W/SOCKETS & SEAL
14	PACKARD	12015793	1	FSO CONN. W/SOCKETS
18			1	FUSE 6 AMP
19	stella-maris	400N9V02	2	RED INSULATOR BOOT

REV	DESCRIPTION OF REVISION	BY	DATE
1	ADDED ITEMS 19 & 20	RJS	4/4/00
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57			
58			
59			
60			
61			
62			
63			
64			
65			
66			
67			
68			
69			
70			
71			
72			
73			
74			
75			
76			
77			
78			
79			
80			
81			
82			
83			
84			
85			
86			
87			
88			
89			
90			
91			
92			
93			
94			
95			
96			
97			
98			
99			
100			

[illegible]

BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	ASSEMBLY, STUB SHAFT, SAE #1, 3.5" DIA	11940
2	1	GUARD, FLYWHEEL, SAE#1, CFPI5E	12591
3	8	SCREW, CAP, HEX HEAD, 7/16-14 UNC x 0.75"	HHCS_0437_0075
4	8	SCREW, CAP, HEX HEAD, 1/2-13 UNC X 1.50"	HHCS_0500_0150



REV	DESCRIPTION OF REVISION	REV BY	DATE
A			

This document contains confidential and trade secret information, is the property of Cummins NPower, LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins NPower, LLC

UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE

ANGULAR DIMENSIONS ± 1°	IMPERIAL UNITS	METRIC UNITS
THIRD ANGLE PROJECTION	MACHINE TOLERANCES .XX ± .010 .XXX ± .005 FORM TOLERANCES .XX ± .030 .XX ± .015 FAB TOLERANCES .XX ± .000 .XX ± .030	MACHINE TOLERANCES .X ± .04 .XX ± .02 FORM TOLERANCES .X ± .08 .XX ± .04 FAB TOLERANCES .X ± .03 .XX ± .08

CUMMINS NPOWER, LLC
CORPORATE OFFICE
1600 BUERKLE ROAD
WHITE BEAR LAKE, MN
WWW.NPOWER.CUMMINS.COM


NPOWER SYSTEMS
DESIGN CENTER
875 LAWRENCE DRIVE
DEPERE, WISCONSIN

TITLE 1: ASSEMBLY, STUB SHAFT WITH GUARD
TITLE 2: FIREPUMP, CFPI5E



DWG UNITS: IN/LB/S	DRAWN BY: S.DANFORTH	DATE: 17JAN2008
EST WEIGHT: 71.028	APPD BY: -	DATE: -

SCALE: 0.250	DO NOT SCALE	SHEET 1 OF 1	DRAWING NO: 12590	REV: -
-----------------	-----------------	-----------------	----------------------	-----------

BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	1	ADAPTER, U-JOINT, SAE #1, HAYES #127830, FIREPUMP	9842
2	1	STUB SHAFT, HAYES, 128745	11941




7/8" KEYWAY



A	RELEASE TO PRODUCTION	MJD	01-07-08
REV	DESCRIPTION OF REVISION	REV BY	DATE



<div>This document contains confidential and trade secret information, is the property of Cummins NPower, LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins NPower, LLC</div>				<div>CUMMINS NPOWER, LLC CORPORATE OFFICE 1600 BUERKLE ROAD WHITE BEAR LAKE, MN WWW.NPOWER.CUMMINS.COM</div>		<div>NPOWER SYSTEMS DESIGN CENTER 875 LAWRENCE DRIVE DEPERE, WISCONSIN</div>					
<div>UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE</div>				<div>TITLE 1: ASSEMBLY, STUB SHAFT TITLE 2: SAE #1, 3.5" DIA</div>							
<div>ANGULAR DIMENSIONS ± 1°</div>		<div>IMPERIAL UNITS</div>	<div>METRIC UNITS</div>	<div>DWG UNITS: IN/LB/S</div>		<div>DRAWN BY: PBS APPD BY: -</div>		<div>DATE: 28-OCT-07 DATE: -</div>			
<div>THIRD ANGLE PROJECTION</div>		<div>MACHINE TOLERANCES .XX = ± 0.005 FORM TOLERANCES .XX = ± 0.030 .XXx = ± 0.015 FAB TOLERANCES .XX = ± 0.060 .XXx = ± 0.030</div>	<div>MACHINE TOLERANCES .X = ± 0.4 .XX = ± 0.2 FORM TOLERANCES .X = ± 0.8 .XX = ± 0.4 FAB TOLERANCES .X = ± 1.3 .XX = ± 0.8</div>	<div>EST WEIGHT: 59.627</div>		<div>SCALE: DO NOT 0.250 SCALE</div>		<div>SHEET 1 OF 1</div>		<div>DRAWING NO: 11940 REV: A</div>	



NOTES:

- 1) MATERIAL: 14 GA. HRS
- 2) ALL BENDS AT MINIMUM BEND RADIUS
- 3) REMOVE ALL BURS AND SHARP EDGES
- 4) PRIME AND PAINT FIRE ENGINE RED

REV	DESCRIPTION OF REVISION	REV BY	DATE
A			

<p>This document contains confidential and trade secret information, is the property of Cummins NPower, LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins NPower, LLC</p>				<p>CUMMINS NPOWER, LLC CORPORATE OFFICE 1600 BUERKLE ROAD WHITE BEAR LAKE, MN WWW.NPOWER.CUMMINS.COM</p>		<p>NPOWER SYSTEMS DESIGN CENTER 875 LAWRENCE DRIVE DEPERE, WISCONSIN</p>		
<p>UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE</p>			<p>TITLE 1: GUARD, FLYWHEEL, SAE#1 TITLE 2: CFPI5E</p>					
<p>ANGULAR DIMENSIONS ± 1°</p>	<p>IMPERIAL UNITS</p>	<p>METRIC UNITS</p>	<p>DWG UNITS: IN/LB/S</p>	<p>DRAWN BY: S.DANFORTH APPD BY:</p>		<p>DATE: 17JAN2008 DATE:</p>		
<p>THIRD ANGLE PROJECTION</p> 	<p>MACHINE TOLERANCES XX ± 0.010 XXX ± 0.005</p> <p>FORM TOLERANCES XX ± 0.030 XXX ± 0.015</p> <p>FAB TOLERANCES XX ± 0.040 XXX ± 0.030</p>	<p>MACHINE TOLERANCES X ± 0.4 XX ± 0.2</p> <p>FORM TOLERANCES X ± 0.8 XX ± 0.4</p> <p>FAB TOLERANCES X ± 1.5 XX ± 0.8</p>	<p>EST WEIGHT: 9.826</p>	<p>SCALE: 0.250</p>	<p>DO NOT SCALE</p>	<p>SHEET 1 OF 1</p>	<p>DRAWING NO: 12591</p>	<p>REV: _</p>

MASS ELASTIC DATA
STIFFNESS K = 0.023 DEG/100 LBFT
INERTIA W_r^2 = 3.05 LBxFT²



WEIGHT = 78.0 LB

UL LISTED VENDOR P/N 906052-1
ASSEMBLED AND BALANCED
P/N: 311929-001 (NO SERVICEABLE PARTS)

BOLT KIT:
P/N 300-1009 (THRU HOLE)
P/N 300-1010 (TAPPED HOLE)

UL LISTED RPM	UL LISTED TORQUE
1470	1525
1760	1525
2100	1525

ITEM	P/N	DESCRIPTION	QTY
1	5-281X	U-JOINT	2
2	6.5-2-359	FLANGE YOKE	2
3	6.5-3-1451KX	SLIP YOKE	1
4	6.5-82-511-1	STUB YOKE	1
5	D6E	DUST CAP	1



CFP#14346 LABEL PROVIDED WITH:
MFG-P/N-DATE CODE, MAX
VALUE, AND SERIAL NUMBER
(APPLIED BY SHAFT VENDOR)

TORQUE AT MIN SPEED
XXXX FT/LB AT XXXX RPM
TORQUE AT MAX SPEED
XXXX FT/LB AT XXXX RPM

40WU
FLEXIBLE CONNECTING SHAFT

XXXX = VALUES PER CHART
(4) PLACES

P/N
MFG-P/N-DATE CODE
SCALE 2.000

B	2009-090	ADDED DIMS. REV CHART	DAVE N	25MAR2009
A	2009-006	REV PER TITLE BLOCK. ADDED P/N	DAVE N	03FEB2009
REV	ENF	DESCRIPTION OF REVISION	REV BY	DATE

This document contains confidential and trade secret information, is the property of Cummins Fire Power LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins Fire Power LLC

UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE

ANGULAR DIMENSIONS ± 1°	IMPERIAL UNITS	METRIC UNITS
THIRD ANGLE PROJECTION	MACHINE TOLERANCES .XX ± 0.010 .XX ± 0.005 FORM TOLERANCES .XX ± 0.010 FAB TOLERANCES .XX ± 0.000 .XXX ± 0.030	MACHINE TOLERANCES .XX ± 0.2 .XX ± 0.1 FORM TOLERANCES .XX ± 0.8 .XX ± 0.4 FAB TOLERANCES .XX ± 0.5 .XX ± 0.8

DRIVESHAFT, 1810, SHORT COUPLED
UL LISTED FOR FIREPUMP SERVICE

DWG UNITS:	DRAWN BY: GVD	DATE: 19AUG2008
	PRO-ENGINEER	REF DRWG:
SCALE: 0.375	SHEET 1 OF 1	DRAWING NO: 13422
EST WEIGHT: 78.000		

MASS ELASTIC DATA
STIFFNESS K = 0.028 DEG/100 LBFT
INERTIA W_r² = 1.642 LBxFT²



WEIGHT = 74.0 LB

UL LISTED VENDOR P/N 12-0035811 
ASSEMBLED AND BALANCED
P/N: 311959-001 (NO SERVICEABLE PARTS)

BOLT KIT:
P/N 300-1009 (THRU HOLE)
P/N 300-1010 (TAPPED HOLE)


UL LISTED RPM	UL LISTED TORQUE
1470	2200
1800	2163

ITEM	P/N	DESCRIPTION	QTY
1	1109-90196	FLANGE YOKE	2
2	1116-90117	U-JOINT	2
3	1105-90434	CENTER SECTION	1
4			
5			



SCALE 0.188

CFP#14346 LABEL PROVIDED WITH:
MFG-P/N-DATE CODE, CHART
VALUES, AND SERIAL NUMBER
(APPLIED BY SHAFT VENDOR)



TORQUE AT MIN SPEED
XXXX FT/LB AT XXXX RPM
TORQUE AT MAX SPEED
XXXX FT/LB AT XXXX RPM

UL LISTED
40WU
FLEXIBLE CONNECTING SHAFT

XXXX = VALUES PER CHART
(4) PLACES

P/N • MFG-P/N-DATE CODE


SCALE 2.000

B	2009-090	REV P/N. ADDED DIMS. RFEV CHART	DAVE N	25MAR2009
A	2009-006	REV PER TITLE BLOCK. ADDED P/N	DAVE N	03FEB2009
REV	ENF	DESCRIPTION OF REVISION	REV BY	DATE

This document contains confidential and trade secret information, is the property of Cummins Fire Power LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins Fire Power LLC

UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE

ANGULAR DIMENSIONS ± 1°	IMPERIAL UNITS	METRIC UNITS
THIRD ANGLE PROJECTION	MACHINE TOLERANCES .XX ± 0.010 .XX ± 0.005 FORM TOLERANCES .XX ± 0.010 FAB TOLERANCES .XX ± 0.005 .XXX ± 0.030	MACHINE TOLERANCES .XX ± 0.4 .XX ± 0.2 FORM TOLERANCES .XX ± 0.8 .XX ± 0.4 FAB TOLERANCES .XX ± 0.5 .XX ± 0.8




CUMMINS FIRE POWER LLC
CORPORATE OFFICE
1600 BUERKLE ROAD
WHITE BEAR LAKE, MN
WWW.CUMMINSFIREPOWER.COM

CUSTOM DESIGN
AND UPFIT CENTER
875 LAWRENCE DRIVE
DEPERE, WISCONSIN

SHAFT, U3172, SHORT COUPLED
UL LISTED FOR FIREPUMP SERVICE

DWG UNITS:	DRAWN BY: GVD PRO-ENGINEER	DATE: 19AUG2008 REF DRWG:
SCALE: 0.313 EST WEIGHT: 74.000	SHEET 1 OF 1	DRAWING NO: 13430

BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	2	WELDMENT, SPLIT BACK PLATE, SHAFT GUARD, TELESOPING, SIZE I-X, SHORT COUPLED SH	14238
2	2	COVER, TELESOPING, SHAFT GUARD, FIREPUMP SIZE X	14148
3	8	SCREW, CAP, HEX HEAD, M10 x 20	HHCS_M10_20
4	4	SCREW, CAP, HEX HEAD, M8 x 20	HHCS_M8_20



This document contains confidential and trade secret information, is the property of Cummins Fire Power LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document accepts the document in confidence and agrees that, except as authorized in writing by Cummins NPower, it will (1) not use the document or any copy thereof or the confidential or trade secret information therein, (2) not copy the document, (3) not disclose to others either the document or the confidential or trade secret information therein, and (4) upon completion of the need to retain the document, or upon demand, return the document, all copies thereof, and all material copied therefrom. COPYRIGHT Cummins Fire Power LLC

CUMMINS FIRE POWER LLC
CORPORATE OFFICE
1600 BUEKLE ROAD
WHITE BEAR LAKE, MN
WWW.CUMMINSFIREPOWER.COM


CUSTOM DESIGN
AND UPFIT CENTER
875 LAWRENCE DRIVE
DEPERE, WISCONSIN

ASSEMBLY, SHAFT GUARD, TELESOPING, SIZE I-XL
SHORT COUPLED SHAFT

DWG UNITS: IN/LB/S	DRAWN BY: DAVE N PRO-ENGINEER	DATE: 11DEC2008 REF DRWG:
SCALE: 0.250 EST WEIGHT: 28.276	SHEET 1 OF 1	DRAWING NO: 14161






REV	ENF	DESCRIPTION OF REVISION	REV BY	DATE

BILL OF MATERIAL			
ITEM	QTY	DESCRIPTION	PART NUMBER
1	2	WELDMNT, SPLIT BACK PLATE, SHAFT GUARD, TELESOPING, SIZE I-XL, SHORT COUPLED S	I4238
2	2	COVER, TELESOPING, SHAFT GUARD, FIREPUMP SIZE XL	I4237
3	8	SCREW, CAP, HEX HEAD, M10 x 20	HHCS_M10_20
4	4	SCREW, CAP, HEX HEAD, M8 x 20	HHCS_M8_20



CFP15E CONNECTION INFORMATION	
SAE #1	FLYWHEEL HOUSING
3/4" NPT	FUEL INLET
3/4" NPT	FUEL OUTLET
1 1/4" NPT	RAW WATER INLET
1 1/2" NPT	RAW WATER DISCHARGE
120 / 240 VAC	COOLANT HEATER (3000WATTS)
6" DIA NPT, CUFF, OR FLANGE	EXHAUST CONNECTION
OPTIONAL DRIVESHAFT	8.5C WING BEARING TYPE
OPTIONAL STUB SHAFT	3.5" DIAMETER (88.9MM)

- NOTES:
1. ALL PLUMBING MUST BE SUPPORTED AND/OR ISOLATED SO THAT NO WEIGHT OR STRESS IS APPLIED TO ANY ENGINE COMPONENT.
 2. REFER TO ENGINE DATA SHEET FOR CUSTOMER CONNECTION RECOMMENDATIONS.
 3. DO NOT SCALE DRAWING.
 4. DRAWING SUBJECT TO CHANGE WITH OUT NOTICE.









ENGINE ONLY DETAILS FOR CFP15E-F10 THRU F40
SEE SHEET 2 FOR CFP15E-F50 THRU F70.
CHANGES TO CFP5E-F50-70 INCLUDE TALLER
EXHAUST BELLOWES, HIGH MOUNTED AIR FILTER
AND LARGER OIL SUMP

B	DRAWING UPDATES	S DUBICK	02/18/08
REV	DESCRIPTION OF REVISION	REV BY	DATE

REF. SCALES		REV. SCALES	
<p>This document contains technical information that is the property of Cummins Inc. and is loaned to you for your use only. It is to be used for information only and is not to be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage and retrieval system, without the prior written permission of Cummins Inc. This document is the property of Cummins Inc. and is loaned to you for your use only. It is to be used for information only and is not to be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage and retrieval system, without the prior written permission of Cummins Inc.</p>		<p>CUMMINS INCORPORATED INCORPORATED OFFICE 1600 BUCKLE ROAD SPRING LAKE, ILL. 60178-1000 WWW.POWER.BY.CUMMINS.COM</p>	
<p>INCORPORATED SYSTEMS DESIGN CENTER 875 LAFAYETTE DRIVE DEARBORN, WISCONSIN</p>			
<p>TITLE 1: GENERAL ARRANGMENT, INSTALLATION TITLE 2: CPFSIE F10 - F40 AND F50 - F70</p>			
<p>DWG UNITS: DRAWN BY: S. DANFORTH IN/LB/S: APPD BY: DATE: -</p>			
<p>EST WEIGHT: SCALE: DO NOT SHEET DRAWING NO: REV: B VARIES: 0.100 SCALE 1067 11656</p>			

CFP15E CONNECTION INFORMATION	
SAE #1	FLYWHEEL HOUSING
3/4" NPT	FUEL INLET
3/4" NPT	FUEL OUTLET
1 1/4" NPT	RAW WATER INLET
1 1/2" NPT	RAW WATER DISCHARGE
120 / 240 VAC	COOLANT HEATER (3000WATTS)
6" DIA NPT, CUFF, OR FLANGE	EXHAUST CONNECTION
OPTIONAL DRIVESHAFT	8.5C WING BEARING TYPE
OPTIONAL STUB SHAFT	3.5" DIAMETER (88.9MM)

- NOTES:
1. ALL PLUMBING MUST BE SUPPORTED AND/OR ISOLATED SO THAT NO WEIGHT OR STRESS IS APPLIED TO ANY ENGINE COMPONENT.
 2. REFER TO ENGINE DATA SHEET FOR CUSTOMER CONNECTION RECOMMENDATIONS.
 3. DO NOT SCALE DRAWING.
 4. DRAWING SUBJECT TO CHANGE WITH OUT NOTICE.





ENGINE ONLY DETAILS FOR CFP15E-F50 THRU F70
SEE SHEET 1 FOR CFP15E-F10 THRU F40.
CHANGES TO CFP5E-F50-70 INCLUDE TALLER
EXHAUST BELLOW, HIGH MOUNTED AIR FILTER
AND LARGER CAPACITY OIL SUMP


B	DRAWING UPDATES	S DUBICK	02/18/08
REV	DESCRIPTION OF REVISION	REV BY	DATE

This document contains confidential information and is the property of Cammus Power, LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of the document, accepts the document in confidence and agrees to maintain the confidentiality of the document. Cammus Power, LLC will not allow the document or any copy thereof or the confidential or trade secret information contained therein to be released to any third party (not the customer) to whom the document or the confidential or trade secret information therein is directed. Cammus Power, LLC will not be obligated to return the document or the confidential or trade secret information to the customer, or upon demand, return the document, all copies thereof, and all material copy thereon. COPYRIGHT Cammus Power, LLC.


UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE

ANGULAR DIMENSIONS	IMPERIAL UNITS	METRIC UNITS
THIRD ANGLE PROJECTION		
	MAXIMUM TOLERANCE	MAXIMUM TOLERANCE
	FORM TOLERANCES	FORM TOLERANCES
	POSITION TOLERANCES	POSITION TOLERANCES
	ORIENTATION TOLERANCES	ORIENTATION TOLERANCES
	LOCATION TOLERANCES	LOCATION TOLERANCES

	CUMMINS NPPOWER, LLC CORPORATE OFFICE 1060 BUEKLE RD WHITE BEAR LAKE, WI WWW.NPPower.CUMMINS.COM		NPPOWER SYSTEMS DESIGN CENTER 875 LAWRENCE DR DEPERE, WISCONSIN	
	TITLE 1: GENERAL ARRANGMENT, INSTALLATION TITLE 2: CPPISE F10 - F40 AND F50 - F70			
DWG UNITS: IN/LB/S	DRAWN BY: S. DANFORTH APPD BY: -		DATE: - DATE: -	
EST WEIGHT: VARIES	SCALE: 0.100	DO NOT SCALE	SHEET 20F6	DRAWING NO: 11656
				REV: B




STANDARD STUB SHAFT SHOWN




STANDARD SC DRIVESHAFT SHOWN

3.0° MAX., 1.0° MIN.



STANDARD 36" DRIVESHAFT SHOWN


3.0° MAX., 1.0° MIN.



STANDARD 24" DRIVESHAFT SHOWN


3.0° MAX., 1.0° MIN.

B	DRAWING UPDATES	S DUBICK	02/18/08
REV	DESCRIPTION OF REVISION	REV BY	DATE

REF. SCALES			
<p>THIS DOCUMENT CONSTITUTES A CONTRACT. IT IS TO BE READ IN CONJUNCTION WITH THE SPECIFICATIONS AND DRAWINGS. THE CONTRACTOR SHALL BE RESPONSIBLE FOR OBTAINING ALL NECESSARY PERMITS AND APPROVALS. THE CONTRACTOR SHALL BE RESPONSIBLE FOR OBTAINING ALL NECESSARY PERMITS AND APPROVALS. THE CONTRACTOR SHALL BE RESPONSIBLE FOR OBTAINING ALL NECESSARY PERMITS AND APPROVALS.</p>		<p>Fire Power</p> <p>CUMMINS POWER, LLC CORPORATE OFFICE 1000 BUCKEYE ROAD MILWAUKEE, WI 53217 WWW.NPOWER.COM/CUMMINS.COM</p> <p>WPOWER SYSTEMS DESIGN CENTER 875 LAWRENCE DRIVE RAFTERS, WISCONSIN</p>	
UNLESS OTHERWISE SPECIFIED ALL DIMENSION TOLERANCES ARE:			
ANGULAR DIMENSIONS ± .1°	IMPERIAL UNITS	METRIC UNITS	TITLE 1: GENERAL ARRANGMENT, INSTALLATION TITLE 2: CP15E F10 - F40 AND F50 - F70
	MAX. TOLERANCE IN: 0.005 FRACTIONAL DECIMAL INCHES	MAX. TOLERANCE MM: 0.13 FRACTIONAL DECIMAL MILLIMETERS	
THIRD ANGLE PROJECTION			DWG. UNITS: IN/LB/S
			APPD BY: _____
			EST WEIGHT: VARIES
			DRAWN BY: S. DANFORTH
			SCALE: 0.100
			SHEET 30FG
			DATE: _____
			DRAWING NO: 11656
			REV: B

CFP15E CONNECTION INFORMATION	
SAE #1	FLYWHEEL HOUSING
3/4" NPT	FUEL INLET
3/4" NPT	FUEL OUTLET
1 1/4" NPT	RAW WATER INLET
1 1/2" NPT	RAW WATER DISCHARGE
120 / 240 VAC	COOLANT HEATER (3000WATTS)
6" DIA NPT, CUFF, OR FLANGE	EXHAUST CONNECTION
OPTIONAL DRIVESHAFT	8.5C WING BEARING TYPE
OPTIONAL STUB SHAFT	3.5" DIAMETER (88.9MM)

-
- 49.14
- 23.99
- STARTER CONTACTOR 1
BATTERY CONNECTION
- STARTER CONTACTOR 1
- CRANK SHAFT ϕ
- STARTER CONTACTOR 2
BATTERY CONNECTION
- STARTER CONTACTOR 2
- INTEGRAL BATT LOCATION SHOWN



EXHAUST LOCATION
FLANGED OPTION SHOWN

GAUGE PANEL /
CUSTOMER CONNECTION

AIR FILTER

ECM SWITCH

DIP STICK

FUEL FILTER

RAW WATER
OUTLET

OIL DRAIN

REAR LIFT POINT

86.53 REF
CFPI5e-F50
THRU
CFPI5e-F70

75.83 REF
CFPI5e-F10
THRU
CFPI5e-F40

49.65 FUEL PUMP
INLET PORT \varnothing

35.50 CRANK \varnothing

10.00

1.98

9.65

25.00

44.00

88.00

73.56

126.00

$\varnothing 0.88$ HOLES
6 PLACES





76.63

25.41

B	DRAWING UPDATES	S DUBICK	02/18/08
REV	DESCRIPTION OF REVISION	REV BY	DATE


CFP15E CONNECTION INFORMATION	
SAE #1	FLYWHEEL HOUSING
3/4" NPT	FUEL INLET
3/4" NPT	FUEL OUTLET
1 1/4" NPT	RAW WATER INLET
1 1/2" NPT	RAW WATER DISCHARGE
120 / 240 VAC	COOLANT HEATER (3000WATTS)
6" DIA NPT, CUFF, OR FLANGE	EXHAUST CONNECTION
OPTIONAL DRIVESHAFT	8.5C WING BEARING TYPE
OPTIONAL STUB SHAFT	3.5" DIAMETER (88.9MM)

- NOTES:
1. ALL PLUMBING MUST BE SUPPORTED AND/OR ISOLATED SO THAT NO WEIGHT OR STRESS IS APPLIED TO ANY ENGINE COMPONENT.
 2. REFER TO ENGINE DATA SHEET FOR CUSTOMER CONNECTION RECOMMENDATIONS.
 3. DO NOT SCALE DRAWING.
 4. DRAWING SUBJECT TO CHANGE WITH OUT NOTICE.
 5. SEE SHEET 1 FOR OIL PAN REMOVAL REQUIREMENTS.



NOTE:
BOTH ASSEMBLIES SHOWN. CFP15E-F10 THRU F40 TIER 3
AND CFP15E-F50 THRU F70 TIER 2
OPTIONAL DRIVELINE EQUIPMENT SHOWN
REPRESENTATIVE PUMP SHOWN

B	DRAWING UPDATES	S DUBICK	02/18/08
REV	DESCRIPTION OF REVISION	REV BY	DATE

This document contains confidential and trade secret information, is the property of Cummins Wipac, LLC and is given to the receiver in confidence. The receiver, by receiving and retaining of this document accepts the responsibility of controlling and protecting the document from unauthorized disclosure. Cummins Wipac, LLC will not use the document or any copy thereof or the information contained therein for any purpose other than that for which it was provided. Cummins Wipac, LLC will not copy the document or any part thereof without the express written consent of Cummins Wipac, LLC. Cummins Wipac, LLC will not disclose the information contained in this document or the confidential or trade secret information contained therein, and its agents, employees, or representatives, to any third party without the express written consent of Cummins Wipac, LLC. All material is the property of Cummins Wipac, LLC.				NP POWER, LLC CORPORATE OFFICE 1600 BUENA VISTA ROAD WHITE BEAR LAKE, MN WWW.NPPOWER.CUMMINS.COM		NPPOWER SYSTEMS DESIGN CENTER 875 LAWRENCE DRIVE DEER, WISCONSIN											
TITLE 1: GENERAL ARRANGMENT, INSTALLATION TITLE 2: CPFS1E F10 - F40 AND F50 - F70																	
ANGULAR DIMENSIONS \pm 1°		IMPERIAL UNITS		METRIC UNITS		DWG UNITS:		DRAWN BY: S. DANFORTH		DATE: -							
THIRD ANGLE PROJECTION		DWG UNITS: IN/LB/S		APPD BY: -		DATE: -		EST WEIGHT: VARIES		DO NOT SCALE		SHEET 50F6		DRAWING NO: 11656		REV: B	

Lubricating Oil System Specifications

Recommended lube oil filter	Fleetguard 3101869
-----------------------------	--------------------

	Metric	US
Oil pressure range at rated	276-414 kPa	40-60 PSI
Oil capacity of pan (high - low)	34-30 liter	9.0-8.0 U.S. Gal
Total system capacity	36.7 liter	9.7 U.S. Gal.

Cooling System Specifications

Recommended Coolant Filter	Fleetguard
----------------------------	------------

	Metric	US
Maximum raw water working pressure range at heat exchanger	414 kPa	60 PSI
Recommended minimum water supply pipe size to heat exchanger	25.4 mm D.	1.0 in. D.
Recommended minimum water discharge pipe size from heat exchanger	31.2 mm D.	1.25 in. D.
Coolant water capacity (engine side)	9.5 liter	2.5 U.S. Gal.
Modulating thermostat range	82-93 °C	180-200 °F
Minimum raw water flow with water temperatures to 90 °F (32°C)	2.5 liter/s	40 U.S. GPM

Air Intake System Specifications

NOTE: Engine intake air must be filtered to prevent dirt and debris from entering the engine. If intake air piping is damaged or loose, unfiltered air will enter the engine and cause premature wear.

Recommended air cleaner element	(Standard) K&N (Optional) Donaldson
---------------------------------	--

	Metric	US
Maximum temperature rise between ambient air and engine air inlet	15 °C	30 °F
Maximum inlet restriction with dirty filter	635 mm H ₂ O	25 in. H ₂ O

Exhaust System Specifications

	Metric	US
Maximum exhaust back pressure imposed by complete exhaust system	10.2 kPa	40.8 in. H ₂ O
Exhaust pipe size normally acceptable	127 mm D.	5 in. D.

General Engine Data NOTE: The following engine and system specification data is extracted from the curves and data sheets that were current when this document was prepared. Refer to www.CumminsFirePower.com if current information is required. Refer to the base engine troubleshooting and repair manual for base engine coverage (see Service Literature in Engine Manual).

Type	4 Cycle; In-Line; 6 Cylinder
Firing Order	1-5-3-6-2-4
Rotation, Viewed from the Front of the Engine	Clockwise
Compression Ratio:	17.0:1
Valves per cylinder: Inlet/Exhaust	2 / 2
Cummins Base Engine Fuel Rating	FR - 10663
Cummins Engine Co. Base Engine	QSX15 Industrial
Installation Drawing	8715
Configuration Number	D103007CX03
Fuel System	HPI Electronic
Aspiration	Turbocharged, Charge Air Cooled

	Metric	US
Bore	137 mm	5.39 in.
Stroke	169 mm	6.65 in.
Displacement	15 liter	915 in. ³
Intake Valve Clearance	0.36 mm	0.014 in
Exhaust Valve Clearance	0.69 mm	0.027 in
Dry Weight lb (kg)	1813 kg	4029 lb
Wet Weight lb (kg)	1881 kg	4179 lb

NOTE: The engine features a no-adjust overhead. The valve train is designed such that adjustment of the valve lash is not required for normal service during the first 5,000 hours. The valve train operates acceptably within the limits of 0.152- to 0.381-mm [0.006- to 0.015-in] intake valve lash and 0.381- to 0.762-mm [0.015- to 0.030in] exhaust valve lash.

Fuel System Specifications

Fuel	Type	Number 2 Diesel
Recommended primary fuel filter	Fleetgard	3104081

	Metric	US
Minimum supply line size	19.05 mm D.	0.75 in. D.
Minimum drain line size	19.05 mm D.	0.75 in.D.
Maximum fuel line length between supply tank & fuel pump	12 m	40 ft.
Maximum fuel height above C/L crankshaft	3048 mm	120 in.
Maximum restriction @ lift pump-inlet - with clean filter	152 mm Hg	6 in. Hg
Maximum restriction @ lift pump-inlet - with dirty filter	254 mm Hg	10 in. Hg
Maximum return line restriction - without check valves	229 mm Hg	9 in. Hg
Minimum fuel tank vent capability	2.10 m ³ /hr	70 ft ³ /hr
Maximum fuel temperature @ lift pump inlet	71 °C	160 °F

Electrical System Specifications

Start Circuit

The start circuit consists of a single starter motor and redundant starter control relays as well as using redundant power sources 24 V (optional) comprised of 12 V wet type storage batteries (optional at shipment).

The battery, starter and starter solenoid positive terminals are booted with a non-conducting cover or otherwise insulated from unintended grounding. Battery cable leads from the batteries to the designated connection points in the starting circuit are minimum 6.53 mm D. (No. 2 AWG), neoprene or rubber insulated with a 1.5 mm (0.060 in.)

minimum insulation thickness rated 80°C (176 °F) minimum. The starter and starter solenoid are all metal enclosed.

Wiring for automatic starting (negative ground)	Standard
Reference wiring diagram	10423 (see Section 8.5)
B.C.I. Group Size	8D

		24V
Minimum recommended battery cold cranking amperes (CCA) ⁽¹⁾		700 Amps
Minimum recommended battery reserve capacity		800 Minutes
Maximum resistance of starting circuit		0.0017 Ohms
Typical cranking speed		120 RPM
Alternator (standard), internally regulated		70 Amps
Battery Cable Size (Metric) (For less than 1.5 meters long)		10.6 mm D.
Battery Cable Size (US) (For less than 5 feet long)		00 AWG

(1) Cold soak at -18 °C (0 °F) or above



Index

A

Air Cleaner Service Indicator	6-2, 6-9
Air cooler	7-19
Air filter	6-4, 6-19
Air Intake Filter	6-2, 6-4
Air Intake System	2-4, 7-22
Alternator	3-3, 7-4
Alternator Belt	6-2, 6-18
Alternator Belt Replacement	6-2, 6-24
Alternator Belt Tension	6-2, 6-19
Alternator pulley	7-4
Alternator rotor	7-4
Annual Maintenance	6-2, 6-10
Antifreeze	6-9, 7-6
Antifreeze concentration	6-9
AUTO Mode	3-7, 3-12, 4-2, 5-1
AUTO/MANUAL (ON/OFF) Switch	4-2
AUTO/MANUAL Mode Switch	4-2, 5-1
AUTO/MANUAL Rocker Switch	7-12, 7-14
AUTO/MANUAL Start Switch	3-12, 5-1, 5-2, 5-3
AUTO/MANUAL Switch Lock Button	3-13, 5-2, 5-3
Auxiliary Battery Starting	3-6

B

Batteries	3-5, 7-4
Battery Cable Kit	3-6
Battery cables	6-8, 7-17
Battery cell specific gravity	3-6
Battery charge	7-5
Battery Condition	6-2, 6-7
Battery electrolyte	3-6
Battery hydrometer	6-8
Battery Installation	3-6
Battery isolator	7-4
Battery Selection	3-5
Battery terminal cables	6-10
Battery Voltmeters	4-2
Belt Tensioner	6-23
Bill of Lading	3-1
Blowby	7-22
Breakers	6-11, 7-6

C

Calibration	7-19
Charge Air Cooler	3-9

Charge Air Cooler Heat Exchanger	6-2, 6-25
Charge air cooling loop	3-8, 6-5
Charge air heat exchanger	2-5
Charge-Air-Cooler™ (CAC) Heat Exchanger	2-5
Circuit Breaker	4-2, 7-12
Claim Filing Procedure	3-1
Cleaning solution	6-25
Cold cranking ampere	3-5
Combustible fumes	7-20
Combustion air	2-4
Continuity	6-8
Control power	3-7
Coolant filter	7-23
Coolant Heat Exchanger	7-7
Coolant heater	3-9, 6-9, 7-10
Coolant leaks	7-6, 7-8
Coolant level	7-7
Coolant System Preparation	3-8
Coolant Temperature	4-1, 7-8
Coolant thermostat	7-9
Cooling System	6-2, 6-4, 6-20
Cooling water piping	3-1
Corrosion	6-4
CRANK BATT A/B Rocker Switch	3-13, 5-2
CRANK BATT A/B Switch	4-4
CRANK Signal	5-1
Crank Terminate Input	3-7
Crank Terminate Potentiometer	6-16
CRANK TERMINATE Signal	5-1
Crank terminate signal	7-24
Crank Termination Set Point	5-4, 6-15
Crankcase Breather Tube	6-2, 6-7
Crankcase dip stick	3-10
Cranking systems analyzer	3-6
Crankshaft rotation	7-16
Customer supplied wiring	3-6

D

Damage During Shipping	3-1
DEC position	6-16
Diesel (ASTM no. 2D) fuel specifications	3-3, 3-4
Drain and Flush Cooling System	6-2, 6-20
Drive belt tension	7-4
Drive shaft universal joint	3-3

Index

E

ECM A/B Indicator Lights	4-4
ECM A/B Selector Switch	5-2
ECM Code	4-5
ECM Data Plate	4-5
ECM date code (DC)	4-5
ECM Fault Code Lights	4-4, 5-4
ECM part number (PN)	4-5
ECM serial number (SN)	4-5
Electrical connections	6-11
Electrical continuity	3-8, 7-11
Electrical fault	7-18
Electrolyte	6-8
Electronic Control Module	4-4
Electronic fuel system	2-7
Emergency Manual Mode Electrical Start	5-3
Emission levels	2-3
Engine Control Panel	3-13, 5-2
Engine cooling fluid	3-4
Engine crank center line	3-2
Engine Heater	6-2, 6-9
Engine heater power supply	6-20
Engine Mounting Bolts	6-2, 6-11
Engine noise	6-9
Engine Operating Speed	5-3
Engine Operation Report	6-1
Engine Overspeed	4-3, 4-6
Engine Protection Fault	4-6
Engine serial number (ESN)	4-5
Engine Shutdown Lamp	4-4
Engine Start	3-13
Engine Start Test	3-12
Engine Warning Lamp	4-4
Equipment Placement and Assembly	3-1
Excess oil	7-17
Exhaust manifold	6-7, 7-21
Exhaust piping	3-2, 6-7
Exhaust System	2-10, 6-2, 6-7
Expansion tank pressure cap	3-8

F

Factory Mutual Approval	2-1
Filter blockage indicator	6-4
Filter gasket	6-13
Filter mounting head	6-14
Filter pop-up indicator	6-19
Fire Pump Control Panel	3-12, 5-1
Fire pump controller	3-6, 3-7

Fluid levels	6-4
Fuel control system	4-4
Fuel Cooling Heat Exchanger	2-7
Fuel Filter	3-3, 6-2, 6-14, 7-15
Fuel line pressure	6-6
Fuel Pump	3-3, 6-2, 6-12
Fuel pump solenoid valve	2-4
Fuel Recommendations	3-4
Fuel return line	3-3
Fuel Supply	2-7
Fuel Supply Installation	3-3
Fuel supply line	3-3, 6-6
Fuel supply valves	6-14
Fuel system	7-15
Fuel System Inspection	6-2, 6-6
Fuel tank	3-3
Fuel tank breather	7-18

G

Grease fittings	3-3
Guards, covers and protective devices	1-1

H

Heat exchanger	6-5, 6-25
Heat Exchanger Pressure Test	6-2, 6-19
High Coolant Temperature	4-6
High Water Temperature Alarm	3-8, 4-1
High Water Temperature Set Point	4-1
High Water Temperature Warning Lamp	4-1, 4-3
Hose clamps	6-5
Hoses	7-9
Hour Meter	4-2

I

INC position	6-16
Inductive charging	3-6
Injection pump	7-21
Injection timing	7-20
Injector Fuel System	2-7
Insite™ service tool	4-5
Instrument Panel	2-3
Intake Manifold	7-23
Integrated Acceptance Testing	5-5
Isolated Acceptance Testing	5-5

J

Jumper cables	3-6
---------------------	-----

L

Lift Pump	3-3
Lifting hooks	3-1
Loose Wire Kit	3-6
Low Coolant Level	4-6
Low Coolant Temperature	4-6
Low Oil Level	4-6
Low Oil Pressure	4-6
Low Oil Pressure Alarm Input	3-7
Low Oil Pressure Warning Lamp	4-1, 4-3
Lubricating Oil	6-2, 6-12, 6-13, 7-9
Lubricating Oil Cooler	7-6
Lubricating Oil System	2-10, 3-10, 6-2, 6-5
Lubrication Oil Pressure Gauge	4-1

M

Maintenance	5-2, 6-1
MANUAL Local Start	5-5
MANUAL Mode	4-2, 7-20
Manual Override Contactor A/B Levers	3-13
MANUAL START Position	3-13
Maximum engine coolant temperature	2-7
Minimum raw water flow	3-13

N

National Fire Protection Association	3-1
--	-----

O

Odors	6-4
Oil capacity	2-10, 6-12
Oil Filter Change	6-2, 6-12
Oil level	3-10, 6-5, 7-10, 7-17
Oil pan drain plug	6-12
Oil pressure	3-13, 6-4, 6-9
Oil System	2-10
Open circuit	7-5
Operating speed (RPM)	2-4
Operating temperature	3-14
Operator Control Panel	2-3, 4-1
Output Shaft Lubrication	6-2, 6-15
Overspeed Alarm Input	3-7
Overspeed module	2-4
Overspeed Potentiometer	6-17
Overspeed RESET/STOP Switch	4-3
Overspeed Set Point	5-3, 6-17
Overspeed Switch	2-4, 3-7, 4-5
Overspeed Warning Light	4-3

P

Power supply	7-10
Pre-Start Inspection	3-11
Pressure Cap	7-8
Pressure-test	7-23
Programmable Parameters	7-19

R

Raw water flow	3-13
Raw Water Piping	3-4, 3-8, 6-5
Receiving and Handling Information	3-1
Refractometer	6-9
RESET Button	4-2, 4-3
Returned Goods Authorization (RGA)	8-1
Run Test	6-2, 6-8

S

Safety Awareness	1-1
Sediment	6-7
Shipping manifest	3-1
Signal and Control Installation	3-6
Site Preparation	3-1
Solenoid Valve	7-11
Specific gravity	6-8
Speed INCREASE/DECREASE Toggle Switch ..	6-16
Speed Sensor	7-13, 7-24
Speedswitch TEST Button	6-17
Start-Up Inspection (SUI) Checklist	5-5
Starter Motor	2-4, 7-17
STOP/RESET Rocker Switch	5-3

T

Tachometer	4-2, 7-13
Temperature Gauge	7-10
Temperature Sender	7-10, 7-11
Temperature Switch	7-10
Tensioner arm	6-23
Terminal panels	6-11
Testing	5-2
Thermostat	6-2, 6-22, 7-10
Turbocharger	7-21
Turbocharger Inspection	6-2, 6-19
Turbocharger turbine wheel	3-11, 6-20

U

Universal joint grease fittings	6-15
---------------------------------------	------

Index

V

Valve lash settings	6-22
Valvoline Premium Blue®	3-10
Voltage regulator	7-4
Voltmeter	3-8, 6-11, 7-5

W

Warning lamps	6-11
Water bypass valves	7-14
Water Cooling System	2-5
Water filter shutoff valve	6-25
Water Flow Control Valves	4-5
Water jacket cooling system	2-7
Water piping	7-9

Water pressure regulator	7-7
Water pump	3-3, 7-9
Water Pump Belt	6-2, 6-17, 6-23
Water pump belt tension	6-18
Water Pump Inspection	6-2, 6-20
Water strainer	7-9
Water strainers	6-7
Water/fuel separator	3-3, 6-6
Weekly Maintenance	6-2, 6-4
Wire damage	7-5
Wiring harness	6-11
www.cumminsfirepower.com/startup	5-5

Z

zinc plug	7-7
-----------------	-----



Index

A

Acceptance Testing	
Integrated	5-5
Isolated	5-5
Air Filter	6-4, 6-19
Service Indicator	6-4, 6-10, 6-19
Air Intake System	2-4, 7-25
Inspection	6-4
Alarm	
High Coolant Temperature Alarm	4-1
High Coolant Temperature Input	3-8
Low Oil Pressure	3-8, 4-3
Alternator	3-3, 7-8
Drive Belt	6-18
Drive Belt Replacement	6-24
Drive Belt Tension	6-18, 7-8
Drive Belt Tensioner	6-18, 6-19, 6-25
Pulley	7-8
Rotor	7-8
Annual Maintenance	6-10
Antifreeze	6-9, 7-10
AUTO/MANUAL Mode	2-4, 3-7, 3-12, 4-2, 5-1
Switch	3-12, 4-2, 5-1, 5-2, 5-3, 7-15, 7-17
Switch Locking Button	3-13, 5-2, 5-3
AUTO/MANUAL Mode Switch	
MANUAL Position	3-13

B

Bateries	
Specific Gravity	6-8
Batteries	3-5, 7-8
Auxiliary Battery Starting	3-6
Cable Kit	3-6
Cables	6-8, 6-10, 7-19
Charging	7-9
Cleaning	6-8
Cold Cranking Ampere	3-5
Condition	6-7
Continuity	6-8
Electrolyte	3-6, 6-8
Electrolyte Level	6-8
Hydrometer	6-8
Installation	3-6
Isolator	7-8
Output Amperage Test	3-6
Selection	3-5

Specific Gravity	3-6
Specifications	3-5
Voltmeters	4-2
Bill of Lading	3-1

C

Charge Air Cooler/Heat Exchanger	2-4, 6-25, 7-22
Cleaning	6-25
Pressure Test	6-19
Removal	6-25
System Description	3-9
Charge Air Cooling System	6-4
Charge AirCoolerHeat Exchanger	2-5
Circuit Breaker	7-9, 7-15
Circuit Breakers	4-2, 6-11, 7-9, 7-15
Claim Filing Procedure	3-1
Cleaning Solution	6-27
Combustible Fumes	7-23
Combustion Air	2-4
Contactar	
A/B Levers	3-13
Manual Override	3-13
Control Power Connection	3-7
Coolant	
Contamination	7-10
Filter	7-26
Heat Exchanger	3-4, 7-10
Heat Exchanger Pressure Test	6-19
Heat Exchanger Zinc Plug	7-10
Heater	3-9, 6-9, 7-13
Heater Power Supply	6-21, 7-13
High Temperature Set Point	4-1
High Temperature Warning Lamp	4-1, 4-3, 4-6
Hose Clamps	6-5
Hoses	3-8, 7-12
Leaks	7-11
Level	2-7, 3-8, 3-14, 6-4, 6-5, 6-22, 7-11
Low Level Warning Lamp	4-6
Low Temperature Warning Lamp	4-6
Maximum Temperature	2-7
Pressure/Fill Cap	7-11
System Drain and Flush	6-20
System Inspection	6-4
Temperature	7-12
Temperature Gauge	4-1, 7-13
Temperature Sender	7-13
Temperature Switch	7-13

Index

Testing 6-9
Thermostat 6-23, 7-13, 7-14
Coolant Pump 3-3, 7-13
Drive Belt Inspection 6-17
Drive Belt Replacement 6-23
Drive Belt Tension 6-17
Drive Belt Tensioner 6-23
Inspection 6-20
Coolant/Fuel Heat Exchanger
 see Coolant Heat Exchanger
 see Fuel Heat Exchanger
Cooling System
 Drain and Flush 6-20
 Inspection 6-4
CRANK BATT A/B Switch 3-13, 4-4, 5-2
CRANK Signal 5-1
CRANK TERMINATE
 Input 3-7
 Potentiometer 6-15
 Set Point 5-3, 6-15
 Signal 5-1, 7-27
Crankcase Breather Tube 6-7
Cranking Systems Analyzer 3-6
Customer Supplied Wiring 3-6

D

Damage During Shipping 3-1
Diagnostic Service Tool 4-4
Diesel Fuel
 Recommendations 3-4
 Specifications 3-3
Dipstick 3-10
Drive Shaft
 Lubrication 3-3

E

ECM
 A/B Indicator Lights 4-4
 A/B Selector Switch 5-2
 Data Plate 4-4, 4-5
 Date Code (DC) 4-5
 Description 4-4
 Fault Code Lights 4-4, 5-3
 Part Number (PN) 4-5
 Serial Number (SN) 4-5
 Software Code 4-5
Electrical
 Connections 6-11
 Continuity 3-8, 7-14
 Fault 7-20
Electronic Control Module *see ECM*
Electronic Fuel System 2-7
Emergency Manual Mode Electrical Start 5-2

Emission Levels
 Tier 2 2-3
 Tier 3 2-3
Engine
 Alignment (to pump) 3-2
 Coolant *see Coolant*
 Coolant Heater 3-9, 6-9, 6-21, 7-13
 Crank Center Line 3-2
 Crankshaft Rotation 7-19
 Cylinder Head Pressure Test 7-26
 Electronic Fuel System 2-7
 Initial Startup 3-13
 Intake Manifold 7-26
 Low Oil Level Warning Lamp 4-6
 Low Oil Pressure Warning Lamp 4-6
 Manual Starting Procedure 5-2
 Monitoring after Startup 3-13
 Mounting Bolts 6-11
 Noise 6-9
 Oil 6-12, 6-13
 Oil and Filter Change 6-12
 Oil Capacity 6-13
 Oil Contamination 7-13
 Oil Cooler 7-10
 Oil Filter Mounting Head 6-14
 Oil Level .. 2-9, 3-10, 3-13, 6-4, 6-5, 7-13, 7-19
 Oil Level Dipstick 3-10
 Oil Pan Drain Plug 6-12
 Oil Pressure 3-13, 6-4, 6-9
 Oil Pressure Gauge 4-1
 Oil Recommendation 3-10
 Oil System 2-9, 3-10, 6-5
 Operating Speed 2-4, 5-3
 Operating Temperature 3-13
 Operation Report 6-1
 Overspeed Set Point 4-2
 Piston Ring Blowby 7-25
 Protection Fault 4-6
 Serial Number (ESN) 4-5
 Shutdown Lamp 4-4
 Speed Sensor 7-16, 7-27
 Start Test 3-11
 Starting (local) 5-2
 Starting (remote) 2-4
 Test Run 6-8
 Valve Lash Settings 6-22
Engine Overspeed
 Alarm Input 3-7
 Module 2-4
 RESET Button 4-2, 4-3
 RESET/STOP Switch 4-2, 4-3
 Set Point 5-3, 6-16
 Switch 2-4, 3-7, 4-5
 Warning Lamp 4-2

Engine Warning Lamp	4-4
Equipment Placement and Assembly	3-1
Exhaust System	2-9, 6-7
Flex Pipe	6-7
Manifold	6-7, 7-23
Piping	3-2
Expansion Tank Pressure/Fill Cap	3-8

F

Factory Mutual Approval	2-1
Fault Code	
Chart	7-3
Warning Lamps	4-4, 5-3
Fire Pump Controller	3-7
Control Panel	3-12, 5-1
Wiring	3-6, 3-7

Fuel

Air in the System	7-18
Control System	4-4
Cooler/Heat Exchanger	2-7
Filter	3-4, 6-13, 7-18
Filter/Separator	3-4, 6-6, 6-13, 7-18
Heat Exchanger	3-4
Heat Exchanger Pressure Test	6-19
High Pressure Injector (HPI) System	2-7
Injection Pump	7-23
Injection Timing	7-23
Injector System	2-7
Lift Pump	3-4
Line Pressure	6-6
Pump	3-4, 6-11
Pump Solenoid Valve	2-4
Recommendations	3-4
Return	3-3
Supply	2-7, 3-3, 6-6
Supply Valves	6-14
System Inspection	6-6
Tank	3-3
Tank Breather	7-20

G

Guards, Covers and Protective Devices	1-1
---	-----

H

High Pressure Fuel Pump	3-4
Hour Meter	4-2

I

Injection Pump <i>see Fuel</i>	
Insite Service Tool	4-4

L

Lift Pump	3-4
Lifting Hooks	3-1
Loose Wire Kit	3-6
Low Oil Pressure Alarm	3-8
Low Oil Pressure Warning Lamp	4-1, 4-3

M

Manual Mode Operation	4-2
Manual Starting Procedure	5-5

N

National Fire Protection Association (NFPA) ...	3-1
---	-----

O

Odors	6-4
Oil and Filter Change	6-12
Oil Pressure	3-13, 6-9
Oil <i>see Engine Oil</i>	
Operator Control Panel	2-3, 3-12, 5-2
Output Shaft	
Lubrication	6-14, 6-15
Universal Joint	3-3

P

Programmable Parameters	7-21
-------------------------------	------

R

Raw Water	
Bypass Valves	7-17
Cooling System	2-5
Flow	3-13
Flow Control Valves	4-6
Minimum Flow	3-13
Piping	3-1, 3-4, 3-8, 6-4, 7-12
Pressure Regulator	7-10
Solenoid Valve	7-14
Strainer	7-12
Strainer Cleaning	6-7
Supply	3-4
Recommended Spare Parts	8-1
Refractometer	6-9
Returned Goods Authorization (RGA)	8-1

S

Safety	
Awareness	1-1
Precautions	1-1
Shipping Manifest	3-1
Signal and Control Installation	3-6

Index

Site Preparation 3-1
Speed INCREASE/DECREASE Toggle Switch 6-16
 DEC (decrease) position 6-16
 INC (increase) position 6-16
Starter Motor 2-4, 7-19
Starting
 Manual (locally) 5-5
Starting Procedure
 Local 5-2
 Remote 2-4
Start-Up Inspection (SUI) Checklist 5-5
STOP/RESET Switch 5-2

T

Tachometer 4-2, 7-16
 Calibration 7-21
temperature gauge 7-13
temperature sender 7-13
Terminal Panels 6-10
Thermostat 6-23, 7-14
Troubleshooting Chart 7-8
Turbocharger
 Air Leaks 7-23
 Inspection 6-19
 Turbine Wheel 3-11, 6-20

V

Voltage Regulator 7-8
Voltmeters 3-8, 4-2, 6-11

W

Warning Lamp
 Low Oil Pressure 4-1
Warning Lamps 6-11
 Engine Overspeed 4-6
 Engine Shutdown 4-4
 Engine Warning 4-4
 High Coolant Temperature 4-6
 Low Coolant Level 4-6
 Low Coolant Temperature 4-6
 Low Oil Level 4-6
 Low Oil Pressure 4-6
Water
 see Coolant
 see Raw Water
Water Pump *see Coolant Pump*
Wire Damage 7-9
Wiring Harness 6-10